


CANDE-2007

Culvert Analysis and Design

User Manual and Guideline




Developed under National Cooperative Highway Research Project NCHRP 15-28

Update Release 7/31/2011
Version 1.0.0.7

CANDE-2007

Culvert Analysis and Design

User Manual and Guideline



Developed under National Cooperative Highway Research Project NCHRP 15-28

Update Release 7/31/2011

Version 1.0.0.7

Mark Mlynarski – Michael Baker Jr. Inc.
Moon Township, PA

Michael G. Katona – Consultant
Gig Harbor, WA

Timothy J. McGrath – Simpson, Gumpertz & Heger Inc.
Arlington, MA

(This page intentionally left blank)

TABLE OF CONTENTS

Updates (Release 1.0.0.7)	ix
1 Introduction.....	1-1
1.1 Purpose of CANDE.....	1-1
1.2 History of CANDE.....	1-1
1.3 CANDE Upgrade (NCHRP 15-28)	1-2
1.4 Why Use CANDE 2007?	1-3
1.5 How to use this manual	1-4
2 General Overview and Major Options	2-1
2.1 Scope and Architecture	2-1
2.2 Execution mode.....	2-1
2.3 Evaluation methodology	2-2
2.4 Solution levels.....	2-3
2.4.1 Level 1 – Elasticity Solution.....	2-3
2.4.2 Level 2 – Automated FEM Solution.....	2-3
2.4.3 Level 3 – User Defined FEM.....	2-4
2.5 Pipe groups and pipe types.....	2-4
2.5.1 Corrugated aluminum	2-5
2.5.2 Reinforced concrete	2-5
2.5.3 Thermoplastic pipe	2-5
2.5.4 Corrugated steel.....	2-6
2.5.5 Basic pipe type.....	2-6
2.6 System Choices	2-6
3 Getting Started	3-1
3.1 System requirements	3-1
3.2 Installation guide.....	3-1
3.3 Launching and running CANDE-2007.....	3-1
3.3.1 Locate and save example input problem.....	3-2
3.3.2 Test run an existing example problem.....	3-3
3.3.3 Example problems and tutorial.....	3-6
4 Graphical user interface (GUI)	4-1
4.1 Overview.....	4-1
4.2 Input Options.....	4-1
4.2.1 Creating a new CANDE input data file – CANDE Input Wizard.....	4-2
4.2.1.1 CANDE Input Wizard- Control Information	4-8
4.2.1.2 CANDE Input Wizard – Level 3 items	4-12
4.2.1.3 CANDE Input Wizard – Pipe Material	4-15
4.2.2 Opening an Existing CANDE Input Document with File->Open	4-18
4.2.3 Opening an Existing CANDE Input Document with File->Open Text Input.....	4-19
4.2.4 CANDE Input Menus	4-20
4.2.4.1 Menu input overview	4-20
4.2.4.2 Viewing help for the input menus	4-21
4.2.4.3 ‘Show Help’ checkbox.....	4-22
4.2.4.4 ‘Show Input’ checkbox	4-23
4.2.4.5 Input range violations.....	4-24
4.2.4.6 Input errors and undefined input	4-25
4.2.4.7 Menu input tree icons.....	4-26
4.2.5 Changing an existing CANDE input document to create a new data file	4-27
4.2.5.1 Create new CANDE input document from existing document with Input Menu.....	4-27
4.2.5.2 Create new CANDE input document from existing document with text editor	4-27
4.2.6 Create a CANDE input document using the CANDE input text editor	4-29
4.3 Running CANDE-2007	4-30
4.3.1 Successful execution.....	4-31
4.3.2 Unsuccessful execution	4-31
4.3.3 CANDE input consistency checking	4-31
4.3.4 Convergence and Nonconvergence of load steps	4-32

4.3.5	CANDE Analysis error messages.....	4-34
4.4	Output data and viewing options.....	4-36
4.4.1	CANDE Output Report.....	4-37
4.4.1.1	Master control and pipe type data	4-39
4.4.1.2	Review of system input data	4-39
4.4.1.3	Design solution (if applicable)	4-40
4.4.1.4	Solution/analysis output results.....	4-40
4.4.2	CANDE log file	4-42
4.4.3	Mesh Plot.....	4-44
4.4.3.1	Using window area to zoom in on mesh	4-45
4.4.3.2	Increasing/Decreasing the element/node font size	4-46
4.4.3.3	CANDE mesh viewer options button.....	4-47
4.4.3.4	Viewing element information.....	4-49
4.4.3.4	Viewing Deformed Shapes	4-50
4.4.3.5	Viewing soil stress/strain contours.....	4-51
4.4.3.6	Coincidental boundary conditions.....	4-52
4.4.4	CANDE Graphs for beam elements.....	4-53
4.4.4.1	Over view of CANDE Graph Selections.....	4-54
4.4.4.2	View of pipe-group shape and properties.....	4-55
4.4.4.3	Graph Options	4-56
4.4.5	Results generator	4-58
5	Detailed CANDE Input.....	5-1
5.1	Input flow charts	5-1
5.1.1	CANDE level 1 input flowchart	5-2
5.1.2	CANDE level 2 input flowchart	5-3
5.1.3	CANDE level 3 input flowchart	5-4
5.2	CANDE input instructions	5-5
5.3	Part A - Control Commands.....	5-6
5.3.1	A-1 – Master Control Input Data	5-6
5.3.2	A-2 –Pipe Selection	5-9
5.4	Part B- Pipe Materials	5-12
5.4.1	Aluminum Pipe Type.....	5-13
5.4.1.1	B-1 – Aluminum – Material and Control Parameters	5-13
5.4.1.2	B-2 – Aluminum – Analysis Section Properties.....	5-16
5.4.1.3	B-2 – Aluminum – Design Safety Factors and Deflection Control.....	5-18
5.4.1.4	B-2 – Aluminum – Design Weights for LRFD	5-20
5.4.1.5	B-3 – Aluminum – Resistance Factors for LRFD	5-22
5.4.2	Basic Pipe Type	5-24
5.4.2.1	B-1 – Basic – Sequence Intervals and Properties.....	5-24
5.4.2.2	B-2 – Basic – Large Deformation Control	5-26
5.4.3	Reinforced Concrete Pipe Type.....	5-27
5.4.3.1	B-1 – Concrete – Concrete Material Properties	5-27
5.4.3.2	B-2 – Concrete – Concrete Material Properties-2	5-30
5.4.3.3	B-3 – Concrete – Reinforcement Steel Placement and Properties	5-32
5.4.3.4	B-4 – Concrete-Case 1– Wall Thickness and Reinforcement Properties	5-35
5.4.3.5	B-4 – Concrete – Case 2 – Arbitrary Specified Wall Thickness	5-38
5.4.3.6	B-4 – Concrete – Case 3 – ASTM Box Wall Thicknesses and Haunches.....	5-40
5.4.3.7	B-4b – Concrete – Case 3 – ASTM Steel Placement for Boxes.....	5-42
5.4.3.8	B-4 – Concrete – Case 4 – Specified Wall Thickness and Working Stress SF	5-45
5.4.3.9	B-4 – Concrete – Case 5 – Specified Wall Thickness/LRFD Design Weights	5-47
5.4.3.10	B-5 – Concrete – Resistance Factors for LRFD	5-49
5.4.4	Plastic Pipe Types.....	5-51
5.4.4.1	B-1 – Plastic – Plastic Load Controls.....	5-51
5.4.4.2	B-2 – Plastic – Material Properties for Plastic	5-52
5.4.4.3	B-3 – Plastic – Cross Sectional Properties for Smooth or General	5-54
5.4.4.4	B-3 – Plastic – Profile Wall Cross Sectional Properties-1	5-55

5.4.4.5	B-3b – Plastic – Cross Sectional Properties (2) (Profile)	5-58
5.4.4.6	B-3 – Plastic – Safety Factors for Working Stress Design.....	5-60
5.4.4.7	B-3 – Plastic – Design Weights for LRFD	5-62
5.4.4.8	B-4 – Plastic – Resistance Factors for LRFD.....	5-64
5.4.5	Steel Pipe Type.....	5-66
5.4.5.1	B-1 – Steel – Material Properties and Control	5-66
5.4.5.2	B-2 – Steel – Section Properties.....	5-69
5.4.5.3	B-2 – Steel – Design Safety Factors for Working Stress	5-71
5.4.5.4	B-2 – Steel – Design Weights for LRFD	5-73
5.4.5.5	B-2b – Steel – Joint Properties.....	5-75
5.4.5.6	B-2c – Steel – Joint Locations and Properties.....	5-78
5.4.5.7	B-2d – Steel – Joint Locations and Properties (2).....	5-80
5.4.5.8	B-3 – Steel – Resistance Factors for LRFD	5-82
5.5	Part C- Solution Levels	5-84
5.5.1	Solution Level 1.....	5-85
5.5.1.1	C-1 – Level 1 – Major Input Parameters	5-85
5.5.1.2	C-2 – Level 1 – Fill Heights and Soil Parameters.....	5-88
5.5.1.3	C-3 – Level 1 – Load Factors for LRFD	5-90
5.5.2	Solution Level 2 – Pipe Mesh.....	5-91
5.5.2.1	C-1 – Level 2 – Pipe Mesh – Control Commands and Title	5-91
5.5.2.2	C-2 – Level 2 – Pipe Mesh – Major Geometry and Loading Parameters.....	5-93
5.5.2.3	C-3 – Level 2 – Pipe Mesh – Control Variables	5-95
5.5.2.4	C-4 – Level 2 – Pipe Mesh – Embankment/Trench Mesh Dimensions	5-97
5.5.3	Solution Level 2 – Box Mesh	5-105
5.5.3.1	C-1 – Level 2 – Box Mesh – Control Commands and Title.....	5-105
5.5.3.2	C-2 – Level 2 – Box Mesh – Control Variables/Installation Dimensions	5-107
5.5.4	Solution Level 2 – Arch Mesh.....	5-114
5.5.4.1	C-1 – Level 2 – Arch Mesh – Control Commands and Title	5-114
5.5.4.2	C-2 – Level 2 – Arch Mesh – Plot and Print Control.....	5-116
5.5.4.3	C-3 – Level 2 – Arch Mesh – Arch and Footing Dimensions	5-119
5.5.4.4	C-4 – Level 2 – Arch Mesh – Arch and Footing Dimensions	5-121
5.5.5	Extended Level 2	5-131
5.5.5.1	CX-1 – Level 2 Extended – Nodes, Elements and Boundary Condition Changes	5-131
5.5.5.2	CX-2 – Level 2 Extended – Nodal Point Number and Changed Coordinates.....	5-132
5.5.5.3	CX-3 – Level 2 Extended – Element Number and Property Array.....	5-133
5.5.5.4	CX-4 – Level 2 Extended – Nodal Loads and/or Displacements to be applied	5-135
5.5.6	Solution Level 3.....	5-137
5.5.6.1	C-1 and C2 – Level 3 – Title and Control Variables.....	5-137
5.5.6.2	C-3 – Level 3 – Node Input.....	5-141
5.5.6.3	C-4 – Level 3 – Element Input.....	5-146
5.5.6.4	C-5 – Level 3 – Boundary Condition Input.....	5-152
5.6	Part D- Soil and/or Interface Property Input	5-156
5.6.1	D-1 – Material Control Parameters for All Models	5-157
5.6.2	D-2 – Isotropic Linear Elastic – Elastic Parameters	5-162
5.6.3	D-2 – Orthotropic Linear Elastic – Elastic Parameters	5-163
5.6.4	Duncan and Duncan/Selig Model Types	5-165
5.6.4.1	D-2 – Duncan – Fundamental Controls.....	5-165
5.6.4.2	D-3 – Duncan/Duncan Selig – Parameters for Tangent Young’s Modulus	5-168
5.6.4.3	D-4 – Duncan/Duncan Selig – Parameters for Tangent Bulk Modulus	5-170
5.6.5	D-2–Overburden Dependent–User Defined Elastic Prop. vs. Overburden Pressure	5-172
5.6.6	D-2 – Extended Hardin Soil Model	5-175
5.6.6.1	D-2 – Hardin Soil Model Input for Special MATNAM.....	5-175
5.6.6.2	D-2 – Hardin Soil Model Input for MATNAM = USER	5-177
5.6.7	D-2 – Interface Element – Angle, Friction and Tensile Breaking Force	5-179
5.7	Part E- Net LRFD Load Factors.....	5-182
5.7.1	E-1 – LRFD – Net Load Factor per Load step.....	5-182

6	List of References	1
6.1	Background Documents	1
6.2	Companion Documents	1
7	Appendices.....	7-1
7.1	CANDE Output Files	7-1
7.1.1	XML Mesh Geometry Format	7-3
7.1.2	Mesh results format	7-7
7.1.3	Beam results format.....	7-11
7.1.4	NCHRP Process 12-50 Results.....	7-14
7.1.5	CANDE-2007 Output Files for Plotting	7-16
7.1.5.1	Contents of PLOT1.DAT	7-16
7.1.5.2	Contents of PLOT2.dat	7-18
7.2	CANDE NASTRAN Import Format	7-21
7.2.1	NASTRAN Input Data Card- GRID- Point	7-22
7.2.2	NASTRAN Input Data Card-CBAR Simple Beam Element.....	7-23
7.2.3	NASTRAN Input Data Card-CTRIA3-Triangular Plate Element	7-24
7.2.4	NASTRAN Input Data Card-CQUAD4-Quadrilateral Plate Element.....	7-25
7.2.5	NASTRAN Input Data Card- PSHELL-Shell Element Property	7-26
7.2.6	NASTRAN Input Data Card-CGAP-Gap Element Connection	7-27
7.2.7	NASTRAN Input Data Card-SPC-Single Point Constraint	7-28
7.2.8	Input Data Card-FORCE-Static Load.....	7-29

List of Tables

Table 3.3-1 – File-tab menu options for input data files.....	3-2
Table 5.3-1 – Reference data on culvert elements used in canned meshes.....	5-11
Table 5.4-1 Aluminum-1. Section Properties for Standard Aluminum Corrugation.....	5-17
Table 5.4-2 Aluminum -2. Section Properties for 9 x 2 ½ Aluminum Corrugation	5-17
Table 5.4-3 – Plastic: Typical range of plastic properties from AASHTO LRFD Specification.....	5-53
Table 5.4-4 – Steel -1: Section Properties for Standard Steel Corrugation Sizes	5-70
Table 5.4-5 – Steel 2 – Section Properties for 6”x 2” Structural Plate	5-70
Table 5.5-1 – Level 1 – Conservative values for Young’s soil modulus and Poisson’s ratio.....	5-89
Table 5.5-2 – Pipe Level 2 – Node renumbering scheme for inserting eleven pipe-soil interface elements around the pipe	5-103
Table 5.5-3 – Pipe Level 2 – Node renumbering scheme for inserting seven pipe-soil interface elements along the trench wall	5-104
Table 5.5-4 – Level 2 Arch – Values for the basic arch parameters as a function of height cover.....	5-128
Table 5.5-5 – Level 2 Arch – Identification of arch and soil nodes that are tied together by interface elements.....	5-129
Table 5.5-6- Level 2 Arch – Identification of element numbers for interface elements as a function of cover height.....	5-130
Table 5.5-7 – Classification of IIFLG Boundary Code numbers.....	5-155
Table 5.6-1 – Summary of special material names (MATNAM).....	5-159
Table 5.6-2 – Material numbers for predefined level 2 material zones	5-160
Table 5.6-3 – Material numbers for predefined Level 2 interface numbers	5-161
Table 5.6-4 – Material names (MATNAM) and values for Duncan model (IBULK=0).....	5-167
Table 5.6-5 – Material names (MATNAM) and values for Duncan/Selig model (IBULK=1)	5-167
Table 5.6-6 – Material names (MATNAM) and values for Overburden Dependent Model	5-174
Table 5.7-1 – Guidance on selecting the net load factor (FACTOR)	5-184
Table 7.1-1 – NCHRP Tag format.....	7-14
Table 7.1-2 – NCHRP Process 12-50 Report ID table	7-15
Table 7.2-1 – NASTRAN commands support by CANDE import.....	7-21

(This page intentionally left blank)

Table of Figures

Figure 2.2-1 – Major options to define the top-level input data for CANDE-2007.....	2-2
Figure 3.3-1 – Starting CANDE.....	3-1
Figure 3.3-2 – CANDE-2007 Startup Window.....	3-2
Figure 3.3-3 – Sample Level 1 CANDE input file	3-3
Figure 3.3-4 – Opening a CANDE input file.....	3-3
Figure 3.3-5 – CANDE input file after open	3-4
Figure 3.3-6 – Successful completion of CANDE analysis.....	3-5
Figure 3.3-7 – Accessing the CANDE tutorials	3-6
Figure 4.1-1 – CANDE GUI overview.....	4-1
Figure 4.2-1 - Creating a new CANDE input document	4-2
Figure 4.2-2 – CANDE Input Wizard startup screen.....	4-3
Figure 4.2-3 – CANDE Input Wizard Level 3 Information.....	4-3
Figure 4.2-4- CANDE Input Wizard: Pipe Material screen	4-4
Figure 4.2-5 – CANDE Input Wizard Final Screen.....	4-5
Figure 4.2-6 – Saving a CANDE input file	4-5
Figure 4.2-7 – CANDE Interface after new CANDE input document is created	4-6
Figure 4.2-8 - CANDE menu with ‘undefined’ input.....	4-7
Figure 4.2-9 – CANDE import dialog box	4-13
Figure 4.2-10 – Import log window.....	4-13
Figure 4.2-11 – Opening an existing CANDE input document.....	4-18
Figure 4.2-12 – Opening an existing CANDE input document in the CANDE input text editor.....	4-19
Figure 4.2-13 CANDE input menu overview	4-20
Figure 4.2-14 – Activating CANDE input menu persistent help.....	4-22
Figure 4.2-15 – Activating CANDE input menu ‘Show Input’	4-23
Figure 4.2-16 – CANDE input menus range violation	4-24
Figure 4.2-17 – Error in CANDE input menus with an invalid character	4-25
Figure 4.2-18 – Opening an existing CANDE input document using the CANDE input text editor	4-27
Figure 4.2-19 – Summary of CANDE input text editor.....	4-28
Figure 4.3-1 – Running CANDE-2007 analysis.....	4-30
Figure 4.3-2 – View of CANDE Analysis while running.....	4-30
Figure 4.4-1 – CANDE output view options	4-36
Figure 4.4-2 – Viewing the CANDE output report	4-37
Figure 4.4-3 – CANDE Output Viewer.....	4-38
Figure 4.4-4 – Viewing the CANDE log file.....	4-42
Figure 4.4-5 – Viewing the CANDE log file.....	4-42
Figure 4.4-6 – CANDE mesh plot options	4-44
Figure 4.4-7 – Zooming in on a mesh using Window-Area	4-45
Figure 4.4-8 – Increasing/Decreasing font size in Mesh Plot viewer	4-46
Figure 4.4-9 – Mesh viewer options	4-47
Figure 4.4-10 – Displaying element information in the mesh viewer	4-49
Figure 4.4-11 – Plotting deflections using the mesh viewer.....	4-50
Figure 4.4-12 – Sample plot of Horizontal Stress	4-51
Figure 4.4-13 – CANDE Graph of bending moment.....	4-53
Figure 4.4-14 – Overview of CANDE Graphs	4-54
Figure 4.4-15 – CANDE Graphs window – Pipe Mesh Button.....	4-55
Figure 4.4-16 – CANDE Graphs window with local node numbering mesh	4-55
Figure 4.4-17 – Beam graph options	4-56
Figure 4.4-18 – Plotting multiple load steps with CANDE Beam Graph.....	4-57
Figure 4.4-19 – CANDE results generator – Generate Mesh Output tab	4-58
Figure 4.4-20 – CANDE results generator – Beam Output tab	4-59
Figure 4.4-21 – CANDE results generator – Report Preview tab.....	4-60
Figure 5.4-1 – Aluminum-1: Bilinear stress-strain parameters	5-15
Figure 5.4-2 – Concrete Stress-Strain model and parameters.....	5-29
Figure 5.4-3 – Cross sections for RSHAPE = STAND or ELLIP	5-37

Figure 5.4-4 – ASTM Concrete box geometry and steel placement for box culverts with a minimum 2-foot cover depth.....	5-44
Figure 5.4-5 - Plastic – Elastic stress-strain model for plastic in tension and compression, short term and long term loading.....	5-53
Figure 5.4-6 – Example Profile Shapes that can be constructed in CANDE.....	5-57
Figure 5.4-7 – Steel-1: Bilinear stress-strain parameters.....	5-68
Figure 5.4-8 – Steel-2 – Pseudo stress-strain model for slotted joints.....	5-77
Figure 5.5-1 – Level 1 – Illustration of Level 1 boundary value problem.....	5-87
Figure 5.5-2 – Level 2-Pipe-Embankment/Homogeneous mesh with load steps and materials.....	5-99
Figure 5.5-3 – Level 2-Pipe-Trench mesh with load steps and material zones	5-100
Figure 5.5-4 – Element numbering scheme for Level 2 pipe mesh (CAN1).....	5-101
Figure 5.5-5 – Nodal numbering scheme for Level 2 Pipe Mesh, (embankment and trench).....	5-102
Figure 5.5-6 – Level 2 Box – Embankment mesh configuration for box with load steps and material zones	5-110
Figure 5.5-7 – Level 2 Box – Trench mesh configuration for box with construction increments and material zones.....	5-111
Figure 5.5-8 – Level 2 Box – Element numbering scheme for box mesh for embankment and trench... 5-112	5-112
Figure 5.5-9 – Level 2 Box – Nodal numbering scheme for box mesh for embankment and trench	5-113
Figure 5.5-10 – Level 2 Arch – Embankment mesh configuration for Arch with load steps and material zones.....	5-123
Figure 5.5-11 – Level 2 Arch – Trench mesh configuration for Arch showing load steps and material zones	5-123
Figure 5.5-12 - Level 2 Arch - Illustration of parameters for 3-segment and 2-segment arch with curved segments	5-124
Figure 5.5-13 – Level 2 Arch – Illustration of parameters for 3-segment and 2-segment arch with straight segments	5-125
Figure 5.5-14 – Level 2 Arch – Element numbering for Arch Mesh for all Arch configurations at maximum fill height, total view.....	5-126
Figure 5.5-15 – Level 2 Arch – Element numbering scheme for Arch Mesh for all arch configurations at maximum fill height, enlarged portion.....	5-126
Figure 5.5-16 – Level 2 Arch – Nodal numbering scheme for Arch Mesh for all arch configurations at maximum fill height, total view	5-127
Figure 5.5-17 – Level 2 Arch – Nodal numbering scheme for Arch Mesh for basic arch configurations, enlarged portion.....	5-127
Figure 5.5-18 - Level 3 – CANDE Elements with nodal connectivity	5-150
Figure 5.5-19 – Level 3 – Illustration of element generation	5-151
Figure 7.1-1 – Sample NCHRP Process 12-50 results	7-14

Updates (Release 1.0.0.7)

The following updates are included for release 1.0.0.7

- **April 21, 2008.** In Subroutine BMResultXML there was an error in Format 9080 in writing RESULT (14,n). Specifically there was an extraneous number 1 following the format field, 'E14.6' which caused the wrong exponent for the PA* variable in the Graph plots and Report Generator.
- **May 6, 2008.** Subroutine STIFNS was modified to handle incremental displacement boundary condition loading over the entire load step schedule. The original version of CANDE-2007 is limited to inputting non-zero specified displacements only on the first load step. This limitation is now removed.
- **October 28, 2008.** Modified Subroutine READM to correct error in distinguishing canned soil models between Duncan and Duncan/Selig forms. MATNAMs are not all unique, that is, CL85 and CL90 are names common to both Duncan and Duncan/Selig model names. CANDE now uses IBULK = 0 or 1 to distinguish which model the user is requesting. No change of input is required.
- **January 17, 2009.** Improved convergence of Duncan and Duncan/Selig Soil model for the case when there is chattering between the tension failure path and the normal compression path. Once the tension path has been activated for any iteration during the load step, we set STHARD (NEL,3) = 1, so that all subsequent iterations in this load step will follow the tension path. Note that STHARD(NEL,3) was not previously being used in the Duncan Subroutine.
- **April 14, 2010.** The bandwidth minimizer was discovered not to work well when "unused node numbers" are present in the mesh system. Unused node numbers are those nodes that are not included in the connectivity array of any element. The fix is related to the selection of Node-2 for the swap, where we must enforce that "unused nodes" are not candidates for swapping. The fix is working well.
- **June 23, 2010.** Introduced "initial gap" capability into interface element. In essence the initial gap means the contact nodes I and J stay in the free-free state until the relative normal displacement of nodes I and J close the gap. After the gap closes the interface behaves exactly as it did before. This feature requires a new material input property called the "initial gap", which heretofore was assumed to be zero. Thus, the new set of interface properties on input line D-2 are; interface angle, friction coefficient, tensile break force and initial gap (XNGAP) where the initial gap is read in columns 30-40, a space that was previously blank. Thus if the input value is blank (or zero) then the interface element behaves exactly like before.
- **July 31, 2011:** Changes to allow CANDE to function in the Windows 7 operating system.
- **July 31, 2011** – Modification to the menu input system for the GAP command for input line D-2.
- **Jul 31, 2011** – Updates to the User Manual and corresponding help file.

1 Introduction

1.1 Purpose of CANDE

CANDE-2007 is public-domain computer program developed for the structural design and analysis of buried culverts; hence the acronym CANDE stands for **Culvert ANALysis and D**esign. CANDE's finite-element methodology is based on a two-dimensional slice of the culvert installation so that both the culvert structure and soil mass are modeled as a combined soil-structure system subjected to an incremental loading schedule. Buried culverts of any shape, size and material, including corrugated metal, reinforced concrete and thermoplastic, may be analyzed and designed to withstand dead weight, incremental soil-layer loading, temporary construction loads and surface loads due to vehicular traffic. A particularly unique feature of CANDE's output is the automatic evaluation of the structural design in terms of safety measures against all failure modes (design criteria) associated with the structural material.

Because of the generality offered by the finite-element solution methodology, CANDE is also applicable to the design and analysis of other soil-structure interaction problems such as underground storage facilities, storm water runoff chambers, retaining walls, tunnel liners, and protective structures. Thus in the following discussion, the words "culvert" or "pipe" can generally be regarded to represent a general underground structure.

This manual describes CANDE-2007, which is the latest version in a 30-year history of usage and development of the CANDE series of programs. This documentation provides a complete description of the theory, capabilities and limitations contained in CANDE-2007 so that the user need not refer to any other manuals or publications to confidently run the program and interpret the output.

CANDE users range from designers to researchers including state DOT bridge engineers, design consultants, manufacturers and suppliers, and university investigators. State DOT designers and their consultants use CANDE when they are confronted with designing large or specialized installations and to choose among alternative designs such as a reinforced concrete arch versus a corrugated metal long span. Culvert suppliers and manufacturers use CANDE to design their products for both routine and specialized installations as well as for investigating new innovations and product improvements. University researchers use CANDE as an analytical tool to interpret experimental tests as well as to test out new modeling theories within the program. CANDE-2007 is intended to meet all of these users' needs.

1.2 History of CANDE

The first version of CANDE was released in 1976 (References 1 & 2) under the sponsorship of Federal Highway Administration (FHWA). The development work, a three-year research program, was conducted at the Naval Civil Engineering Laboratory in Port Hueneme California. The original release of the CANDE program contained the following options and features (to be described more fully in later chapters):

- Execution mode choice: Analysis or Design.
- Solution level choice: Level 1, 2 or 3. Level 1 is a modified elasticity solution, Level 2 is a finite element solutions with an automated mesh for circular culverts, and Level 3 is a finite element solution with a user-defined mesh.
- Pipe type choice: Corrugated aluminum, basic, reinforced concrete, plastic, and corrugated steel.
- Soil model choice: Linear elastic, overburden dependent, and nonlinear hyperbolic model by Hardin
- Interface choice: Bonded, frictionless, or friction at soil-structure interface.

In 1979 FHWA awarded the University of Notre Dame (Reference 3) a research contract to extend the CANDE program by adding an automated Level-2 finite element mesh for reinforced concrete box culverts along with an improved concrete constitutive model. Also, this contract included installing the Duncan

hyperbolic soil model originally developed at University of California at Berkeley. Later in 1982, FHWA awarded the University of Notre Dame another research contract to develop a special model for corrugated metal culverts to simulate the behavior of slotted joints. This study demonstrated that slotted joints, which allow slippage and circumferential shortening of the culvert, are very effective in reducing the thrust stress in the culvert wall.

Lastly in 1987, FHWA awarded a “CANDE maintenance contract” to Syro Steel Company, a company at the time using CANDE on a daily basis to design long-span arch culverts. The main purpose of this contract was to produce a unified user manual, which incorporated all the previous upgrades to CANDE and to insure that the input/output programming was compatible with personal computers (Reference 4). In addition, a new Level-2 capability for arch culverts was developed along with a revised form of the hyperbolic soil model, referred to as the Duncan/Selig model based on research at the University of Massachusetts, Amherst.

The final result of the FHWA sponsorship is CANDE-89, a public domain program available at a nominal cost through McTrans. Excluding the NCHRP sponsorship discussed next, no additional public-domain improvements have been on CANDE since 1989. However, there have been numerous improvements made by individuals and private companies for their specific use. One private company has extensively modified CANDE-89 and is marketing the revised program as CandeCAD. There is absolutely no collaboration whatsoever between this privately marketed program and CANDE-2007.

1.3 CANDE Upgrade (NCHRP 15-28)

In May 2005, TRB/NCHRP negotiated a contract with Michael Baker Jr., Inc to modernize and upgrade CANDE-89 under the sponsorship of AASHTO. The project known as the CANDE Upgrade project, designated as NCHRP 15-28, is the funding source for the enhancements that have been incorporated into CANDE-2007 and this documentation.

The CANDE Upgrade project targeted the following three areas for enhancement:

- Pre- and Post-processing with modern computer technology
- New analysis capabilities and architecture for multiple structures
- Update design criteria for all culvert types, including LRFD methodology.

Pre- and Post-processing. All previous versions of CANDE operated in a batch input mode without dedicated graphical-unit-interface software to aid the user in data preparation. Similarly, output data was written to a print file without any post-processing capability to graphically display results.

These shortcomings have been rectified under the CANDE Upgrade project so that CANDE 2007 is now equipped with a Windows®-based, menu-driven format for interactive data input and real-time control of data output along with a context-sensitive help system and numerous graphical plotting options. Details on using these new interactive features are discussed in subsequent chapters.

New analysis capabilities. One of the limitations of the old CANDE architecture was that each analysis was restricted to one, sequentially connected, set of beam elements (one pipe group), which represented a single culvert shape composed of one material. The new architecture installed in CANDE-2007 allows the use of multiple pipe groups, thereby allowing an analysis of several culverts placed side-by-side pipe, or a retrofit design, say a plastic pipe inserted inside a corrugated steel pipe.

Another limitation of the old CANDE program was its restriction to small deformation theory, and accordingly, its inability to directly predict global buckling of the culvert system. An updated Lagrange formulation has been incorporated into CANDE-2007 that provides an accurate and robust algorithm for predicting large deformations along with methodology for predicting buckling capacity at the end of each load step.

Still another shortcoming of the old CANDE program was the requirement that the user assign the nodes numbers on the finite element mesh in a judicious manner to avoid producing an excessively large bandwidth for the system matrix. This shortcoming has been eliminated in CANDE-2007 by including an automated bandwidth minimizer.

Design Criteria and LRFD Methodology. The original CANDE program was based on the concept of service-level loads and working-stress design methodology. Accordingly, the old CANDE output reported safety factors against various modes of failure (design criteria) that have been traditionally associated with the type of culvert being considered. In recent years AASHTO (Reference 6) has promoted the ultimate strength design approach known as Load Resistance Factor Design (LRFD) methodology. Rather than using safety factors, the LRFD methodology uses load factors and resistance factors to achieve a safe design.

As part of the CANDE Upgrade project, a complete and compatible set of design criteria, applicable to both working-stress and LRFD methodologies, was identified for the common culvert materials; corrugated metal, reinforced concrete, and thermoplastic pipe. These design criteria are now incorporated in the corresponding pipe subroutines of the CANDE-2007 program. More importantly, the user now has the option to choose either service load (working-stress evaluation of the design criteria) or factored loading (LRFD evaluation of the design criteria.)

Many improvements have been incorporated into CANDE-2007 that are not mentioned in the major improvements listed above. It should be noted, however, that all the capabilities and options that existed in the CANDE-1989 version have been retained. Said another way, the CANDE Upgrade project added to and improved upon the existing capabilities of CANDE-89, nothing was removed.

1.4 Why Use CANDE 2007?

The popularity of CANDE is, in part, due to the rigorous adherence to the principle of good mechanics and to the trustworthiness of the program, earned over 30 years of testing and improvement. Early on in the development of CANDE, an independent study at Purdue University rated CANDE as the best program among a suite of computer programs developed for soil-structure interaction (Reference 5).

Equally important to CANDE's popularity is that, unlike most commercial software, CANDE is available with its source coding language and documentation of the programming structure. From the beginning, CANDE's programming architecture was designed with the forethought that future additions and modifications would always continue. Accessibility to the source program is an extremely important feature for researchers who often want to test new theories and models as part of their research program. Successful research studies on new modeling techniques benefit the entire community.

The question of whether or not to use CANDE-2007 should not be a question of choosing one computer program over another. After all, since CANDE is virtually free (public-domain), acquiring and using CANDE does not preclude one from buying and using a commercial program. There are several commercial finite element programs that are well suited for soil-structure analysis, for example PLAXIS, ABACUS and ADINA are well-trusted programs, and they also have been successfully cross-tested against CANDE-2007. Many commercial programs are "general purpose" and their capabilities go well beyond CANDE's two-dimensional scope. Certainly, there are times when a 3-dimensional analysis is necessary to understand the behavior of some soil-structure systems. However in the case of the culvert world, a 2-D representation is generally quite adequate in most situations where the soil load is dominant. For a point live load with shallow cover, the 2-D representation will generally give a conservative evaluation of the culvert performance.

What makes CANDE-2007 a special purpose program, differing from the general purpose programs mentioned above is the automatic evaluation of the culvert performance in terms of well-accepted design

criteria. That is, CANDE sorts through all the mechanistic responses of deformations, stresses, strains, thrust, moments and shears and summarizes the pipe performance in terms of safety factors or demand-to-capacity ratios.

1.5 How to use this manual

This manual is intended to give the reader ample information to understand the overall the program architecture and assumptions, to define and select input data, to run the program using the graphical unit interface (GUI) or in batch mode, and to navigate, plot and interpret the output data. A companion document, *CANDE-2007 Solution Methods and Formulations*, contains the mathematical developments that describe the various theoretical formulations and nonlinear models that are contained in CANDE-2007. A second companion document, *CANDE-2007 Tutorials for Applications*, provides examples of applying CANDE to a variety of real-world culvert applications.

In this manual, Chapter 2 provides the reader with the overall architecture, capabilities and major input options, Chapter 3 provides the basic instructions to get started using the CANDE-2007 program, and Chapter 4 describes how to use the GUI for inputting data, executing the program, and viewing the output. Chapter 5 is the detailed user manual that provides stand-alone instructions for batch-mode input as an alternative to input via the GUI. Thus Chapter 5 serves as the main reference manual for GUI and batch-mode input, and it contains a wealth of information on culvert design and analysis practices.

2 General Overview and Major Options

2.1 Scope and Architecture

CANDE's scope is limited to a two-dimensional framework, called plane-strain, and to real-time independence, implying pseudo-static loading. Thus, three-dimensional problems, or dynamic analysis or the analysis of viscid materials is outside the scope of the formulation. However, CANDE's scope does include a pseudo-time analysis capability, called incremental construction. This capability allows, not only specified load forces, but also structural-system components, to be added to the system in a predefined series of load steps. Although CANDE's scope is not limited to culvert installations, the following discussion is keyed to culvert installations.


The easiest way to understand CANDE's overall architecture is to view it from the perspective of a user who is using CANDE to solve a particular soil-culvert problem. To initiate a CANDE solution, the user begins by making several top-level choices that best captures the character of problem to be solved.

Figure 2-1 shows these top-level selection categories in shaded boxes designated as; Execution Mode, Evaluation Methodology, Solution Level, Pipe Groups and Type, and System Choices. To the right of the shaded boxes are the various choices that may be selected for each top-level category; only one choice is selected for each category in any particular problem. The particular set of choices for the top-level categories dictates the subsequent stream of input data. It also controls the solution flow path through the program as well as characterizing the nature of the output. Each top-level category is discussed below

2.2 Execution mode

Execution mode is the choice between design and analysis. By analysis it is meant that a particular culvert and soil system are defined in terms of geometry, material properties and loading conditions and solved by the chosen solution level. The solution output provides an evaluation of the culvert in terms of its safety for all potential modes of failure associated with the structural material and shape of the culvert. The evaluation of the culvert's safety is reported either in terms of safety factors or in ratios of factored demand-to-factored capacity depending on the user's choice of the Evaluation Methodology. The analysis mode is generally the most useful and commonly used choice for the execution mode.

The alternative execution mode, called design, implies that the culvert shape, materials and loading conditions are defined exactly like the analysis case. However, the culvert's cross-sectional properties are not defined, but rather, the desired safety factors or the desired LRFD design weights are specified. CANDE achieves a design solution through an iterative series of analysis solutions. That is, an initial trial cross-section is devised by the program and successively modified after each analysis until the design criteria are satisfied in an optimum manner. The design output lists the required cross-sectional properties of the culvert, which, of course, depend on the culvert type. For example, design solutions for corrugated metal culverts are given in the required corrugation size and gage thickness while reinforced concrete is given in the required area of reinforcement steel for one or two cages. Automated design solutions are limited to certain classes of standard soil-culvert systems.

Figure 2.2-1 – Major options to define the top-level input data for CANDE-2007

2.3 Evaluation methodology

The evaluation methodology is the choice between a working-stress solution and a LRFD solution. A working-stress solution means the applied loads are the actual (or perceived) set of loads acting on the soil-structure system, referred to as the service-loading schedule. Thus, the service-loading schedule represents the actual dead weight of the structure, the actual weight density of the various soil zones, and the actual pressures and forces from construction equipment and live loads. Evaluation of the culvert's performance under the working stress option is reported in terms of safety factors for each design criterion associated with the selected culvert type. A safety factor is defined as are a ratio of the actual capacity-to-actual demand. For example, the safety factor for the design criterion based on thrust stress is the material yield stress divided by the maximum computed thrust stress.

A LRFD solution means the service-loading schedule is increased by individualized load factors. The user begins by defining the service-loading schedule in exactly the same manner as for working-stress methodology. Later in the input stream, the user selects appropriate load factors to be applied to each load step so that the dead loads, earth loads, and live loads may be assigned individual factors as required by

AASHTO LRFD specifications. Evaluation of the culvert's performance under the LRFD option is provided in terms of ratios of factored demand-to-factored capacities for each design criterion associated with the selected culvert type. An evaluation ratio should be less than 1.0 in order for a given design criterion to be considered safe.

Since the fundamental design criteria (potential failure modes) are identical for working-stress and LRFD methodologies, one could use the LRFD methodology to get a working-stress solution by setting all load factors and resistance factors equal to 1.0. In this case, the reported LRFD ratios would be the inverse of the working-stress safety factors.

The AASHTO LRFD specifications include restrictions on service loading performance in addition to the factored strength limit states discussed above. Typical examples for service load performance criteria are maximum allowable deflection for flexible culverts and maximum allowable crack width for concrete culverts.

One way to satisfy the AASHTO specifications is to run a given problem twice, once with LRFD methodology to assess the strength design criteria, and once with working-stress methodology to assess the service load performance criteria. However, the LRFD methodology programmed into CANDE-2007 also provides an estimate of the service load responses associated with the performance criteria. This is achieved by dividing the incremental response from the factored load step by the current load factor and maintaining a running total of the response. This approach provides the exact service load response if the system is entirely linear. However, since the system is generally nonlinear at factored load levels, the predicted response is approximate but conservative. Thus, if the service load performance criteria are safe, a separate working stress solution is not necessary.

2.4 Solution levels

The selection of a Solution Level (1, 2, or 3) provides a choice that corresponds to successively increased levels of analytical sophistication. The solution level concept permits the user to choose a degree of rigor and modeling fidelity commensurate with the details and knowledge of the culvert-soil system under investigation. For example, Level 1 is useful for screening and comparing various circular-shaped culverts in deep burial. Level 2, considered the “work-horse” of CANDE, is applicable to many common culvert shapes including circular, elliptical, box and arch installations, but limited to center-line symmetry for loading and geometry. Level 3 is virtually unlimited in modeling the structure shape, soil system and loading conditions. Level 2 and Level 3 share a common finite element solution methodology and only differ in the manner of input data: automatic versus user defined.

2.4.1 Level 1 – Elasticity Solution

Level 1 is based on the well known Burns and Richard elasticity solution (Reference 7) and is suitable for circular culverts deeply buried in homogenous soil subjected to gravity loading. Although the elasticity solution is based on material linearity and uniform pipe stiffness properties, Level 1 approximates the pipe's nonlinear behavior by averaging the effective stiffness properties in the following manner. After each load step, the elasticity solution provides a prediction of the structural responses including the moment, thrust and shear distribution around the pipe periphery. Next, the selected pipe-type subroutine processes the structural responses to determine the current level of structural distress at discrete points around the periphery including the effective bending and hoop stiffness. The current stiffness values around the pipe are averaged to provide effective uniform stiffness properties to be used in the next load step. The method works reasonably well as long as the structural distress is not too localized. Overall, Level 1 is useful as a learning tool on the comparative behavior of culvert types and soil stiffness.

2.4.2 Level 2 – Automated FEM Solution

Known as the automatic finite element option, Level 2 relieves the user from the burden of generating and debugging a finite element mesh, i.e., defining node numbers and coordinates and element connectivity arrays. Rather, Level 2 automatically constructs the finite element mesh based on a few physical input

parameters. Level 2 offers three fundamental choices for culvert shape, referred to as pipe-mesh, box-mesh and arch-mesh options. The pipe-mesh option is for round- or elliptical-shaped culverts, the box-mesh option is for rectangular-shaped culverts, and the arch-mesh option is for two- or three-segmented arches including straight leg segments. Each of these “canned mesh shapes” are specialized by a set of physical input parameters such as the culvert dimensions, the installation type (embankment or trench), bedding dimensions, height of cover, and the number of incremental construction layers.

A special feature, called Level 2 – extended, allows the user to change nodal coordinates, element properties, and/or boundary conditions on any of the canned meshes. This feature is particular useful for prescribing live loads representing construction equipment or design truck vehicles for any load step in the loading schedule.

The major shortcoming of all Level 2 canned meshes is the assumption of symmetry about the vertical centerline of the culvert (i.e., only one-half the system is modeled). Thus asymmetric loading or different soil conditions on either of the culvert are not appropriate for Level 2.

2.4.3 Level 3 – User Defined FEM

Level 3 brings the full power of the finite element method to solve complicated and/or important soil-structure systems that are outside the scope of Level 2. In this case the finite element mesh topology must be devised and input by the user. CANDE-2007 has many helpful techniques to expedite the generation of finite element meshes, however, they require some learning on the part of the user.

Whether using Level 2 or Level 3, CANDE-2007 offers the user many features that are especially useful for realistically modeling soil-structure problems. Some key features are listed below:

- Incremental construction – the capability to simulate the physical process of placing and compacting soil layers, one lift at a time, below, along side and above the culvert as the installation is constructed.
- Interface elements – the ability to simulate the frictional sliding, separation and re-bonding of two bodies originally in contact. Typically these elements are used between the culvert and soil and between trench soil and in situ soil.
- Soil elements and models – soil elements are high-order continuum elements with a suite of soil models ranging from linear elastic to highly nonlinear. The so-called Duncan and Duncan/Selig soil models are very representative of the nonlinear soil behavior in most culvert installations.
- Large deformation and buckling – an updated Lagrange formulation that has the ability to accurately track culvert deformations up to and beyond its buckling capacity.
- Pipe elements and models – beam-column elements that may be used to model culvert structures and other structures such support braces. Special nonlinear material models are available for corrugated metal, reinforced concrete and thermoplastic.

2.5 Pipe groups and pipe types

A single “pipe group” is defined as a connected series of beam-column elements that are identified with only one pipe-type name; aluminum, basic, concrete, plastic, or steel. For example, all the “canned meshes” in Level 2 are composed of a single pipe group whose beam-column elements trace a continuous path around the culvert’s periphery through the wall centroid that defines the overall structural shape. Selection of the pipe-type name along with the associated wall-section and material properties completes the information required to compute the initial structural stiffness of the overall culvert.

The top-level choice for the “number of pipe groups” is only available for Level 3, because Level 1 and Level 2 are predefined configurations with only one pipe group. With the ability to choose up to 30 pipe groups, Level 3 provides the user with a great deal of modeling power. For example, two groups may be assigned independent node numbers (no nodes in common) so that they represent independent structures.

Alternatively, element groups may be arbitrarily joined together at common nodes to model cell-like structures or composite structures such as a corrugated metal arch roof placed on a reinforced concrete U-shaped base. Indeed the multi-group option provides virtually unlimited modeling capabilities to define any configuration within CANDE's two-dimensional framework.

Each pipe-type name is associated with a corresponding pipe-type subroutine, which form the heart of CANDE-2007 architecture. All pipe-type subroutines perform three main functions:

- (1) Process input data along with stored data to generate initial pipe stiffness.
- (2) Modify pipe element stiffness properties during nonlinear iterations.
- (3) Evaluate the pipe's design criteria at the end of each converged load step.

In the design mode there is a 4th function, which is to resize the pipe wall properties after each trial design repetition until the design criteria are satisfied. The assumptions behind these four functions are noted for each pipe-type name in the following paragraphs wherein default material properties built in to CANDE-2007 relieve the user of defining most input data.

2.5.1 Corrugated aluminum

Wall properties of corrugated aluminum are characterized by cross-sectional area, moment of inertia and section modulus, which represent the geometry of the corrugation's waveform per unit length. The aluminum pipe-type subroutine has built-in tables for commercially available corrugation sizes as well as realistic default values for all linear and nonlinear material properties. Aluminum's material behavior is simulated with a bilinear stress-strain model with an initial elastic response up to yield stress followed a hardening plastic response, identical in tension and compression. All unloading is assumed linear elastic.

Design criteria for corrugated aluminum include strength limits for thrust stress against material yielding in hoop compression, global buckling and seam strength rupture. A new strength criterion is a limit on the amount of plastic penetration through the cross section. Here a recommended default value of 85% penetration is considered tantamount to failure. Finally, a performance limit on the allowable deflection, typically taken as 5% of the total rise, completes the set of design criteria.

2.5.2 Reinforced concrete

Wall sections for reinforced concrete culverts are defined by the concrete wall thickness with up to two rows of reinforcing steel, typically placed near the inner and outer surface with specified cover depths. In tension, concrete behavior is characterized by cracking when tension stress levels exceed the tensile strain limit. When this occurs the pre-existing tensile stresses are redistributed to the uncracked section, and the cracked location is assumed not to heal for any subsequent tensile loading. In compression, concrete is simulated with a tri-linear stress-strain curve. Initially, the concrete response is linear up to a specified strain level after which the concrete exhibits plastic-hardening behavior. When the compressive stress reaches the ultimate strength limit (f_c'), the stress-strain response becomes perfectly plastic with no increase in stress as compressive strain increases. Reinforcing steel behavior is characterized by an elastic-plastic stress-strain model, which becomes perfectly plastic when the steel yield stress is reached in tension or compression.

Design criteria for reinforced concrete culverts include strength limits for yielding of steel reinforcement, crushing of concrete in compression, diagonal cracking due to shear failure, and radial cracking due to curved tension steel (also called bowstringing). Finally, a performance limit on the allowable flexure crack width, typically taken as 0.01 inches, completes the set of design criteria.

2.5.3 Thermoplastic pipe

CANDE-2007 provides three options to characterize the wall sections for thermoplastic pipe; smooth, profile or general. Smooth refers to a uniform wall (gun barrel) whose cross-section properties are

completely defined by the wall thickness. Profile refers to the majority of manufactured plastic pipe whose wall section properties may be characterized by the geometry of sub-elements such as web, valley, crest, liner and links. General refers to an arbitrary properties described generically by the wall's area and moment of inertia per unit length.

Material properties are assumed linear elastic with default values provided for high-density polyethylene, polyvinyl chloride and polypropylene for both short-term and long-term loading conditions. A nonlinear local buckling algorithm is provided for the profile option wherein the profile's section properties are reduced in proportion to the amount of compressive strain computed in the sub elements.

Design criteria for thermoplastic pipes include strength limits for thrust stress against material yielding in hoop compression and global buckling. Another strength state is a limit on the maximum outer fiber combined strain (hoop plus bending strain). Performance limit states include allowable vertical deflection and maximum allowable tensile strain, dependent on type of plastic.

2.5.4 Corrugated steel

Like corrugated aluminum, the wall properties of corrugated steel are characterized by cross-sectional area, moment of inertia and section modulus, which represent the geometry of the corrugation's waveform per unit length. The steel pipe-type subroutine has built-in tables for commercially available corrugation sizes as well as realistic default values for all linear and nonlinear material properties. Steel's material behavior is simulated with a bilinear stress-strain model with an initial elastic response up to yield stress followed a hardening plastic response, identical in tension and compression. All unloading is assumed linear elastic.

Design criteria for corrugated steel include strength limits for thrust stress against material yielding in hoop compression, global buckling and seam strength rupture. A new strength criterion is a limit on the amount of plastic penetration through the cross section. Here a recommended default value of 90% penetration is considered tantamount to failure. Finally, a performance limit on the allowable deflection, typically taken as 5% of the total rise, completes the set of design criteria.

2.5.5 Basic pipe type

The so-called "basic" pipe-type is not associated with any particular wall geometry or material. Therefore, it is not associated with any design criteria and is only applicable to the analysis execution mode. Further, the basic pipe-type model is limited to linear elastic properties.

One unique feature of the basic pipe type is that each individual beam-column element in the 'basic pipe-type group' may be assigned individual section properties and material properties. Perhaps, the most useful function of the basic pipe type is in Level 3 applications to serve as special structural components in addition to the culvert structures such as struts or temporary bracing.

Lastly, if it is desired to use CANDE's continuum and/or interface elements without any pipe-type elements in the mesh, then the user should declare one group of basic pipe-type elements with zero elements in the group.

2.6 System Choices

CANDE offers a suite of soil models to choose from including the popular hyperbolic forms of Duncan, Duncan and Selig, and Hardin as well as the standard linear forms for isotropic elastic, orthotropic elastic, and overburden dependent. Predefined model parameters are installed in the program for simulating crushed rock, sands, silts and clays under a range of compaction conditions.

Another system choice is the interface condition between the soil and culvert. The user may select a bonded interface or a friction interface that permits frictional sliding and separation during the loading schedule. Interface elements may also be used between the backfill soil and in situ soil wall for trench installations.

Still another system choice is the option to include large deformation analysis. This is particularly useful for investigating large, flexible culverts under heavy loading. Associated with the large deformation analysis is the capability to predict the global buckling capacity the soil-structure system, which provides a direct factor of safety against collapse.

In summary, this chapter has provided an overview of the capabilities in CANDE-2007 and how the various modeling choices can be used to solve difficult soil-structure problems. For more technical depth, the reader is referred to the companion document, *CANDE-2007 Solution Methods and Formulations*. Likewise for more detailed applications, the reader is referred to another companion document, *CANDE-2007 Tutorial and Applications Manual*.

(This page intentionally left blank)

3 Getting Started

This chapter is focused on retrieving the CANDE 2007 executable files from a CD or from an internet-download or from some other source and making sure that the program is operative on your stand-alone personal computer (PC) computer.

3.1 System requirements

CANDE 2007 was developed using Microsoft Visual Studio 2005 along with Intel FORTRAN 9.1 compiler. CANDE has been tested and may be installed on a personal computer with the following:

- Microsoft Windows XP, service pack 2 or later.
- Microsoft Windows NET Framework 2.0.


3.2 Installation guide

CANDE-2007 is contained in file folder that is transmitted to your computer from one of several sources such as a CD disk, Internet download, a zip-folder, or perhaps emailed to you from a colleague. The installation is similar to any Windows program setup. Double-clicking on the 'setup.exe' program delivered with the CANDE installation will initiate the CANDE installation program. Follow the screen by screen instructions to complete the installation.


3.3 Launching and running CANDE-2007

The CANDE-2007 executable is available through the Windows->Programs menu under 'CANDE-2007' (see below). You may also want to create a shortcut for CANDE and place it on your Windows Desktop.

Figure 3.3-1 – Starting CANDE



After launching CANDE, the CANDE-2007 logo and disclaimer will appear on the screen for about two seconds. Next, the CANDE-2007 GUI menu and toolbar will appear as shown below.

Figure 3.3-2 - CANDE-2007 Startup Window

Once CANDE-2007 is started, the user has the options as shown in the following table to create a new CANDE input file or to open an existing file. These options are available through the “File” menu; subsequent chapters discuss all the toolbar options for complete input and output control.

Table 3.3-1 – File-tab menu options for input data files

Dropdown ‘File’ Menu Choices:	Description of File-tab menu option
1. New	Develop a new input data file using the GUI input Wizard*
2. Open Text Input	Recall and/or edit an existing input data file without GUI input menu*
3. Open	Recall and/or edit an existing input data file with GUI input menu. *

*All input files are created with the “cid” extension for example, Cande_input #1.cid

3.3.1 Locate and save example input problem

From the File menu click “Open Text Input” or “Open” to access all potential input data files that have a “cid” extension. A file browser will open to search and select an input file for the purposes of getting started, look inside the CANDE-2007 file folder for a folder with a name like “CANDEInputFiles” and click on the any input example listed in the folder. Again using the File pull-down menu, use the “Save As” option to save the example input data file to a work folder in another location on your computer.

If you cannot find nor have access to an example input problem, copy the simple Level-1 input problem listed in Figure 3.3-3 below. Copy it to a new NotePad document (or other text editor). Save the input data file using a cid extension, (e.g. “Simple_input_example.cid”).

Figure 3.3-3 – Sample Level 1 CANDE input file


```

DESIGN    1 1 1  Level 1 Steel Design LRFD
STEEL
  0.
  0.
  0.
    60.0      120.0
    30.0      1000.0      0.35
    1      1      1.95
STOP

```


3.3.2 Test run an existing example problem

From the File menu click “Open Text Input” or “Open” and use the browser to locate the data file to be executed (see Figure 3.3-4).

Figure 3.3-4 – Opening a CANDE input file


Click on the input data file and it will appear on a screen below the CANDE-2007 toolbar (see Figure 3.3-5)

Figure 3.3-5 – CANDE input file after open



Lastly, click the “Run – CANDE-2007” tab on the toolbar. The CANDE GUI screen will disappear and an echo of the CANDE analysis engine will appear providing a top-level summary of the problem input, a log of the solution as it progresses through the load steps, and finally a message “NORMAL EXIT FROM CANDE”. This last message means the problem ran successfully and that CANDE-2007 is successfully working on your computer (see Figure 3.3-6).

Figure 3.3-6 – Successful completion of CANDE analysis



In summary, the steps to run an existing example problem:


- Launch CANDE-2007 through the ‘Start->All Programs->CANDE-2007’ menu
- Click “Open Text Input” or “Open” from File Menu
- Use file browser to locate existing input file (“cid” extension)
- Click “Run -- CANDE-2007” on toolbar
- Observe message “Normal Exit from CANDE”
- Click View tab to see data and plots of output .

Chapter 4 describes the all GUI input and output options and Chapter 5 provides detailed input instructions. As a preview to the output options discussed in Chapter 4, click on the “View” tab and look at the CANDE Output Report. For the input file listed above, the output report gives the design results and evaluation of a 60-inch corrugated steel pipe buried under 30 feet of fill soil.

3.3.3 Example problems and tutorial

The CANDE documentation includes a stand-alone tutorial manual containing many example problems. The tutorial defines each problem to be solved followed by a step-by-step illustration of using the GUI to develop the input and view output. It is highly recommended that the user examine the tutorial prior to undertaking the development of a new input data file. The tutorial can be accessed from the Help tab on the CANDE-2007 tool bar (see Figure 3.3-7).

Figure 3.3-7 – Accessing the CANDE tutorials




4 Graphical user interface (GUI)

4.1 Overview

CANDE-2007 provides a graphical user interface (GUI) that provides features to ease the task of creating CANDE input documents and also to view the CANDE output results graphically. This chapter provides a discussion of GUI input options, directions for running CANDE-2007, and viewing the output reports, plots and graphs. To make use of the directions in this chapter, the user must launch the CANDE-2007 program through the ‘Start->All Programs->CANDE-2007’ folder. CANDE’s main interface is a multi-document interface (MDI). This means that multiple CANDE documents can be opened at one time. The only exception to this rule is that only one CANDE input file may be opened at a time (see Figure 4.1-1). CANDE uses the input file prefix as an indicator to open other CANDE view windows:

Figure 4.1-1 – CANDE GUI overview



4.2 Input Options

The key concept behind the GUI input option is that it ultimately creates a CANDE-2007 input data file that contains the same formatted data stream as that of the traditional batch-mode input. The traditional batch-mode method of input requires the user to hand type data files in accordance with the written input instructions in the detailed user manual, Chapter 5. In contrast, the GUI is much easier to follow because each input step is “tailor-made” to conform to the user’s previous input choices. Said another way, the user does not need to navigate through the entire user manual, just follow the screen input instructions. However, the traditional batch-mode is still an optional input method discussed at the end of this section.


The GUI has options to create new data input files, edit and rerun existing data files, and import data files from external sources. Each of these options is discussed in turn.

4.2.1 Creating a new CANDE input data file – CANDE Input Wizard

The creation of a new input data file using the GUI is a seamless, two-step process. The first step employs the so-called Input Wizard to define the top-level choices of the soil-structure problem to be solved, and the second step employs the so-called CANDE Input Menu to define the values system parameters.

This subsection describes the Input Wizard, which generates the major control data and establishes a unique input menu for the data to be supplied in step 2. The CANDE Input Wizard is accessed when a new CANDE project is created. This is done by selecting the ‘New’ option from the CANDE ‘File’ menu as shown below.

Figure 4.2-1 - Creating a new CANDE input document



Selecting ‘New’ will activate the first Input Wizard screen called Control Information as shown in below. Using two or three additional screens with key input choices, the wizard will generate a CANDE input menu that will then be completed by the user in step 2.

Figure 4.2-2 – CANDE Input Wizard startup screen

Note that the selections made on this menu screen and subsequent wizard menus will enable or disable items on the menu. If an item is disabled, it is not a valid option based on your current input selections.

After completing the information on the CANDE Input Wizard-Control Information menu, click on the 'Next >>' button to advance to the next wizard input screen. You can return to this screen later by clicking on the '<<Prev' button. For solution level 3 problems, a screen specific to level 3 problems is required to define the parameters for the finite element mesh. (See Figure 4.2-3 below).

Figure 4.2-3 – CANDE Input Wizard Level 3 Information

For the level 3 information, two options are available; ‘Manual Input’, and ‘Import Mesh file’. In general ‘Manual Input’ is used if the user will manually define all of the nodes and elements into CANDE or by using the inherent Mesh generation capabilities built into the CANDE analysis engine (see Level 3 in chapter 5 on CANDE Input for more information on CANDE’s built-in mesh generation capabilities).

For the format of the imported input files, see the Appendix.


For all solutions levels (1, 2 and 3), the next Wizard input screen is the ‘Pipe Material’ screen as shown below

Figure 4.2-4- CANDE Input Wizard: Pipe Material screen

Again, selection items on the screen are enabled or disabled based on the applicability that is determined from this screen and previous input. Also note that for Level 3, this screen is repeated based on the number of pipe materials input on the ‘Control Information’ screen. For more detailed information see the section ‘CANDE Input Wizard – Pipe Material’.


Once completed with all of the input screens, the final CANDE Input Wizard Menu will be as shown below:

Figure 4.2-5 – CANDE Input Wizard Final Screen



Click on the 'Finish' button and you will be prompted to save your input file (see below).

Figure 4.2-6 – Saving a CANDE input file




CANDE provides a default name for the file based on some user input values, but the name can be changed at this time. Two things of importance:


- **The extension of the file must be '.cid'.**
- CANDE will prompt you if the name of the file selected already exists.

Once a new file is created, the CANDE interface will look similar to the figure shown below:

Figure 4.2-7 – CANDE Interface after new CANDE input document is created



Note the red 'X' items on the left side. In general, these CANDE input screens contain 'undefined' input information. This input is required but does not have a CANDE default value supplied. All of these menus must be resolved before CANDE will permit the running of the CANDE analysis engine. A sample of a menu with 'undefined' input is shown below.

Figure 4.2-8 - CANDE menu with ‘undefined’ input

In addition to the undefined input, the user must decide what of the default input is acceptable. The CANDE input menu system guides the user in which input to choose and the CANDE analysis engine provides a degree of error checking, but the user should be thoroughly familiar with the input as described in the ‘Detailed CANDE Input’ section of this manual. As with all engineering programs, the responsibility for proper input and proper interpretation of the results lies with the user.

The details of the CANDE Input Menus are discussed in subsequent sections.

4.2.1.1 CANDE Input Wizard- Control Information

The Control Information of the CANDE input wizard provides key information related to the entire CANDE model. The follow is a description of the items provided on this dialog box:

Parameter	Input options	Description
Type of Analysis (XMODE)	'Analysis' or 'Design'	Specifying the variable XMODE controls the decision of design or analysis. Analysis implies all system and pipe properties are known and the objective is to evaluate pipe performance. Design means the pipe wall section properties are unknown, and that they will be determined in an iterative analysis process.
Method of analysis/design	(0, service, = 1, LRFD)	Choice of Working Stress (service) or Load Resistance Factor Design (LRFD) methodology for analysis and design. Working Stress uses actual loading conditions, where as LRFD increases the actual load with specified load factors.
Solution Level	= 1, Elasticity = 2, FEM with canned mesh = 3, FEM with user mesh	<p>Level 2 is considered the workhorse of CANDE and provides a finite element solution methodology using an internally developed mesh based on a few physical parameters specified by the user in part C. Canned meshes are available for round, elliptical, box and arch-shaped culverts. Loading includes live loads as well as incremental layers of soil. Level 2's major limitation is the assumption of symmetry about the vertical centerline of a specified pipe type.</p> <p>Level 3 provides the full power of the finite element method to characterize any soil-structure system. This includes multiple structural shapes and/or multiple structural materials (pipe types).</p> <p>Level 3 requires that the user develop the finite element mesh including element connectivity arrays, coordinates and boundary conditions. Although CANDE has many helpful mesh generation features, use of Level 3 requires some familiarity with the finite element method for proper modeling of the soil-structure system.</p>
Use the auto-generate option for the interface elements	Check 'ON' or 'OFF'	If this input is checked 'ON', CANDE will assume that the user is going to take advantage of the 'Short-cut' method for entering input 'D-2.Interface Elements'. The input wizard will generate a beginning and ending set of D-1/D-2 commands to define the interface elements.

Parameter	Input options	Description
Number of pipe element groups (level 3 only)	= number of groups (Maximum = 30)	For Level 1 and 2 the number of pipe groups is inherently defined = 1. For level 3, however, more than one pipe group may be specified if it is desired to model more than one pipe material or more than one sequence of connected pipe elements. Specifically, a pipe group is defined by a pipe material type (STEEL for example) <u>and</u> the number of pipe elements in that group (1 or more). The pipe elements in any group must be connected in an ordered sequence head-to-toe tracing a curvilinear path representing the mid depth of the structural segment. Pipe groups (or structural segments) may be connected to one another in any fashion or be disconnected. For example, one pipe group could represent a concrete box culvert and another group could represent an arch-shaped steel culvert that is not directly connected because they share no nodes in common. Or, two concrete culvert groups could represent the left and right footings connected to a group representing an arch-shaped steel culvert.
Heading for output	text up to 60 characters long	This text will be placed in the heading of the CANDE output file.
<u>LEVEL 2 Specific</u>		The following input is only applicable for the Level 2 type Solution Level.

Parameter	Input options	Description
Canned Mesh Type (NPCAN)	Pipe mesh Box mesh Arch mesh	<p>Under level 2, NPCAN allows the user to select the type of canned mesh to be used in this problem.</p> <p>For level 1 the NPCAN variable is not used, and for level 3 this variable is renamed NPMATX and defined differently as discussed subsequently.</p> <p>The “Pipe mesh” creates a circular or elliptical culvert cross-section assuming vertical centerline symmetry. Options for trench and embankment installations, interface elements, and incremental construction. (a.k.a CAN1 mesh)</p> <p>The “Box mesh” creates a rectangular, closed-cell culvert cross-section assuming vertical centerline symmetry. Options for trench and embankment installations, bedding depth and incremental construction. (a.k.a. CANBOX mesh)</p> <p>The “Arch mesh” creates a two or three segment arch resting on footings assuming vertical centerline symmetry. Options for trench and embankment installations with built-in interface elements. (a.k.a. CANAR1 mesh)</p>
Soil Mesh Pattern	Embankment Trench Homogeneous	<p>The values available are dependent on the ‘Canned Mesh Type (NPCAN)’ entered:</p> <p>Pipe – (Embankment, Trench, Homogeneous) Box – (Embankment, Trench) Arch – (Embankment, Trench, Homogeneous)</p>
Interface Elements	(for pipes only) Pipe-soil (SLIP) Trench-insitu (SLPT) None	<p>WORD1 provides options for including frictional interfaces between pipe and soil or between trench soil and in-situ soil. Default (blank) means no interface elements are added.</p> <p>For WORD1 = SLIP, the mesh is automatically altered to include eleven interface elements at the common nodes between the pipe and soil. This feature allows for frictional slippage, separation and re-bonding of the pipe-soil interface during the loading schedule. The user must subsequently input interface material properties for each of the eleven interface elements as described in Part D.</p> <p>For WORD = SLPT, the trench mesh option is automatically altered to include seven interface elements at the common nodes between the</p>

Parameter	Input options	Description
		trench wall and in-situ soil starting from the spring line to the top of the trench. This feature allows the trench soil to slip along the vertical during the backfilling loading schedule. The user must subsequently input interface material properties for each of the eleven interface elements as described in Part D
MOD-Make changes to the basic mesh	Checked if the user is going to change the basic Level 2 mesh.	<p>If this item is checked, the user may change the basic mesh in terms of nodal locations, element properties and prescribed loads. This is accomplished by supplying additional data in lines CX-1 through CX-4 after the basic C-1 through C-4 data is complete.</p> <p>Motivations for changing the basic mesh include: add a live load(s), simulate voids or rocks in the soil system, and to change shapes such as the bedding. The default case (no modifications) applies to many basic problems without the need for modifications.</p>

4.2.1.2 CANDE Input Wizard – Level 3 items

This menu of the input wizard defines information related specifically to level 3 models.

Parameter	Input options	Description
Select level 3 input option	Manual input Import mesh file	Two options are available in the Input Wizard for generating level 3 input documents. The manual input method requires that the user provide general level 3 information (i.e. number of nodes, number of elements, etc.). After the generation of the input file, the user will manually enter the coordinates, element connectivity, etc. in the blank input cells. The Import mesh file option, permits the input of a mesh file that has been created using the CANDE Mesh geometry XML format (see appendix section on XML Mesh Geometry).
Select the mesh import file	Click on the button with the (...). File name expected is *MeshGeom.xml. or a NASTRAN or CANDE-89 P1 file	CANDE has three options for importing: <u>CANDE-MeshGeom.xml</u> The file may have been generated by a previous CANDE run (for a Level 2 model that is now being imported as a level 3 model), or may have been generated externally. For the proper format of the Mesh Geometry file (see section in Appendix on XML Mesh Geometry format) <u>NASTRAN</u> – Limited NASTRAN input file import (see below and Appendix for more details). <u>CANDE-89 P1</u> – This permits the import of P1 plot files generated by previous versions of CANDE.
<u>Level 3 options</u>		The following only apply for the 'Manual Input' option. They are filled in automatically for the 'Import mesh file' option.
Number of nodes		Input the number of nodes for this model. The nodal geometry will be entered once the input document is generated.
Number of elements		Input the number of elements for this model. The element connectivity will be entered once the input document is generated.
Number of boundary conditions		Input the number of boundary conditions. The details of the boundary conditions will be entered once the input document is generated.
Number of load steps		Input the number of load steps for this model.
Number of soil materials		Enter the total number of soil materials for the model.
Number of interface elements.		Enter the number of interface elements for this model. If no interface elements, enter zero ('0').


CANDE Import options

CANDE has the capability to import meshes for the following three formats:

- CANDE XML Mesh files (see)
- CANDE-89 Plot files
- NASTRAN

When the user clicks on the 'Import File' button in the 'Level 3 Information' window of the CANDE Input Wizard', an import dialog box appears as shown in Figure 4.2-9.


Figure 4.2-9 – CANDE import dialog box



The user clicks on the file format and then the 'Import' button. Once the import has concluded, the OK button will be enabled. Clicking 'OK' finishes the import and returns the user to the CANDE Input Wizard.

When importing NASTRAN or CANDE-89 files, a log file window will appear to display the progress of the import as shown in Figure 4.2-10. Once the import is completed, the import log file can be reviewed by clicking on the 'Review Import Log' button. The log file will display any problems that CANDE had while performing the import.

Figure 4.2-10 – Import log window



The formats for the available CANDE import files are in the following sections:

- CANDE Mesh XML (see Appendix section XML Mesh Geometry Format)
- CANDE-89 Plot File (see Appendix section CANDE-2007 output files for plotting)
- NASTRAN File (see Appendix section CANDE NASTRAN Import Format)

4.2.1.3 CANDE Input Wizard – Pipe Material

This menu defines the pipe materials for this model. For levels 1 and 2, only one pipe material is permitted.

NOTE: For Level 3, this menu is repeated for the number of pipe element groups entered on the 'Control Information' screen

Parameter	Input options	Description
Pipe material type (PTYPE)	Aluminum Basic Concrete Plastic Steel	<p>Choosing PTYPE means the selection of the pipe material to be analyzed or designed. For level 1 or 2 only one pipe type can be selected per problem.</p> <p>For level 3 the user will select a PTYPE for each pipe group (NPGRPS times). Input for each PTYPE consists of Line A-2 followed by the set of lines in Part B, which defines the pipe-type properties.</p> <p>Corrugated aluminum cross-section with material options for elastic-plastic behavior.</p> <p>General cross-sectional properties with elastic material.</p> <p>Reinforced concrete smooth wall section with nonlinear material models for concrete and rebar.</p> <p>Smooth wall plastic pipe with linear material properties. (To be upgraded to profile wall with local buckling)</p> <p>Corrugated steel cross-section with elastic-plastic material behavior. Also has option for slotted joint behavior.</p>
Number of connected beam elements	Number of connected beam elements in this group, for level 3 only. Maximum = 999	<p>The number (quantity) of beam elements in any group may range from 1 to 999. It is to be understood that elements in any group form a continuous sequence, connected head to toe tracing the centerline path of the structure or a segment of the structure.</p> <p>The group number identifier, 1 to NPGRPS, is automatically assigned in the sequential order of input. That is, the first data set (Line A2 plus set B) becomes group # 1, the second data set becomes group # 2, and so on until all NPGRPS groups are input.</p> <p>The linkage between the group numbers established here and the finite element mesh established in input set C is by means of the element's material identification number called IX(5). In data set C, the user must assign the appropriate group number to each beam element's material identification number.</p>
<u>Concrete specific input</u>		The following input only applies for concrete pipe materials.


Parameter	Input options	Description
Reinforcement shape (RSHAPE)	Standard Elliptical Arbitrary Boxes	<p>RSHAPE allows selection of how the reinforcement will be shaped and placed relative to the concrete inner and outer wall surfaces.</p> <p>Standard placement for two rows of reinforcement cages, which parallel the inner and outer wall surfaces. The concrete wall thickness is uniform and concrete cover-depths and properties are uniform in each individual cage. (Applicable to levels 1, 2, or 3; and design or analysis)</p> <p>Elliptical placement of a single reinforcement cage sometimes used in circular pipe. The cage starts at a specified cover-depth from the outer wall surface of the crown, transitions to the inner wall surface at the spring line, and transitions back to the outer wall at the invert. (Applicable to levels 1, 2, or 3; and design or analysis)</p> <p>Arbitrary placement of two rows of reinforcement. The concrete wall thickness, the reinforcements' concrete cover-depth, and reinforcement steel areas may be specified at each node along the pipe-group path. (Applicable to levels 2 or 3 for analysis only)</p> <p>Boxes - Special placement of two rows of reinforcement conforming to ASTM box culvert specifications. (Intended to be used in conjunction with level 2 – Box mesh for analysis only)</p>
<u>Plastic specific input</u>		The following input only applies for plastic pipe materials.
Wall section type	Smooth (design and analysis) General (analysis only) Profile (analysis only)	<p>SMOOTH refers to uniform smooth wall (gun barrel) whose only independent cross section property is the wall thickness. Applies to design & analysis.</p> <p>GENERAL refers to arbitrary cross-section properties for area and moment of inertia without local buckling consideration. Applies only to analysis.</p> <p>PROFILE refers to a spectrum of profile shapes such as corrugated with or without liners, ribbed walls, etc. Profile shapes require additional geometry input and include local buckling analysis. Applies only to analysis.</p>
<u>Steel specific input</u>		The following input only applies for steel pipe materials.
Joint slip	No Yes Yes, show trace	This option allows the representation of slipping joint behavior like the so-called “key-hole slot”, wherein joint slippage is intended to reduce thrust stress. Further input is required.

Parameter	Input options	Description
Vary joint travel length	Same lengths Different lengths	This option applies to solution levels 2 & 3. One main utility of this option is to model “half joints”. This occurs in level 2 meshes when the axis of symmetry cuts through a joint at the crown or invert, which produces a half-joint with the same properties as a full joint except the slot length, is one-half its full value.
Number of joints	Enter the number of joints if ‘Joint Slip’ has been entered as ‘Yes’ (Maximum =15)	This is the actual number of joints (longitudinal seams) in the pipe-group model. The model for Level 1 is the whole circular pipe, whereas Level 2 is modeled using a symmetric half shape.

4.2.2 Opening an Existing CANDE Input Document with File->Open

Existing CANDE input documents may be opened using the File→Open menu (see below).

Figure 4.2-11 – Opening an existing CANDE input document



CANDE input files must have a .CID extension. CANDE uses the prefix to name all other files in a CANDE project. For example, the CANDE input file title 'EX1.cid' will produce the following CANDE files when the analysis is run:


EX1.ctc	CANDE output table of contents.
EX1.out	CANDE output files
EX1.log	CANDE analysis log file
EX1_BeamResults.xml	Generated by the CANDE analysis run and used for graphic of the beam analysis results.
EX1_MeshGeom.xml	Generated by the CANDE analysis run and used for plotting of the FEM mesh.
EX1_MeshResults.xml	Generated by the CANDE analysis run and used for plotting of the mesh results for the FEM mesh.

For further description of these files and others generated by CANDE, see the Appendix of this User Manual.

4.2.3 Opening an Existing CANDE Input Document with File->Open Text Input

To open an existing CANDE input documents with the CANDE text editor, use the File→Open menu (see below). This option may be used in lieu of the CANDE input menu interface and is generally for users who are very familiar with the CANDE data file input format. A detailed description of the CANDE input text editor is provided in a subsequent section.

Figure 4.2-12 – Opening an existing CANDE input document in the CANDE input text editor




4.2.4 CANDE Input Menus

Once the CANDE input document has been initiated, either by creating a new document using the CANDE Input Wizard or opening an existing document using the 'File->Open' menu, the user will be directed to the CANDE Input Menus. This section describes the CANDE input menus and their various functions.

4.2.4.1 Menu input overview

The following figure provides an overview of the CANDE menu input screen. The function of the CANDE menu input system is to guide the user in the creation of a CANDE input document. To do this, the menu system uses a hierarchal menu to guide the user through the input needed for a specific CANDE model. For guidance on creating a new CANDE input document, see the section 'Creating a new CANDE input data file – CANDE Input Wizard'.

Figure 4.2-13 CANDE input menu overview



4.2.4.2 Viewing help for the input menus


Input help is provided through several methods in the CANDE Input menu system. These consist of combination of tools tips, persistent help display, and context sensitive help. For more information, see one of the following sections:

Persistent help	'Show Help' checkbox
Show Input	'Show Input' checkbox
Range information	Input range violations
Error/Warning messages	Input errors and undefined input
Input tree icons	Menu input tree icons

4.2.4.3 ‘Show Help’ checkbox

Clicking on the ‘Show Help’ checkbox will turn on persistent input help at the bottom of the Menu Input screen. Persistent help can also be turned on/off by clicking on the input description (see Figure 4.2-14 below):


Figure 4.2-14 – Activating CANDE input menu persistent help



4.2.4.4 ‘Show Input’ checkbox

Clicking on the ‘Show Input’ checkbox will turn on CANDE input document display at the bottom of the Menu Input screen (see Figure 4.2-15 below). This input is NOT modifiable through this screen, but provides a view of the input document for those familiar with the format.


Figure 4.2-15 – Activating CANDE input menu ‘Show Input’



4.2.4.5 Input range violations

If a user enters a value below the lower range or above the upper range, the text is turned to red and a warning message is displayed when the user enters that input field as shown in Figure 4.2-16 below.

Figure 4.2-16 – CANDE input menus range violation




While the user is warned of range violations, CANDE will permit the user to run the analysis. For input errors that are not range violations, CANDE will NOT permit running the analysis.

4.2.4.6 Input errors and undefined input

In addition to checking upper and lower limit ranges, the CANDE menu input system will check for input typos and for new input documents will highlight 'undefined' input that must be provided before a CANDE analysis may be run. A sample of an input typo is shown in Figure 4.2-17 where a character is entered where a numeric is expected.

Figure 4.2-17 – Error in CANDE input menus with an invalid character



For this type of error CANDE will not run until the error is corrected. An error is also provided if user attempts to click on 'Accept Input' without changing the value.


Undefined input

Similar messages are provided when input is marked as undefined ('undef.'). Input is typically marked as undefined for new CANDE input documents or when the input tree changes because of a revised input command (e.g. when the soil model is changed in the Part D commands, new input menus are added to the input tree that contain undefined values). If any item on the input menu is marked as undefined, the menu tree will display a red 'X' for that menu.




The CANDE analysis may not be run until all undefined quantities have been resolved.

4.2.4.7 Menu input tree icons

The CANDE menu input tree provides different icons to display the status of all the menus at a glance. An example is shown below.



The following table provides a summary of the different icon states.

Icon	Description
 - Clear icon	Input for this menu does not contain any errors or 'undefined' values. The user however is responsible for checking the input to ensure that it is correct with respect to the current model being considered.
 - Error icon	The input for this menu contains one or more errors and/or 'undefined' values. All of these values must be resolved before the CANDE analysis may be run.
 - Input Change	One or more input item for this menu has changed. If the user attempts to leave them menu before 'Accept Input' is clicked, a warning message will appear asking the user to save the input.

4.2.5 Changing an existing CANDE input document to create a new data file

Often a user may wish to change one or more parameters in existing data file to investigate the influence of parameter variations on the solution. Rather than creating a new data file from scratch, the GUI offers two simple methods of modifying an existing data file to create new data file.

1. Create a new file by editing an existing data file using the CANDE Input Menu
2. Create a new file by editing an existing data file using text editor

The first method takes full advantage of the GUI but is somewhat restricted in the changes that can be made. The second method is unrestricted in the changes that can be made but requires the user to refer to the detailed input instructions in Chapter 5. These two methods are discussed in the following subsections in turn.

4.2.5.1 Create new CANDE input document from existing document with Input Menu

To use this method, click on the File tab from CANDE tool bar and select “Open”, which will display the file browser. Using the file browser locate the existing input data file that you wish to modify (if you wish to save the original file, you must first make a copy). Clicking on the data file to be modified will show the complete CANDE Input Menu of the original problem.


At this point you are free to scroll through the CANDE Input menu and make any changes you wish in the same way as discussed in step 2 of creating a new data file (section 4.2.2). After you have made the desired changes, save the file, and then proceed to run CANDE.

The down side of this method is that you are only free to change those parameters listed in the menu, which are restricted by the flow path created by Input Wizard in step 1. For example you may change pipes wall properties but not change the pipe type.


4.2.5.2 Create new CANDE input document from existing document with text editor

To use this method, click on the File tab from the CANDE tool bar and select “Open Text file”, which will display the file browser.

Figure 4.2-18 – Opening an existing CANDE input document using the CANDE input text editor



Using the file browser locate the existing input data file that you wish to modify (if you wish to save the original file, you must first make a copy). Clicking on the data file to be modified will show the formatted input file that is directly read by the CANDE program. An example along with a summary of the editor command is shown in Figure 4.2-19 below.

Figure 4.2-19 – Summary of CANDE input text editor

Using the text editor you may change the values and locations of any variable, add lines of input, and/or delete lines of input. Of course the data must conform to the formatted instructions in the detailed CANDE input manual in Chapter 5. In essence you are creating a text-mode input file, but taking advantage of pre-existing data file. Once the file is created it should be saved, prior to running CANDE.

At first glance a GUI generated data file looks different than a standard batch-mode input file because each line of GUI data starts in column 28 rather than column 1. This is because the GUI uses the first 27 columns to “tag” each line of input corresponding to the designation in the user manual as defined in Chapter 5. The advantage of placing the tag in front of the input line is that the editor works as a ‘smart’ editor. That is the tags are used to provide help at the bottom of the screen as the user changes columns in the input file. If a tag is present at the beginning of the line, the help at the bottom of the screen will change as the user moves to a new ‘field’ based on the CANDE input document fixed format described in Chapter 5. This provides the user with interactive guidance regarding which columns or fields to place data. The input tags are also used when running CANDE to perform a consistency check on the input file. If the tags are not placed, CANDE will still run, but will not perform the consistency check.

In order to place the proper command without typos, an ‘Insert command’ button is available in the text editor. To insert a new CANDE input command tag, do the following:

- Go to the beginning of a new line
- Select the appropriate CANDE input command tag from the pull down list (see Figure 4.2-19).
- Click on the ‘Insert Command’ button (see Figure 4.2-19)

For more information on input consistency checks that CANDE makes using the input command tags, see section ‘checking’ of this manual

4.2.6 Create a CANDE input document using the CANDE input text editor

If desired, an input file (CANDE input document) may be developed externally using other software or by hand typing line-by-line the formatted input data as prescribed by the input instructions in Chapter 5. The only prerequisite is that data input files must have a .cid extension along with any prefix name you choose.

After the data file is created and saved, launch the CANDE-2007 program, click on the File tab, and select Open Text Input. Using the file browser locate the CANDE input document to be executed and click on Run CANDE 2007. CANDE uses the name you choose as a prefix to name all other files that are generated as result of running your input file. These generated files will be saved in the same folder as the CANDE input document.

While it is not necessary to use “input command tags” on the input lines like those provided by the GUI, however, providing the input tags provides a level of consistency checking that will not occur if the tags are not present. For a description of why the tags are useful, see ‘CANDE input consistency checking’. Recall that name tags are used by the GUI to identify the input line according to the instruction manual section letter and line number such ‘A-1!!’ for the first input line followed by a double exclamation mark (!!).

4.3 Running CANDE-2007


If the data file to be run is already open such as when creating a new data file, simply click Run CANDE-2007 to execute the program.

To run any existing CANDE input data file, click the File tab and choose:

- “Open” to open data file in CANDE Input Menu format
- Or, “Open Text Input” to open data file as a batch-mode data list.


Using the file browser select the data file to be run. Regardless of how the data file was created, it be opened in either of the above two modes and executed.

Figure 4.3-1 – Running CANDE-2007 analysis



Once started, the CANDE interface will be hidden and the CANDE analysis window will appear (see Figure 4.3-2 below). No other operations in CANDE can be performed while the analysis is running.

Figure 4.3-2 – View of CANDE Analysis while running



When the analysis is completed, the ‘Close’ button will be activated. Click the ‘Close’ to return to the CANDE interface. NOTE: The information that CANDE prints to the screen is available back in the CANDE interface by selecting the ‘View->CANDE Log File’ option from the menu.

4.3.1 Successful execution

The successful execution of any CANDE run is observed by the appearance of the last output line on the monitor screen and the CANDE Log File, saying:

```
**** NORMAL EXIT FROM CANDE ****
```

This message means that all the input data has been read without input errors and that all the specified load steps have been processed without execution errors. However, it does not guarantee the input data is correctly defined; only the user can make this determination by reviewing the CANDE output report.

Moreover when nonlinear models are included the problem, the above message does not imply that every load step converged within acceptable limits. When any load step does not converge a separate message is printed on the monitor screen and in the CANDE Log File identifying the load step number that did not converge along with the iteration limit.

4.3.2 Unsuccessful execution

An unsuccessful execution of any CANDE run is observed when the program stops prior to completion *without* the “normal exit from CANDE” message. When this occurs diagnostic messages are printed on the screen and saved in the CANDE Log File as well as printed in the CANDE Output Report.

The most common error is a data input error. In many cases CANDE will detect these errors with internal programming that checks the data makes physical sense. In such cases, the printed diagnostics will state the nature of the error and the suspected input line number where the error occurred along with an error number. Typically the user will be able to discover the cause of the error based on the diagnostic information and then make the necessary corrections.

A second type error is the so-called execution error, the cause of which can be more difficult to determine. As opposed to a message from CANDE, this type error is identified by a system error message such as exceeding the dimension of a particular variable, division by zero and other similar system error messages. Very often these types of errors can be traced back to incorrect input data as opposed to a bug in the CANDE program. In such cases the user should carefully review the input data as listed in the CANDE Output Report, not the input data file. The CANDE Output Report lists all the input data as interpreted and/or generated by CANDE in an easy to understand format. As a last resort the user may contact the CANDE program developers to help determine the source of the error.

4.3.3 CANDE input consistency checking

CANDE input documents that are generated by the input menus contain input tags at the beginning of each input line. These tags serve several purposes:

- They provide a quick description of the input line if a user is reviewing a CANDE input document in a text editor.
- In the CANDE input text editor, they facilitate the use of the ‘smart’ help used by the CANDE text editor by providing help as the user moves to a new input column.
- When the CANDE analysis engine is running, a consistency check is performed as the input document is read that checks the ‘expected’ input line and compares it with the ‘actual’ input line. If the two don’t match, a warning is provided to the user. CANDE will continue to read the input file, but messages will be provided to guide the user if an input line is missing or out of place.

This consistency check can be particularly useful if the user is generating a CANDE input file by using the CANDE input text editor rather than using the Input Menus. The menus automatically generate the input document, but using the text editor, the user is in charge of the input document creation. Using the input tags provides the user with an additional level of checking. An example of an input file consistency check error and an input check message is shown below.

The following is a snippet of a valid CANDE input document.

```

      A-1!!DESIGN    2 0  1New Input file
      A-2.L12!!ALUMINUM  1
      B-1.Alum!!  10000000      0.33      24000      0
      B-2.Alum.D.WSD!!      3      2      2      4      5
      C-1.L2.Pipe!!TREN New Level 2 Pipe Mesh
      C-2.L2.Pipe!!      61      1      28.75      120

```

If the B-2.Alum.D.WSD line was omitted (or accidentally deleted) as shown below,

```

      A-1!!DESIGN    2 0  1New Input file
      A-2.L12!!ALUMINUM  1
      B-1.Alum!!  10000000      0.33      24000      0
      C-1.L2.Pipe!!TREN New Level 2 Pipe Mesh
      C-2.L2.Pipe!!      61      1      28.75      120

```

The following error would occur and appear in the log file and the screen output while running the CANDE analysis:

WARNING- at Line 4 of the input file

```

      Expecting input line of type "B-2.Alum.D.WSD"
      but read from the input file an input type of "C-1.L2.Pipe"

```

Check your input file.

Other error messages will likely occur as CANDE continues to read the input file, but this message will point the user to spot where the input document starts to diverge.

4.3.4 Convergence and Nonconvergence of load steps

CANDE employs a variety of nonlinear models that are used to simulate real-world behavior such as nonlinear behavior of various pipe materials, soil material behavior, frictional interfaces and large deformations. If one or more of these nonlinear models are activated in any input data file, CANDE repeats (iterates) the solution within each load step until two successive solutions yield the same answers within a small tolerance of error. This means the solution has converged for the current load step and the solution is reliable. The solution output data is recorded in the CANDE Output File.

On the other hand, if two successive solutions do not converge after a user-specified number iterations are attempted (default ITMAX = 30), CANDE will stop execution with a screen message saying that the solution did not converge for the current load step. Further diagnostics are printed in the CANDE Output Report wherein the particular nonlinear model(s) that did not converge are identified along with the maximum percentage of error between the last two successive solutions.

It is important to note that the occurrence of nonconvergence does not necessarily mean there is an error on the part of the user or the CANDE algorithm. Rather, nonconvergence is often expected to occur when the nonlinear models are loaded to the point that they loose stiffness so that the structural system or portion of the structural system cannot sustain further loading. Said another way, the load step at which nonconvergence occurs may, in some cases, be interpreted as the maximum load capacity of the structural system. This interpretation can be checked by plotting structural deflections versus load step and observing increasingly larger movements in a load-deformation plot.

On the other hand, nonconvergence may be problematic, but curable, requiring some investigation on the part of the user. Specifically if nonconvergence occurs, the user should consider the following checklist:

- (1) Review the CANDE Output Report to see which type of nonlinear models did not converge and the relative error in the lack of convergence.
- (2) Examine the input parameters of the nonlinear models that did not converge and make sure that the parameters are correct and reasonable. For example a common input error for interface elements is that they are assigned incorrect interface angles in input line D-2
- (3) Try reducing the load magnitude assigned to each load step. That is, use more load steps to define thinner soil layers for gravity loads and/or smaller force increments for boundary conditions.
- (4) Try increasing the maximum number of iterations, ITMAX on input line A-1. Typically the default value is sufficient, but some cases have required 50 or more iterations to achieve convergence. If convergence has not been obtained in 100 iterations, it is probably fruitless to try more iterations.
- (5) Try reducing the number of different nonlinear models to isolate the problem. For example, turn off the large deformation option, or inactivate the interface elements by assigning large numbers to the friction coefficient and tension strength, or increase the strength parameters on the pipe models.

As a last resort, CANDE offers the option to continue the execution after nonconvergence occurs. This is achieved by specifying the iteration limit as a negative number (e.g., ITMAX = -30). In this case all the load steps are solved and those load steps that did not converge are identified. However, all solutions beyond the load step where nonconvergence first occurred must be viewed with suspicion. In this case the user must exercise engineering judgment to carefully examine the output data and the diagnostics to see if the final solution is meaningful.

4.3.5 CANDE Analysis error messages

The following table provides a summary of the CANDE input errors that may be reported when creating a CANDE input document.

Input Error Number	Text
9001	Input: Aluminum: Some Pipe Section Properties are zero.
9002	Input: Basic: Beam sequence numbers are out of bounds
9003	Input: CAN1: Incorrect command for CAN1 mesh.
9004	Input: CAN1: Number of load steps exceeds maximum.
9005	Input: CAN1: Pipe diameter ratio is beyond limit for CAN1 mesh
9006	Input: CAN1: FATAL-Height of cover must be within allowable limits.
9007	Input: CAN1: Thickness of backpacking is not within allowable limits
9008	Input: CAN1: Trench is too narrow in CAN1 mesh to accommodate backpacking
9009	Input: CAN1: Trench is too narrow in CAN1 mesh.
9010	Input: CAN1: Trench is too wide in CAN1 mesh.
9011	Input: CAN1: Trench is too shallow for CAN1 mesh.
9012	Input: CAN1: Hgt. Trench+Hgt. of cover must be greater than 1.3 * Pipe Diameter.
9013	Input:CANAR1:Incorrect mesh pattern for CANAR1 mesh.
9014	Input:CANAR1:Incorrect "modify" command for CANAR1 mesh
9015	Input:CANAR1: Number of Constuction Increments must be within limits.
9016	Input:CANAR1: Half-span must be a positive number.
9017	Input:CANAR1: Side-Rise must be non-negative.
9018	Input:CANAR1: Radius must be non-negative.
9019	Input:CANAR1: Trench width must be within limits.
9020	Input:CANAR1: Trench depth must be within limits.
9021	Input:CANAR1: Trench slope must be within limits.
9022	Input:CANAR1: Outer footing width must be within limits.
9023	Input:CANAR1: Outer footing width must be within limits.
9024	Input:CANAR1: Inner footing width must be within limits.
9025	Input:CANAR1: Footing depth must be within limits.
9026	Input:CANAR1: Number of "NTN" nodal points must be within limits
9027	Input:CANAR1: Number of "NCN" nodal points must be within limits
9028	Input:CANAR1: Number of "NTN" nodal points must be within limits
9029	Input:CANAR1: Number of "NCN" nodal points must be within limits
9030	Input:CANAR1: Arch geometry is not self consistent.
9031	Input:CANAR1: Arch geometry is not self consistent.
9032	Input:CANBOX:Incorrect mesh pattern for CANBOX
9033	Input:CANBOX:The cover height must be ≥ 0.0
9034	Input:CONCRE: Must use Level 2 for RSHAPE=BOXES
9035	Input:CANDE_DLL:Invalid Design/Analysis Input =
9036	Input:CANDE_DLL:Invalid Level Number =
9037	Input:CANDE_DLL: Error for Pipe-Type =
9038	Input:CANDE_DLL: Error for LEVEL =
9039	Input:CANDE_DLL: *** STOP, INVALID PIPE-TYPE NAME =
9040	Input:CANDE_DLL: *** STOP, INVALID CANNED MESH NUMBER =
9041	Input:CANDE_DLL: *** STOP, END OF FILE ENCOUNTERED ON FIRST INPUT'


Input Error Number	Text
9042	Input:CANDE_DLL: Element number "NE" is out of bounds.
9043	Input:GENEL: Not allowed to specify Limit=L if IX(1)=0 for element connectivity.
9044	Input:GENEL: A node number assigned to element connectivity is out of bounds.
9045	Input:GENEND:A triangular element has negative (or too small) area.
9046	Input:GENEND:A quadrilateral element has negative (or too small) area.
9047	Input:GENEND: The number of different material numbers for continuum elements is above limit(10 max).
9048	Input:GENEND: An interface element has a material number out of bounds (0 to 99).
9049	Input:GENNOD: Node number NNP is out of bounds.
9050	Input:GENNOD: Nodal generation parameters are not consistent.
9051	Input:GENNOD: Nodal generation parameters are not consistent.
9052	Input:GENNOD: Nodal generation parameters are not consistent.
9053	Input:GENNOD: Nodal generation using MODEG=2 or 3 is not consistent with NPINC.
9054	Input:GENNOD: The input radius for arc generation is not small for the node locations.
9055	Input:GENNOD: Node reference using Krelad-Parameter is not consistent.
9056	Input:GENNOD: The current nodal generation with MODEG =2,3, or 5 will cause Node N* to be redefined.
9057	Input:HEROIC: *****FATAL ERROR BANDWIDTH IS TOO LARGE*****
9058	Input:HEROIC: *****FATAL ERROR SYSTEM STORAGE IS TOO SMALL*****
9059	Input:JMOD: **FATAL ERROR FOR SLOTTED JOINTS IN STEEL PIPE
9060	Input:PLASTI: Some section properties are not > 0.0
9061	Input:PREP: The control word must be "PREP"
9062	Input:PREP: * * * STORAGE SIZE ERROR IN PREP * * * *
9063	Input:PREP: INCREASE NUMBER OF SPECIFIED BOUNDARY CONDITIONS IN LINE C-2.
9064	Input:PRHERO: PARAMETER "ISIZE" NEEDS TO BE INCREASED IN SUBROUTINE PRHERO
9065	Input:RESPIP:Inconsistent number of beam elements specified and actually input.
9066	Input:RESPIP:Lack of beam element sequence connectivity in beam group.
9067	Input:RESPIP:The input beam-element-group number
9068	Input:SLPJNT: Number of input joints > maximum joints allowed =
9069	Input:SLPJNT: Joint number NJ is assigned joint location I3 which exceeds bounds.
9070	Input:SLPJNT: Joint parameter PFAIL must be larger than the stress level at the end of slipping.
9071	Input:STEEL: Some pipe sections are zero.
9072	Input:XANGLE:Cannot compute interface angle.
9073	Input:READM:Material zone number is out-of-bounds in section D input.
9074	Input:READM:Material model number is out-of-bounds in section E input.
9075	Input:READM:Overburden-dependent data points are out-of-bounds in Section D input.
9076	Input:READM: Interface number is out-of-bounds in Section D input.
9077	Input:READM: Not enough soil materials were input.
9078	Input:READM: Not enough interface materials were input.

4.4 Output data and viewing options

To view any output data that has been created from a previously run input file, click “File” on the CANDE tool bar and choose either “Open text input” or “Open” from the drop down menu. A browser window is displayed from which the user selects the name of the input file whose output is to be viewed and plotted.

Next, click on “View” from the CANDE tool bar the drop down menu offers five viewing choices for output consisting of three text files and two interactive graphic tools, which are also accessible from individual icons on the tool bar. The five choices are shown below.

Figure 4.4-1 – CANDE output view options




Short descriptions of the five choices are provided below, followed by more detailed discussion in subsequent sections.

- **CANDE Output Report.** This is the most comprehensive output file and contains text and tables for all the input selections as well as the complete set of structural response data for each load step. The Output Report has an interactive table of contents that allows the user to quickly locate output data of interest. Most notably the evaluation of the pipe type is given in last subsection.
- **CANDE Log File.** The log file is a short file that is displayed on the monitor screen during execution. It contains the master input selections along with a history list of each load step analyzed and a trace of iterations required to solve each load step. If the solution is unsuccessful the log file also provides error messages and, when possible, guidance to correct the error.
- **Mesh Plot.** The mesh plot is an interactive plotting tool for creating and viewing the finite element mesh topology (Level 2 and 3) including element numbering, nodal connectivity, material zones, load steps, and boundary conditions. Likewise, the tool is used to create and plot solution output such as deformed shapes and color contours of soil stresses and strains.
- **Graphs.** This is an interactive plotting tool for creating and viewing the structural response of beam element groups, i.e., pipe types. Structural responses are plotted contiguously over the pipe shape for any load step or sets of load steps. Structural responses include moments, thrusts and shears as well as responses specific to the pipe type such as plastic penetration for corrugated metal and crack depth for reinforced concrete.
- **Results Generator.** This is an interactive text writing tool allowing the user to easily reformat the CANDE output data into in a tailor made report. Options are available for tabularizing soil responses and pipe group responses as a function of load step.

4.4.1 CANDE Output Report

The CANDE output report that is generated during a CANDE analysis is being run may be viewed in the GUI by selecting the View-> Output Report (CANDE) from the main menu (see below).

Figure 4.4-2 – Viewing the CANDE output report



The CANDE Output Report is the primary reference document that defines values for all the input variables as well as the complete tabularized output of soil responses, interface responses and structural responses for each pipe group including safety evaluations of the culvert's structural performance in terms of appropriate design criteria. The report's bottom line is a safety evaluation of each pipe group given at the end of the report.

The Output Report reviewer is equipped with an interactive table of contents that allows the user to quickly locate data of interest. To go directly to a location in the output file, simply click on a node in the interactive 'Output Table of Contents' shown on the left side of the screen. A 'Find' and 'Find Next' button are also available to search for know strings in the output file (such as 'Error').


The 1st -level headings are organized into three major categories;

- (1) Master control and pipe-type data,
- (2) Review system input data,
- (3) Solution output results.

If the user selected the design mode, a fourth major heading called design solution is also included in the table of contents.

An example of an Output Report is shown in the output report viewer below highlighting the nodal displacements for the 3rd load step.

Figure 4.4-3 – CANDE Output Viewer



4.4.1.1 Master control and pipe type data

The master control heading contains the high-level input choices defining the problem and is the first entry in the table of contents with the information shown below:

Master Control

- Title of problem
- Execution mode
- Solution level
- Methodology (LFRD or service)
- Number of pipe groups
- Iteration control

Pipe data is reported by pipe-group number in sequence. Within each pipe group the input data (specified and defaulted) is displayed as illustrated below.

Pipe-Type Properties for Group # x

- Type of pipe material
- Number of pipe elements in group
- Tables of pipe cross-section properties
- Tables of pipe material properties
- Design factors if applicable
- Selection of large deformation/buckling

4.4.1.2 Review of system input data

The second heading level contains a review of system input data describing the geometry and loading of the culvert installation. The table's contents are dependent upon the Solution Level (Level 1, 2 or 3) as illustrated in the following table of content headings.

Level 1 System Properties

- Pipe diameter
- Soil density
- Number of load increments
- Slip or bonded pipe-soil interface assumption
- Table of soil stiffness properties versus fill height
- Table of LRFD load factors per load step, if applicable

Level 2 Data for Canned Meshes

- Canned mesh type (pipe, box or arch)
- Type of installation (embankment, trench or other)
- Number of load steps
- Geometry, shape and dimensions of culvert
- Soil height and density
- Material zones and dimensions
- Interface element options

Level 2 and 3 Finite Element Input Controls and Input data

- Print and plot control numbers
- Key numbers describing mesh topology
- Listing of all input nodes
- X and Y coordinates and node generation codes
- Listing of all element numbers, node connectivity material numbers and load step

- List of all nodes and coordinates including Laplace generated nodes
- Listing of all nodes where boundary conditions are specified
- Listing of local pipe node sequence number related to mesh nodes
- Soil model type and properties for each continuum material number
- Interface element properties for each interface material number
- Listing of load factors for each load step (if applicable)

4.4.1.3 Design solution (if applicable)

The next major heading provides the design solution (if applicable), which is dependent on pipe type as shown below.

Corrugated Metal Design Solution

- Design iteration count
- Required moment of inertia and section area
- Available corrugation sizes and thicknesses
- Optimum design solution and prelude to final analysis

Plastic Pipe Design Solutions

- Design iteration count
- Required wall thickness
- Safety evaluation
- Prelude to final analysis

Reinforced Concrete Design Solutions

- Design iteration count
- Required reinforcement steel area
- Safety evaluation
- Diagnostics and prelude to final analysis

4.4.1.4 Solution/analysis output results

The last major heading contains the complete solution and analysis of the culvert-soil system that was analyzed or designed. The contents depend on whether the solution is closed form (Level 1) or finite element (Solution Level 2 and 3). The output subheadings for the finite element solutions are shown below, the Level-1 subheadings are similar.

Finite Element Output for Load Step #1

Finite Element Output for Load Step #2

+

+

+

Finite Element Output for Load Step #last

Within each load-step, the finite element solution contains the following 3rd level subheadings

Finite Element Output for Load Step # n

- All nodal displacements for soil and structure
- All beam element internal forces
- All continuum element stresses and strains
- All interface element internal forces and movement
- Pipe type evaluation for pipe-group # 1
- Pipe type evaluation for pipe-group # 2

+

- +
- +
- Pipe type evaluation for pipe-group # last (3rd tree level)

The pipe-type evaluation summary for each pipe group contains an assessment of the pipe's structural performance, which is dependent on the pipe material. Shown below is an illustration of the assessment contents for a generic pipe-group x, for load step n.

Pipe type evaluation for pipe-group # x, load step n


- Primary structural responses around pipe (moment, thrust, shear, etc.)
- Special diagnostics depending on pipe material (stains, cracking, local buckling, etc.)
- Assessment summary of pipe safety (safety factors or demand-to-capacity ratios)

The assessment summary is the most important result of the entire output report because it succinctly quantifies the safety of the pipe group in terms of relevant design criteria. This bottom line data is located at the end of the output report.

4.4.2 CANDE log file


The log file that is displayed to the screen when the CANDE analysis is being run may be viewed in the GUI by selecting the View-> CANDE Log File from the main menu (see below).

Figure 4.4-4 – Viewing the CANDE log file



Once selected, the file is displayed as shown below.

Figure 4.4-5 – Viewing the CANDE log file



The log file contains a top-level summary of the input choices that identify the problem being run. It also contains any error messages that may occur during the solution process as well as guidance for fixing the problem.

As illustrated below, the log file also contains a tabular listing of the solution progress to let the user know the real-time status of solving the problem.

TRACK SOLUTION PROCESS

LOAD-STEP	EXIT-CODE	ITERATION
1	0	1
2	-1	1
2	-1	2

2	-1	3
2	0	4
3	-1	1
3	0	2
4	-1	1
4	-1	2
4	0	3
5	-1	1
5	1	2

The first column lists the current load step being solved. The second column is a code number that signals whether or not the solution has converged; -1 means the solution has not yet converged so that the load step is repeated again, 0 means the load step has converged and we advance to the next load step, 1 means solution has converged and all load steps are completed (exit program). Another exit code, -2, which only applies to the design mode means the trial design wall section did not converge. When this occurs, all load steps are repeated with a new trial design.


The right hand column keeps track of the number of iterations per load step. In the above example, we see that the first load step converged in one pass whereas load step two required 4 iterations, load step three required 2 iterations and so on. In the presence of material nonlinearity, interface nonlinearity and large-deformation nonlinearity it is not unusual to require up to 30 iterations to achieve convergence.

A successful CANDE run is recorded in the Log File with the words “NORMAL EXIT FROM CANDE” in the last line.

4.4.3 Mesh Plot

The mesh file and mesh results that are generated by the CANDE analysis may be viewed in the GUI by selecting the View-> Mesh Plot from the main menu. After the mesh plot screen opens, the user has a variety of toolbar-like options to view the mesh topology and/or system response. The following figure provides a summary of the tools for using the CANDE mesh plot viewer.


Figure 4.4-6 – CANDE mesh plot options



4.4.3.1 Using window area to zoom in on mesh

Zooming in a part of the mesh can be accomplished by using the 'Window-Area' icon in the CANDE Mesh Viewer (see Figure 4.2-7 below).


Figure 4.4-7 – Zooming in on a mesh using Window-Area



4.4.3.2 Increasing/Decreasing the element/node font size

The font size shown for the elements and nodes can be increased or decreased simply by clicking on the 'Font-Increment' or 'Font-decrement' buttons on the mesh viewer. This is often convenient when the image is zoomed in or out. Each click on the icons increases or decreases the font size by one point. (See below)


Figure 4.4-8 – Increasing/Decreasing font size in Mesh Plot viewer



4.4.3.3 CANDE mesh viewer options button

Clicking on the 'Options' button in the mesh viewer provides a dialog box where a user can customize the view of the CANDE mesh (see Figure 4.2-11 below). Descriptions of each item are given below the figure.

Figure 4.4-9 – Mesh viewer options



Mesh Coloring

Element text color

Change the color of the element text.

Element line color

Change the color of the mesh lines (with the exception of the beam elements). To make the elements 'invisible', set to white.

Node text color

Change the color of the node text.

Beam element color and thickness

Change the color of the beam element and the thickness of the beam element line weight. This is helpful in making the beam elements stand out.

Magnification Factors

Deflection

Multiplier applied to the deflected shape to exaggerate the deflections.

Boundary diameter

The boundary conditions are shown as circles at the appropriate node. This parameter increases or decreases the diameter to make them less or more visible on the plot. Since the user can click on the boundary conditions to retrieve information, this is often helpful.

Boundary Conditions

Turn on/off the symbols for force or displacement boundary conditions. This is useful for nodes with mixed boundary conditions (force and displacement) in order to see the color-coded boundary condition type. This option is used in tandem with the Boundary Condition On/Off button, 'B', on the tool bar. Note the boundary condition node symbols are color-coded as;

- green means displacement conditions specified in x and y direction,
- blue means a displacement condition specified in either x or y direction,

- Red means a non-zero force boundary condition specified in either x or y direction.

Element numbering

Turn on/off the element numbering for the four primary CANDE elements (interface, beam, triangular or quadrilateral). This option is used in tandem with the Element On/Off button.

Node numbering

Turn on/off the node numbering for the four primary CANDE elements (interface, beam, triangular or quadrilateral). This option is used in tandem with the Node On/Off button.

Materials and Load steps

By default, the materials and load steps are delineated by color. These options permit the user to view them by number.

Ignore Deflections

By default, deflections and other results are plotted as the total accumulated values from the first load increment to the current load increment number. If this button is checked, the response values associated with the load step number entered in the next item ('Load Increment') are subtracted from the current load increment. Thus, the observed displacements are relative to the specified load increment number.


Load Step

Load step to start ignoring deflections.

4.4.3.4 Viewing element information

Element information (node coordinates, element number, element type and current results information) can be viewed in the mesh viewer by selecting the 'Refresh Plot' button and clicking on an element of interest. The example shown below happens to be for a beam element number 801.


Figure 4.4-10 – Displaying element information in the mesh viewer



4.4.3.4 Viewing Deformed Shapes

Viewing a deformed shape in the mesh viewer is achieved by clicking the response button, “R” on the tool bar and choosing the response “Deflections” from the associated drop-down menu. Next, select the desired load increment number from the drop-down menu, and the monitor screen will show the undeformed mesh topology overlain with the deformed mesh due to accumulated deflections at the specified load step. Recall that the deflection magnification factor is specified by the user in the Option Dialogue Box, which is accessed through the “O” button on the tool bar. A sample deflection plot is shown below.

Figure 4.4-11 – Plotting deflections using the mesh viewer




4.4.3.5 Viewing soil stress/strain contours

Color contour plots for stresses and strains in the soil may be generated for the following stress and strain components

- Horizontal stress or strain (normal component in positive x direction)
- Vertical stress or strain (normal component in the positive y direction)
- Shear stress or strain (traction component on x-face in the positive y direction)

Contour plots are generated by clicking the response button, “R” on the tool bar and choosing the desired stress or strain component from the associated drop-down menu. Next, select the desired load increment number from the drop-down menu, and the monitor screen will show the soil mesh topology where each element is colored in accordance with magnitude of stress or strain response at the specified load step. The color scale is shown on the right side of the contour plots. A sample is shown below.

Figure 4.4-12 – Sample plot of Horizontal Stress




4.4.3.6 Coincidental boundary conditions

When more than one boundary condition occurs at a single node, CANDE will offset the boundary conditions when displaying them in the mesh viewer. An example is shown in Figure 4.4-13 below, where 3 boundary conditions exist at node 1436. The purpose of the offset is to display the boundary conditions in a way that the user may click on each one individually to obtain information.

Note: the offset of the boundary conditions is in the mesh viewer only. The analysis places the boundary condition at its proper location.


Figure 4.4-13 – Coincidental boundary conditions offset in mesh viewer



4.4.4 CANDE Graphs for beam elements

The beam element responses that are generated by the CANDE analysis may be viewed in the GUI by selecting the View-> Graphs from the main menu. This tool allows the user to plot beam-element responses for an entire pipe group. The opening screen is similar to that shown Figure 4.4-14 below wherein the bending moment distribution is shown at load step 4.

Figure 4.4-14 – CANDE Graph of bending moment




4.4.4.1 Over view of CANDE Graph Selections

Three drop down menus at the top of the Graph screen, offer the user the following basic choices.

- Selection of load step number to be plotted
- Selection of pipe group number to be plotted
- Selection of the structural response to be plotted

The above selections are illustrated in Figure 4.2-16 below.


Figure 4.4-15 – Overview of CANDE Graphs



4.4.4.2 View of pipe-group shape and properties


To view the pipe group shape and its element topology, click on the toggle button as shown in the figure below.

Figure 4.4-16 – CANDE Graphs window – Pipe Mesh Button



Once the toggle is turned on, a new section will appear in a windowpane at the bottom of the graph viewer as shown in the figure below. The graph window tools are the same icons as described in the Mesh Input viewer and work in the same fashion. (See Section 4.4.3 Mesh Plot for information on the plotting icons)

Figure 4.4-17 – CANDE Graphs window with local node numbering mesh




4.4.4.3 Graph Options

Three options are to customize the graphs are:

- Choice of horizontal axis coordinates
- Capability to plot single or multiple load steps
- Choice of units

To activate the 'Graphs Options', select the button as shown in Figure 4.4-18 below.

Figure 4.4-18 – Beam graph options



Show node numbers on horizontal axis.

The horizontal axis for plotting structural response is always portrayed as a straight line even though the actual path of the pipe group is very likely to be curvilinear. All responses are plotted in reference to the nodes along the pipe-group path. The nodal locations along the horizontal axis may be selected as one of two choices:

- Local node numbers from 1 to the number of pipe group nodes, spaced evenly along axis.
- Actual distance along the along the pipe path (X), starting with 0.0 at node 1. (default)

US units/SI units

Selects either US customary units or SI units to use to display the graph.


Show single load step

If this box is checked, only one load step will be shown per graph. For this case, the user chooses the load step from the combination box on the graph viewer. If this is not checked, the user selects which load steps will be shown on the same graph.

Plot multiple load steps

An example of plotting multiple load steps is shown below. To do this, turn the check off of the 'Show single load step' on the menu. Select the desired load steps to graph. Return to the Graphs window. (See Figure 4.4-19 below)

Figure 4.4-19 – Plotting multiple load steps with CANDE Beam Graph




4.4.5 Results generator

The Results Generator provides a means to view all of the output information provided in the CANDE Mesh Viewer and CANDE Graphs Plotter in a tabulated output report. Because the Results Generator is dynamic, the user can customize the report with any results that are available for the currently loaded CANDE model.

To start the Output Generator, select View->Output Generator from the main menu (Note: you must have successfully run CANDE to be able to review output reports). The following menu will be displayed.

Figure 4.4-20 – CANDE results generator – Generate Mesh Output tab



Formatting

Column separator

There are several options for placing a separator character between the columns in the output file. The default is 1 space but other options are:

- 2 spaces
- 3 spaces
- 4 spaces
- | vertical bar
- , comma
- * asterisk
- ! exclamation
- + plus

The primary purpose for this option is to allow for different delimiters that may be useful for importing CANDE results into other software packages like Microsoft Excel or Access.

Set all output to exponential

The output file will be generated with a predefined number of decimal places unless this box is checked. If it is checked, all output will be presented in exponential format.

CSV File

Checking this box and setting the column separator character to ‘comma’ will generate a comma delimited file CSV which can be opened directly in spread sheet applications like Microsoft Excel.


US units/SI units

Display the output file in the selected units.

The remainder of the General/Mesh Output tab provides check-box selections for the user to choose the mesh input data and solution output data to be written to report.


In addition, the following beam results are available on the ‘Beam Output’ Tab.

Figure 4.4-21 – CANDE results generator – Beam Output tab




In general the items shown grouped together will appear in the same table in the output. If an item is unchecked, the next checked item in the list will ‘slide’ to the left in the table.

If an item is ‘disabled’ or grayed-out, it is not available for display in the output report. After all of the items have been selected, click on the ‘Generate Preview’ button. This will generate and display the output file on the ‘Report Preview’ tab. (see below).

Figure 4.4-22 – CANDE results generator – Report Preview tab

The output file may now be reviewed to see if everything was generated properly. If not, return to the 'General/Mesh Output' and 'Beam Output' tabs to change your options and click on the 'Generate Preview' button again. Once everything is in order, press the 'OK' option. This will open the output file in the Main CANDE interface window

The output window contains a browser for navigating all of the tables generated and a search capability (See Figure 4.4-23). Because the report is dynamic, a user can customize a report at any time to include as much or as little information from the CANDE plot files as needed.

Figure 4.4-23 – CANDE output results browser

5 Detailed CANDE Input

CANDE's Graphical User Interface (GUI) offers two methods for generating input data for CANDE-2007. One method is the "batch mode", which means the user prepares a data file (or CANDE input document) in accordance with the formatted input instructions in this chapter using a text editor such as the CANDE input text editor or Notepad. A CANDE input document is simply a data file or text file that contains the entire formatted input stream, line by line, as prescribed in the detailed input instructions. The user may assign any descriptive name to the data file followed by the file extension ".cid", for example "My problem.cid."

The other method of input is called the Input menu mode (see Chapter 4 Graphical user interface (GUI)), which leads the user through the input options and choices one step at a time. An advantage of the screen mode is that each input step (monitor screen image) is "tailor-made" to conform to the user's previous input choices. Said another way, the user does not need to navigate through the user manual to determine which commands are needed, just follow the screen input instructions.

The two input methods are identical when it comes to executing the program, that is, exactly the same formatted input file is created whether by batch mode or by screen mode. The formatted input file, which is read by the CANDE Engine, consists of lines of input data wherein each line may contain several numerical values to define a set of variables and/or word commands to initiate desired actions. CANDE employs a rigid format to read the input file so that the placement of numerical values and words on each input data line must follow the input instructions in this chapter.

The input flow charts in the next section summarize the type of input data that is required for Solution Levels 1, 2 and 3, respectively. Input data for Level 1 and 2 does not usually require very much preparation time on the part of the user beyond knowing the type and shape of culvert, depth of burial and class of soils. CANDE's internal library provides default values for most material properties of culvert and soil. With the aid of the screen-mode input, even a novice user can generate an input data file in a few minutes.


In contrast to the above, Solution Level 3 does require the user to spend some time in preparing a plan for the finite element mesh topology. Although CANDE contains many helpful mesh generation features, the user's preparation time for Level 3 is considerably longer than for Level 1 or 2.

5.1 Input flow charts

As illustrated in the following charts, the input data is structured into the five parts (A, B, C, D and E) as listed below.


- Part A – Master control selections
- Part B – Pipe type material properties and options
- Part C – Solution Level 1, 2 or 3 input
- Part D – Soil model material properties (Levels 2 and 3)
- Part E – Load factors for LRFD analysis/design (Levels 2 and 3)

5.1.1 CANDE level 1 input flowchart


Level 1 – Input Data Flow Chart

5.1.2 CANDE level 2 input flowchart

Level 2 – Input Data Flow Chart



5.1.3 CANDE level 3 input flowchart

Level 3 – Input Data Flow Chart

5.2 CANDE input instructions

This section provides a guideline for the format of the input instructions provided in the following sections. Each line of input is identified by the capital letter A, B, C, D, or E followed by a number. The capital letter identifies the Data-Part to which the input lines belong, and the trailing number is a count of the formatted lines associated with the Data Part. For example, A-1 and A-2 are the required two lines of input to complete the input for Part A (Master Control).

Input instructions for each line of input are shown in a 3-column table with the headings; Parameter, Input Options and Description. The Parameter column provides a name of the variable or word command along with its short FORTRAN name in parenthesis. In addition, three important pieces of information are given for each parameter:

- **(columns)** = Range of column numbers on data line where parameter is placed. Each data line has a maximum of 80 columns to place parameter values. For example, (21-25) means that the data defining the parameter is to be entered within columns 21 through 25.
- **(format)** = Symbols A, I and F. A is for a word, I is for an integer number and F is for floating point variable. The number “n” following each symbol is the number of column spaces allotted to the input data. All integer and floating-point variables are right justified in the absence of a decimal point.
- **(units)** = **Physical** units are identified for floating point parameters in US Customary units.

Input Options, shown in the center of the input instruction table, provides a short description of each parameter along with optional choices and default values if appropriate. The last segment of the input instruction table provides a longer description of the parameter along with recommendations to the user.

Since many of the CANDE input instruction tables are dependent on previously entered input, tabularized information is provided at the beginning of each data input line to alert the user to the applicability of that input. For example, if the user selected the “ANALYS” mode on data line A-1, then the tabularized information reminds user he should ignore input lines dealing with the “DESIGN” mode.

5.3 Part A - Control Commands

5.3.1 A-1 – Master Control Input Data

A-1
Master Control Input Data

Use if	Comments
Always	This input starts each new problem

Parameter (columns) (format) (units)	Input Options	Description
Design/Analysis Parameter (XMODE) (01-08) (A8) (character)	Word defining problem mode: = ANALYS = DESIGN = STOP (No default)	Specifying the variable XMODE controls the decision of design or analysis. Analysis implies all system and pipe properties are known and the objective is to evaluate pipe performance. Design means the pipe wall section properties are unknown, and that they will be determined in an iterative analysis process. CANDE will continue to execute new problems, back-to-back, until XMODE = STOP is encountered.
Solution Level (LEVEL) (09-10) (I2) (integer)	Defines Solution Level to be used: = 1, Elasticity = 2, FEM with canned mesh = 3, FEM with user mesh (No default)	<p>Level 1 is based on the closed form elasticity solution of Burns and Richards. It is applicable to round pipes deeply buried in homogenous soil installations (no live loads).</p> <p>Level 2 is considered the workhorse of CANDE and provides a finite element solution methodology using an internally developed mesh based on a few physical parameters specified by the user in part C. Canned meshes are available for round, elliptical, box and arch-shaped culverts. Loading includes live loads as well as incremental layers of soil. Level 2's major limitation is the assumption of symmetry about the vertical centerline of a specified pipe type.</p> <p>Level 3 provides the full power of the finite element method to characterize any soil-structure system. This includes multiple structural shapes and/or multiple structural materials (pipe types). Level 3 requires that the user develop the finite element mesh including element connectivity arrays, coordinates and boundary conditions. Although CANDE has many helpful mesh</p>

Parameter (columns) (format) (units)	Input Options	Description
		generation features, use of Level 3 requires some familiarity with the finite element method for proper modeling of the soil-structure system.
Method of Analysis/Design (LRFD) (11-12) (I2) (integer)	Method of analysis/design = 0, service = 1, LRFD Default = Service	Choice of Working Stress (service) or Load-Resistance-Factor-Design (LRFD) methodology for analysis and design. Working Stress uses actual loading conditions, where as LRFD increases the actual load with specified load factors.
Number of Pipe Element Groups (NPGRPS) (13-15) (I3) (integer)	Number of pipe element groups for Level 3: = number of groups (Default = 1) (Maximum = 30) This item is only input for Level 3	For Level 1 and 2 the number of pipe groups is inherently defined = 1. For level 3, however, more than one pipe group may be specified if it is desired to model more than one pipe material or more than one sequence of connected pipe elements. Specifically, a pipe group is defined by a pipe material type (STEEL for example) <u>and</u> the number of pipe elements in that group (1 or more). The pipe elements in any group must be connected in an ordered sequence head-to-toe tracing a curvilinear path representing the mid depth of the structural segment. Pipe groups (or structural segments) may be connected to one another in any fashion or be disconnected. For example, one pipe group could represent a concrete box culvert and another group could represent an arch-shaped steel culvert that is not directly connected because they share no nodes in common. Or, two concrete culvert groups could represent the left and right footings connected to a group representing an arch-shaped steel culvert.
Heading for Output Files (HED) (16-75) (A60) (character)	User defined heading of problem	Enter any descriptive words that describe the problem to be solved. This heading will also be printed with the output.
Maximum Number of Iterations per Step (ITMAX) (76-80) (I5) (integer)	Max number of iterations per step = N, perform N iterations and stop = -N, perform N iterations and continue. Default = +30 (recommended)	ITMAX is the maximum number of iterations per load step, which controls the convergence of all nonlinear algorithms in CANDE (pipe models, soil models, interface model and large deformations). If ITMAX is input positive (N>0), CANDE will stop at the load step that did not converge and print out diagnostics on models that did not converge. If ITMAX is input negative (N<0), CANDE will continue processing all load steps even if they did not converge as well as print out diagnostics on models that did not converge.

Parameter (columns) (format) (units)	Input Options	Description
Culvert ID (CULVERTID) (81-85) (I5) (integer)	Culvert ID number. Default = 0	This value is only used as an identifier for the culvert of buried structure if NCHRP Process 12-50 results are desired. The value is only used in the printing of the 12-50 results. If this value is not input, the NCHRP Process 12-50 results will not be produced. The output format for the Process 12-50 results are provided in the appendix of this User Manual.
Process ID (PROCESSID) (86-90) (I5) (integer)	Process ID number. Default = 0	This value is only used as a unique identifier for this version of CANDE. The value is only used in the printing of the 12-50 results. The output format for the Process 12-50 results are provided in the appendix of this User Manual.
Subdomain ID (SUBDID) (91-95) (I5) (integer)	Subdomain ID number. Default = 0	This value is only used as a unique identifier for this version of CANDE. The value is only used in the printing of the 12-50 results. The output format for the Process 12-50 results are provided in the appendix of this User Manual.

5.3.2 A-2 –Pipe Selection

A-2.L12 (levels 1 or 2), A-2.L3 (level 3)

Master Control Input Data

Use if	Comments
Always	
A-1.LEVEL = 1 or 2	Use this command once for solutions levels 1 and 2 to describe the pipe material.
A-1.LEVEL = 3	This command will be entered for each pipe group . The number of pipe groups for solution level 3 is defined on the A.1 command. NOTE: This command is used in tandem with the B-commands defined in subsequent sections of this chapter

Parameter (columns) (format) (units)	Input Options	Description
Pipe Type (PTYPE) (01-10) (A10) (word)	<p>Word defining type of pipe material (or structure segment).</p> <p>= ALUMINUM</p> <p>= BASIC</p> <p>= CONCRETE</p> <p>= PLASTIC</p> <p>= STEEL</p> <p>(No default)</p>	<p>Choosing PTYPE means the selection of the pipe material to be analyzed or designed. For level 1 or 2 only one pipe type can be selected per problem.</p> <p>For level 3 the user will select a PTYPE for each pipe group (NPGRPS times). Input for each PTYPE consists of Line A-2 followed by the set of lines in Part B, which defines the pipe-type properties.</p> <p>Corrugated aluminum cross-section with material options for elastic-plastic behavior.</p> <p>General cross-sectional properties with elastic material.</p> <p>Reinforced concrete smooth wall section with nonlinear material models for concrete and rebar.</p> <p>Smooth and Profile wall plastic pipe with linear material properties and non-linear local buckling model.</p> <p>Corrugated steel cross-section with elastic-plastic material behavior. Also has option for slotted joint behavior.</p> <p>There is no default for “no pipe type”. To use CANDE without pipe elements select: LEVEL</p>

Parameter (columns) (format) (units)	Input Options	Description
		= 3, PTYPE = BASIC, and NPMATX = 0. Skip part B input.
Canned Mesh Code (NPCAN) (Level 2 only) (11-15) (15) (integer)	Canned mesh code used only for LEVEL = 2. = 1, Pipe mesh circular or elliptical opening) = 2, Box mesh (rectangular opening) = 3, Arch mesh (arch-shaped or 3 sided box opening)	Under level 2, NPCAN allows the user to select the type of canned mesh to be used in this problem. (see Table 5.3-1 for increments) For level 1 the NPCAN variable is not used, and for level 3 this variable is renamed NPMATX and defined differently as discussed subsequently. The “Pipe mesh” creates a circular or elliptical culvert cross-section assuming vertical centerline symmetry. Options for trench and embankment installations, interface elements, and incremental construction. (a.k.a CAN1 mesh) The “Box mesh” creates a rectangular, closed-cell culvert cross-section assuming vertical centerline symmetry. Options for trench and embankment installations, bedding depth and incremental construction. (a.k.a. CANBOX mesh) The “Arch mesh” creates a two or three segment arch or box resting on footings assuming vertical centerline symmetry. Options for trench and embankment installations with built-in interface elements. (a.k.a. CANAR1 mesh)
For Level 2, Part A is complete- Proceed to Part B.		

Parameter (columns) (format) (units)	Input Options	Description
Number of Connected Beam Elements (NPMATX)(Level 3 only) (11-15) (15) (integer)	Number of connected beam elements in this group, for level 3 only, (No Default value) (Maximum = 999)	<p>The number (quantity) of beam elements in any group may range from 1 to 999. It is to be understood that elements in any group form a continuous sequence, connected head to toe tracing the centerline path of the structure or a segment of the structure.</p> <p>The group number identifier, 1 to NPGRPS, is automatically assigned in the sequential order of input. That is, the first data set (Line A2 plus set B) becomes group # 1, the second data set becomes group # 2, and so on until all NPGRPS groups are input.</p> <p>The linkage between the group numbers established here and the finite element mesh established in input set C is by means of the element's material identification number called IX(5). In data set C, the user must assign the appropriate group number to each beam element's material identification number.</p>

Proceed to Part B to define pipe properties for the Pipe-Type Selected.

After set B is complete, return to Line A-2 to select next pipe-type if NPGRPS > 1.

Table 5.3-1 – Reference data on culvert elements used in canned meshes

Pipe element statistics (1-group)	Pipe Mesh (NPCAN = 1)	Box Mesh (NPCAN = 2)	Arch Mesh (NPCAN = 3)
Number of pipe elements, NPMAT=	10	14	19
Number of sequence pipe nodes, NPPT=	11	15	20

5.4 Part B- Pipe Materials

This section provides the description of the input data related to Pipe Materials.

CANDE provides the modeling of the following pipe materials:

- Corrugated Aluminum
- Basic
- Reinforced Concrete
- Thermoplastic
- Corrugated Steel

Proceed to the desired pipe material.

5.4.1 Aluminum Pipe Type


5.4.1.1 B-1 – Aluminum – Material and Control Parameters

B-1.Alum
Aluminum Material and Control Parameters

Use if	Comments
A-2.PTYPE 'ALUMINUM'	= One or more pipe groups are Aluminum.

Parameter (columns) (format) (units)	Input Options	Description
Young's Modulus (PE) (01-10) (F10.0) (lb/in ²)	Elastic Young's Modulus of pipe material Default=10.0x10 ⁶ psi	Linear stress-strain modulus for pipe material, see Figure 5.4-1.
Poisson's Ratio (PNU) (11-20) (F10.0) (--)	Poisson's ratio of pipe material Default = 0.33	Poisson's ratio is used for plane-strain formulation. This means that the effective linear modulus is $PE^* = PE/(1-PNU^2)$.
Yield Stress of Pipe(PYIELD) (21-30) (F10.0) (lb/in ²)	Yield Stress of pipe material Default = 24,000 psi	Stress at end of elastic range, same in tension and compression. See the bilinear stress-strain curve in Figure 5.4-1
Yield Strength of Pipe Seam(PSEAM) (31-40) (F10.0) (lb/in ²)	Yield strength of pipe seam Default = PYIELD	Strength of longitudinal seams in corrugations that are bolted, riveted, or welded may be less than PYIELD. For seamless pipes, PSEAM = PYIELD.
Density of Material (PDEN) (41-50) (F10.0) (lb/in ³)	Density of material Default = 0.0 lb/in ³	Applies only to Level 2 and 3. This value produces the self-weight of the aluminum culvert in the loading schedule (PDEN = 0.0975 pci). Leave blank to ignore self-weight deformations.

Parameter (columns) (format) (units)	Input Options	Description
Modulus of Upper Portion of Bilinear Model (PE2) (51-60) (F10.0) (lb/in ²)	Modulus of upper portion of bilinear model. Default = 0.05*PE	This value is only used when NONLIN = 2. It is the slope of the stress-strain curve after yielding, see Figure 5.4-1. For aluminum alloys the default is recommended.
Linear Material Behavior (NONLIN) (61-65) (I5) (integer)	Code to select material behavior: =1, linear stress-strain =2, bilinear stress-strain Default = 2	This parameter controls the material law to be used. The linear model only uses the modulus PE, whereas the bilinear model uses both PE and PE2. Recommend NONLIN = 2.
Buckling Indicator (IBUCK) (66-70) (I5) (integer)	Code to select large-deformation and buckling analysis: = 0, small deformation = 1, large deformation = 2, plus buckling.	IF IBUCK = 0, small deformation theory and simplified buckling equations are used. If BUCK = 1, the pipe elements will include large deformation theory (geometric stiffness). In addition if IBUCK=2, an estimate of the remaining buckling capacity will be computed at each load step.

Figure 5.4-1 – Aluminum-1: Bilinear stress-strain parameters

5.4.1.2 B-2 – Aluminum – Analysis Section Properties

B-2.Alum.A	
Aluminum analysis section properties	
Use if	Comments
A-2.PTYPE 'ALUMINUM' =	One or more pipe groups are Aluminum.
A-1.XMODE=ANALYS	Use only if the 'Design/Analysis' parameter (XMODE) is set to 'ANALYS'.

Parameter (columns) (format) (units)	Input Options	Description
Area of pipe wall section per unit length (PA) (01-10) (F10.0) (in ² /in)	Area of pipe wall section per unit length (No default)	The cross-sectional area of one corrugation period divided by the period length. (See Table 5.4-1 and Table 5.4-2. for standard section properties)
Moment of inertia of pipe wall section per unit length (PI) (11-20) (F10.0) (in ⁴ /in)	Moment of inertia of pipe wall section per unit length (No Default)	Moment of inertia of one corrugation period divided by period length. Centroid is at mid- depth of cross section. (See Table 5.4-1 and Table 5.4-2. for standard section properties)
Section modulus of pipe wall per unit length (PS) (21-30) (F10.0) (in ³ /in)	Section modulus of pipe wall per unit length. (No Default)	The section modulus is equal to the moment of inertia divided by one-half of the corrugation depth, $PI/(h/2)$. (See Table 5.4-1 and Table 5.4-2. for standard section properties).

If XMODE = ANALYSIS and LRFD = 0, Part B is now complete.

Go to Part C (or return to line A-2 if more pipe groups need to be defined).

If XMODE = ANALYSIS and LRFD = 1, Proceed to line B-3

Table 5.4-1 Aluminum-1. Section Properties for Standard Aluminum Corrugation

Corrugation Profile	Section Properties	Corrugation thickness -- inches					
		0.048	0.060	0.075	0.105	0.135	0.164
1-1/2 x 1/4	PA in ² /in	0.05070	0.06342	0	0	0	0
	PI in ⁴ /in	0.00034	0.00035	0	0	0	0
	PS in ³ /in	0.00228	0.00226	0	0	0	0
2-2/3 x 1/2	PA in ² /in	0	0.06458	0.08067	0.11300	0.14533	0.17775
	PI in ⁴ /in	0	0.00189	0.00239	0.00342	0.00453	0.00573
	PS in ³ /in	0	0.00675	0.00831	0.01131	0.01427	0.01726
3 x 1	PA in ² /in	0	0.07416	0.09317	0.1300	0.17400	0.20483
	PI in ⁴ /in	0	0.00866	0.01088	0.01545	0.02017	0.02508
	PS in ³ /in	0	0.01634	0.02024	0.02796	0.03554	0.04309
6 x 1	PA in ² /in	0	0.0646	0.08067	0.11300	0.14533	0.17775
	PI in ⁴ /in	0	0.00850	0.01060	0.01490	0.01910	0.02340
	PS in ³ /in	0	0.01604	0.01972	0.02697	0.03366	0.04021

Table 5.4-2 Aluminum -2. Section Properties for 9 x 2 1/2 Aluminum Corrugation

Section Properties	9 x 2-1/2 Corrugation thickness -- inches						
	0.100	0.125	0.150	0.175	0.200	0.225	0.250
PA in ² /in	0.11700	0.14583	0.17500	0.20408	0.23325	0.26242	0.29175
PI in ⁴ /in	0.08310	0.10400	0.12490	0.14590	0.16700	0.18820	0.20940
PS in ³ /in	0.06392	0.07924	0.09426	0.10908	0.12370	0.13813	0.15229

Thickness = Specified thickness of metal gage in inches

Corrugation size = nominal height x pitch measured in inches.

Nominal height = Inside valley to corrugation crest (i.e., actual height minus thickness)

Actual height = nominal height plus thickness

PA = Cross-sectional area per unit inch

PI = Moment of Inertia per unit inch

PS = Section modulus per unit inch (PI divided by one-half of actual height)

5.4.1.3 B-2 – Aluminum – Design Safety Factors and Deflection Control

B-2.Alum.D.WSD
Aluminum Material and Control Parameters

Use if	Comments
A-2.PTYPE 'ALUMINUM' =	One or more pipe groups are Aluminum.
A-1.LRFD = 0	This command is only applicable for Service Load design.
A-1.XMODE='DESIGN'	This command is only applicable if the 'Design/Analysis' parameter is set to 'DESIGN'

Parameter (columns) (format) (units)	Input Options	Description
Desired safety factor against thrust yielding(PFS(1)) (01-10) (F10.0) (--)	Desired safety factor against thrust yielding; (Default = 3.0)	Safety factor protects against excessive thrust force causing aluminum material yielding of the entire cross-section (tension or compression). Typical PFS range is 2.0 to 3.0
Desired safety factor against global buckling (PFS(2)) (11-20) (F10.0) (--)	Desired safety factor against global buckling. (Default = 2.0)	Safety factor protects against excessive thrust force causing global buckling of the pipe's walls in soil-structure system. Typical PFS range is 2.0 to 3.0
Desired safety factor against seam failure due to thrust stress (PFS(3)) (21-30) (F10.0) (--)	Desired safety factor against seam failure due to thrust stress (Default = 2.0)	Safety factor protects against excessive thrust force causing seam failure. For seamless pipe this is equal to material yielding, PFS = 2.0. For structural plate, recommend PFS = 3.0
Desired safety factor against full plastic hinge penetration (PFS(4)) (31-40) (F10.0) (--)	Desired safety factor against full plastic hinge penetration (Default = 4.0)	Safety factor protects against excessive plastic hinge penetration from thrust and bending. PFS = (100% depth)/(% allowable depth). Thus, for 25% allowable penetration, PFS= 4.0

Parameter (columns) (format) (units)	Input Options	Description
Maximum allowable vertical deflection percentage (ADISP) (41-50) (F10.0) (%)	Maximum allowable vertical deflection percentage (Default = 5.0)	ADISP is the maximum allowable percentage of vertical deflection with respect to the vertical height. For pipes and pipe arches, 5% of the vertical height is typical. For long-span structures, 2% of total rise is typical

The working-stress design output provides a list of corrugation sizes along with the required metal thickness to meet the above design criteria. CANDE determines the design output by performing a series of analyses beginning with a trial cross-section and successively modifying it after each analysis until the specified safety factors are satisfied in an optimum manner. CANDE selects the least weight corrugation for a final analysis and evaluation.

If the ‘Design/Analysis’ XMODE = Design and the ‘Method of Analysis’ parameter LRFD = 0, Part B is now complete.

Go to Part C (or return to line A-2 if more pipe groups need to be defined).

5.4.1.4 B-2 – Aluminum – Design Weights for LRFD

B-2.Alum.D.LRFD**Aluminum Material and Control Parameters**

The specification of the WLRFD design weights has the following consequences:

- WLRFD = 1.0, Standard LRFD (factored resistance = factored loads)
- WLRFD > 1.0 More conservative (factored resistance > factored loads)
- WLRFD < 1.0 Less conservative (factored resistance < factored loads)
- WLRFD = -1.0 Exclude the corresponding design criterion

Use if	Comments
A-2.PTYPE 'ALUMINUM' =	One or more pipe groups are Aluminum.
A-1.LRFD = 1	This command is only applicable for LRFD design.
Design/Analysis parameter is 'DESIGN'	This command is only applicable if the 'Design/Analysis' parameter is set to 'DESIGN'

Parameter (columns) (format) (units)	Input Options	Description
Wall area failure due to maximum thrust stress (WLRFD(1)) (01-10) (F10.0) (--)	Wall area failure due to maximum thrust stress (Default weight = 1)	The design goal is to determine the corrugated wall area so that the weighted-factored-thrust-stress is just less than the factored-yield-strength-resistance of aluminum
Global buckling due to thrust stress (WLRFD(2)) (11-20) (F10.0) (--)	Global buckling due to thrust stress (Default weight = 1)	The design goal is to determine the corrugated wall moment of inertia so that the weighted-factored-thrust-stress is just less than the factored-thrust-resistance for global buckling.
Seam failure due to thrust stress (WLRFD(3)) (21-30) (F10.0) (--)	Seam failure due to thrust stress (Default weight = 1)	The design goal is to determine the corrugated wall area so that the weighted-factored-thrust-stress is just less than the factored-yield-strength-of longitudinal seams
Cross-section failure due to plastic penetration (WLRFD(4)) (31-40) (F10.0) (--)	Cross-section failure due to plastic penetration. (Default weight = 1)	The design goal is to determine the corrugated wall moment of inertia so that the weighted-factored-plastic-penetration due to thrust and bending is less than the factored-complete-plastic wall penetration. **

Parameter (columns) (format) (units)	Input Options	Description
Service deflection limit (WLRFD(5)) (41-50) (F10.0) (--)	Service deflection limit (Default weight = 1)	The design goal is to determine the corrugated wall moment of inertia so that the weighted-service-load deflection is less than the allowable deflection.

Similar to the working-stress approach, the above design weights give the designer control over the degree of conservatism for the LRFD process. By choosing the design weights = 1, CANDE will determine the required corrugation size and thickness such that the controlling factored load nearly matches the corresponding factored resistance. If, however, a designer desires a 25% more conservative design solution against global buckling, the designer may specify $WLRFD(2) = 1.25$. Alternatively, a designer may exclude any design criterion that the designer does not want to apply to the problem at hand by setting the corresponding design weight = -1.

** Limiting the plastic penetration in corrugated metal is a newly proposed strength criterion that replaces the ineffectual plastic moment criterion for metal box culverts.

Proceed to line B-3 (LRFD = 1)

5.4.1.5 B-3 – Aluminum – Resistance Factors for LRFD

B-3.Alum.AD.LRFD**Resistance factors for LRFD limit states**

Use if	Comments
A-2.PTYPE = 'ALUMINUM'	One or more pipe groups are Aluminum.
A-1.LRFD = 1	This command is only applicable for LRFD design.
A-1.XMODE = 'ANALYS' or 'DESIGN'	This command is only applicable if the 'Design/Analysis' parameter is set to 'DESIGN' or 'ANALYS'

Parameter (columns) (format) (units)	Input Options	Description
Resistance factor for wall area yielding due to thrust stress (PHI(1)) (01-10) (F10.0) (--)	Resistance factor for wall area yielding due to thrust stress (Default = 1.0)	Factored thrust stress resistance = $\text{PHI}(1) \times \text{PYIELD}$. Choosing $\text{PFS}(1) = 1$ is generally recommended and consistent with current LRFD specifications.
Resistance factor for global buckling due to thrust stress (PHI (2)) (11-20) (F10.0) (--)	Resistance factor for global buckling due to thrust stress (Default = 1.0)	Factored global buckling resistance = $\text{PHI}(2) \times \text{Buckling-Capacity}$. Buckling capacity is determined by large deformation theory in CANDE if $\text{IBUCK} = 2$. Otherwise simplified buckling equations are used.
Resistance factor for seam strength due to thrust stress (PHI (3)) (21-30) (F10.0) (--)	Resistance factor for seam strength due to thrust stress (Default = 0.67)	Factored seam strength resistance = $\text{PHI}(3) \times \text{PSEAM}$. The default value applies to metal structures with longitudinal seams, for seamless structures set $\text{PHI}(3) = 1$.
Resistance factor for cross-section capacity for plastic-penetration (PHI (4)) (31-40) (F10.0) (--)	Resistance factor for cross-section capacity for plastic-penetration (Default = 0.85)	Factored cross-section capacity resistance = $\text{PHI}(4) \times 100\%$ of cross-section depth. This criterion applies to the percentage of cross-section that becomes plastic due to both thrust and bending stresses.**

Parameter (columns) (format) (units)	Input Options	Description
Allowable deflection at service load (DISP) (41-50) (F10.0) (%)	Allowable deflection at service load (Default = 5%)	Allowable deflection is the relative vertical deflection, typically taken as 5% of vertical diameter. For long-span structures, allowable deflection is 2% total rise. The service loading criterion is approximated by reducing predicted displacements by the load factors.

Comment: The above resistance factors are used for both the design and analysis modes. In the analysis mode CANDE will show the five numerical values of the above factored resistances along with the corresponding factored responses.

In the design mode, the designer is given additional control on the previous page to design with more or less conservatism and to permit turning on or off any of the criterion to fit the problem at hand.

****** Limiting the plastic penetration in corrugated metal is a newly proposed strength criterion that replaces the ineffectual plastic moment criterion for metal box culverts.
We suggest that designers evoke this criterion for all metal culverts.

This completes the current B-set input.

Go to Part C (or return to line A-2 if more pipe groups need to be defined).

5.4.2 Basic Pipe Type

5.4.2.1 B-1 – Basic – Sequence Intervals and Properties

B-1.Basic
Sequence intervals and properties: Repeat line B-1 to define all sequences of pipe properties in this group.

Use if	Comments
A-2.PTYPE = 'BASIC'	One or more pipe groups are Basic.
A-1.XMODE = 'ANALYS'	This command is only applicable if the 'Design/Analysis' parameter is set to 'ANALYS' NOTE: This input is not valid for 'DESIGN'

Parameter (columns) (format) (units)	Input Options	Description
First pipe-element number in this sequence (ISEQ1) (01-05) (15) (integer)	First pipe-element number in this sequence (No Default)	ISEQ1 is the beginning local element sequence numbers within this pipe group that shares the same material properties up to and including ISEQ2. This feature allows changing the material properties within the pipe group. (See example in Note #2)
Last pipe-element number in this sequence (ISEQ2) (06-10) (15) (integer)	Last pipe-element number in this sequence (Default = ISEQ1)	ISEQ2 is the ending local element sequence number within this pipe group that shares the same material properties with all elements in the sequence ISEQ1 to ISEQ2. (See example in Note #2)
Young's modulus for this sequence of pipe material. (PE) (11-20) (F10.0) (lb/in ²)	Young's modulus for this sequence of pipe material. (No Default)	The BASIC element is not associated with any particular material (hence no default values or design option). A linear stress-strain model is the only option, characterized by PE.
Poisson's ratio for this sequence of pipe material. (PNU) (21-30) (F10.0) (--)	Poisson's ratio for this sequence of pipe material. (No Default)	Poisson's ratio is used for plane-strain formulation. This means that the effective modulus is $PE^* = PE/(1-PNU^2)$.
Area of pipe wall-section per unit length, for sequence (PA) (31-40) (F10.0) (in ² /in)	Area of pipe wall-section per unit length, for sequence (No Default)	This is the pipe's wall cross-sectional area per unit length of pipe, which provides resistance to hoop (or column) compression or tension

Parameter (columns) (format) (units)	Input Options	Description
Moment of inertia of wall section per unit length, for sequence (PI) (41-50) (F10.0) (in ⁴ /in)	Moment of inertia of wall section per unit length, for sequence (No Default)	This is the pipe's wall moment inertia per unit length of pipe, which provides resistance to ovaling (or bending) deformation
Line-load of pipe element, for sequence (PDENL) (51-60) (F10.0) (lb/in)	Line-load of pipe element, for sequence (No Default)	The element's line-load is the gravity force per inch along the element's length in the x-y plane. To represent dead weight of material, set PDENL = PA * density(pci). This only applies to Levels 2 and 3.

Note #1. The BASIC pipe type only applies to the analysis mode. The material model is linear elastic and allows changing the material and geometric properties from element to element.

Note # 2. Example of using ISEQ1 and ISEQ2. If there are 10 elements in this pipe group with a change of material properties after the first five elements, then we would set ISEQ1 = 1 and ISEQ2 = 5, thereby assigning the first sequence material properties to the first five elements. Then, the B-1 instructions would be repeated with ISEQ1 = 6 and ISEQ2 = 10 to define the second set of material properties. If all the group elements happen to have the same material properties, we would set ISEQ1 = 1 and ISEQ2 = Number of elements in the group.

After all B-1 subsequences are defined Proceed to Line B-2.

5.4.2.2 B-2 – Basic – Large Deformation Control

B-2.Basic
Large deformation control.

Use if	Comments
A-2.PTYPE = 'BASIC'	One or more pipe groups are Basic.
A-1.XMODE = 'ANALYS'	This command is only applicable if the 'Design/Analysis' parameter is set to 'ANALYS' NOTE: This input is not valid for 'DESIGN'

Parameter (columns) (format) (units)	Input Options	Description
Analysis mode (IBUCK) (01-05) (15) (integer)	Code to select large deformation and buckling analysis = 0, small deformation = 1, large deformation = 2, plus buckling	If IBUCK is greater than zero, the element group will include large deformation theory (geometric stiffness). In addition if IBUCK = 2, an estimate of the remaining buckling capacity will be computed for each load step. (See Note # 3 for extended IBUCK codes)

Note # 3. For academic purposes, the variable IBUCK is further defined in the table below to provide control on the three components of large deformation theory; (1) geometric stiffness matrix, (2) rotational stretch vector, and (3) coordinate update.

Large Deformation Component:	IBUCK Code Value						
	2	1	0	-1	-2	-3	-4
Geo-Stiffness	On	On	Off	On	On	On	Off
Rotation-Stretch	On	On	Off	Off	Off	On	Off
Coordinate Update	On	On	Off	Off	On	Off	On
Buckling Prediction	On	Off	Off	Off	Off	Off	Off

This completes the current B-set input.

Go to Part C (or return to line A-2 if more pipe groups need to be defined).

5.4.3 Reinforced Concrete Pipe Type

5.4.3.1 B-1 – Concrete – Concrete Material Properties

B-1.Concrete		
Concrete material properties		

Use if	Comments	
A-2.PTYPE 'CONCRETE'	=	One or more pipe groups are Concrete.

Parameter (columns) (format) (units)	Input Options	Description
Compressive strength of concrete (f_c') (PFPC) (01-10) (F10.0) (lb/in ²)	Compressive strength of concrete (f_c') Default = 4000 psi	Uni-axial compressive stress of concrete in standard cylinder compression test or core specimen from pre-cast pipe. See Figure 5.4-2.
Young's modulus of concrete for elastic (PCE) (11-20) (F10.0) (lb/in ²)	Young's modulus of concrete for elastic Default = $33 * (\text{density})^{1.5} (f_c')^{0.5}$	Slope of stress-strain curve of concrete in initial compression prior to nonlinear yielding. See Figure 5.4-2.
Poisson's ratio of concrete material (PNU) (21-30) (F10.0) (--)	Poisson's ratio of concrete material Default = 0.17	Poisson's ratio is used for plane-strain formulation
Multiplying factor to compute nominal shear strength (VFACTOR) (31-40) (F10.0) (--)	A multiplying factor to compute nominal shear strength = $VFACTOR \times (f_c')^{1/2}$ Default = (traditional method not used)	By specifying VFACTOR > 0.0 (e.g. 2.0), the traditional method of specifying concrete shear strength is used instead of the newer methods offered next. For plain concrete without any steel reinforcement, VFACTOR = 2 is recommended. Shear strength is only used in CANDE for design/analysis evaluations. (See comments next page)

Parameter (columns) (format) (units)	Input Options	Description
Option to select shear strength equation (NSHEAR) (41-45) (15) (integer)	Code to select shear strength equation: = 1, concrete pipes and arches = 2, concrete boxes and 3-sided structures with at least 2 feet of fill = 3, concrete boxes and 3-sided structures with less than 2 feet of fill. Default = 1	At the present time, the AASHTO LRFD specifications provide three different sets of equations to estimate the shear strength of reinforced concrete culverts depending on the installation type. For culvert installations other than concrete boxes or a 3-sided box structure, it is recommended to use the shear strength for concrete pipes and arches (NSHEAR = 1). Note that the shear strength equations are used in CANDE for design/analysis evaluation in both working stress and LRFD methodology. (See comments below)

Comment on shear strength:

CANDE offers four options for estimating the shear strength of the concrete cross-sections, which are applicable to either working stress or LRFD design/analysis evaluation. Note, the shear strength equations are not part of the r/c constitutive model so that they do not influence the structural responses; rather, the shear strength equations are only used only to evaluate the safety and performance. The four options are:

VFACTOR > 0.0, Older traditional method. The shear strength equation is given by VFACTOR multiplied by the square root of PFPC to give shear strength in terms of psi units. The shear strength is multiplied by the shear depth “d” to get shear capacity in terms of lbs/inch. If VFACTOR = 0, then the shear capacity is determined by the choice of NSHEAR.

NSHEAR = 1, Concrete pipes and arches. The associated shear strength equation is adapted from AASHTO LRFD specifications 12.10.4.2.5, which is based on the work by Heger and McGrath (1983). In this model, the shear capacity is dependent on the moment, thrust and shear at the cross-section so that the shear capacity varies around the structure. Tim McGrath provided the modified equations that are used in CANDE and the resulting shear capacity is printed out at each node along with equivalent “v-factor” interpretation.

NSHEAR = 2, Concrete boxes and 3-sided structures with at least 2 feet of fill. The associated shear strength equations are given directly in AASHTO LRFD specifications 5.14.5.3-1. In this model, the shear capacity is dependent on the moment and shear at the cross-section so that the shear capacity varies around the structure. The resulting shear capacity is printed out at each node along with equivalent “v-factor” interpretation.


NSHEAR = 3, Concrete boxes and 3-sided structures with less than 2 feet of fill. The associated shear strength equations are given in AASHTO LRFD specifications 5.8.3.3. For this model, it is assumed that the concrete sections are not prestressed and that simplified procedure defined in Section 5.8.3.4.1 is applicable so that the diagonal crack parameters are taken as $\beta = 2$ and $\theta = 45$ degrees, thereby producing a constant, but conservative, shear capacity.

Comment on transverse reinforcement.

CANDE does not directly include transverse reinforcement (e.g., stirrups for diagonal cracking and/or radial tension) in the reinforced concrete model. However, the new version of CANDE computes the required shear force at each node, if any, that the transverse reinforcement must sustain over and above the concrete shear strength. With this information the designer can readily determine the required stirrup size and spacing.

Proceed to line B-2

Figure 5.4-2 – Concrete Stress-Strain model and parameters



5.4.3.2 B-2 – Concrete – Concrete Material Properties-2

B-2.Concrete**More concrete material properties and model selection**

Use if	Comments
A-2.PTYPE 'CONCRETE'	= One or more pipe groups are Concrete.

Parameter (columns) (format) (units)	Input Options	Description
Concrete strain at tension rupture (positive) (STNMAT(1)) (01-10) (F10.0) (in/in)	Concrete strain at tension rupture (positive) Default = 0.0	The tensile strain that causes concrete initial cracking is a sensitive parameter. Setting STNMAT(1) = 0.0 is conservative, but common practice for design. Typical range for standard concrete is 0.00003 to 0.0001 in/in. See Figure 5.4-2
Compressive strain at end of elastic range (positive) (STNMAT(2)) (11-20) (F10.0) (in/in)	Compressive strain at end of elastic range (positive) Default = 0.5*PFPC/PCE	This strain level marks the end of the linear stress-strain relation in compression. See Figure 5.4-2
Compressive strain at the initial strength limit, (positive) (STNMAT(3)) (21-30) (F10.0) (in/in)	Compressive strain at the initial strength limit, f_c' Default = 0.002 in/in	This strain level marks the end of the yielding range and the beginning of the pure plastic response of concrete in compression. See Figure 5.4-2
Unit weight of concrete for body weight. (PDEN) (31-40) (F10.0) (lb/ft ³)	Unit weight of concrete for body weight. Default = 0.0 pcf	Density of concrete is used to include body weight in the loading schedule for levels 2 & 3. If PDEN = 0.0 no body weight is included, and density = 150 pcf for PCE default calculation.
Crack width model option (CWMODEL) (41-50) (F10.0) (-- or inches)	Selection of crack width model: = 0, Heger-McGrath = -1, Gergely-Lutz = positive value equal to crack-spacing length for plain concrete. Default = Heger-McGrath	Generally it is recommended to use the Heger-McGrath model, which is required by the AASHTO LRFD code. If there is no tension steel reinforcement, such as for plain or fiber reinforced concrete (FRC), then CANDE provides the option to apply the crack-spacing-length model wherein CWMODEL = the crack spacing length (nominally 10 inches). See comments on crack width models below

Parameter (columns) (format) (units)	Input Options	Description
Analysis mode (IBUCK) (51-55) (15) (integer)	Code to select large-deformation and buckling analysis: = 0, small deformation = 1, large deformation = 2, plus buckling.	If this value is greater than zero, the pipe elements will include large deformation theory (geometric stiffness). In addition if IBUCK=2, an estimate of the remaining buckling capacity will be computed at each load step. Typically large deformations and buckling is not a concern for reinforced concrete structures, but may be useful in some special cases.

Comment on Crack Widths.

CANDE uses empirical formulas to predict crack width based on the magnitude of tension steel stress determined from CANDE's reinforced concrete model. CANDE output always gives the predicted crack width at service load level regardless of whether LRFD = 0 or 1.

The Heger-McGrath crack-width equation is adapted from the AASHTO LRFD code (12.10.4.2.4d) and is expressed with stresses (f_s and f_c') in ksi units as:

$$CW = (1/3000) (t_b s_l / 2n)^{1/3} \{f_s - 0.0316 C_1 (h/d)^2 \sqrt{f_c'} / \rho\} \quad (\text{inches})$$

The older Gergely-Lutz empirical formula for crack width with f_s in ksi units is:

$$CW = (0.000122) (2 t_b^2 s_l)^{1/3} \{f_s - 5.0\} \quad (\text{inches})$$

When there is no reinforcement steel such as for plain concrete, CANDE provides the option to predict crack width based on the concrete tension strain in excess of the concrete cracking strain multiplied by the crack spacing length (nominally = 10 in):

$$CW = \text{crack-spacing-length} * (\epsilon_{\text{tension}} - \epsilon_{\text{cracking}}) \quad (\text{inches})$$

5.4.3.3 B-3 – Concrete – Reinforcement Steel Placement and Properties

B-3.Concrete
Reinforcement steel placement and properties.

Use if	Comments
A-2.PTYPE 'CONCRETE'	= One or more pipe groups are Concrete.

Parameter (columns) (format) (units)	Input Options	Description
Reinforcement Shape (RSHAPE) (01-05) (A5,5X) (word)	Word defining the shape and placement of reinforcing steel cage(s): = STAND = ELLIP = ARBIT = BOXES (Default = STAND)	RSHAPE allows selection of how the reinforcement will be shaped and placed relative to the concrete inner and outer wall surfaces. Standard placement for two rows of reinforcement cages, which parallel the inner and outer wall surfaces. The concrete wall thickness is uniform and concrete cover-depths and properties are uniform in each individual cage. (Applicable to levels 1, 2, or 3; and design or analysis) Elliptical placement of a single reinforcement cage sometimes used in circular pipe. The cage starts at a specified cover-depth from the outer wall surface of the crown, transitions to the inner wall surface at the spring line, and transitions back to the outer wall at the invert. (Applicable to levels 1, 2, or 3; and design or analysis) Arbitrary placement of two rows of reinforcement. The concrete wall thickness, the reinforcements' concrete cover-depth, and reinforcement steel areas may be specified at each node along the pipe-group path. (Applicable to levels 2 or 3 for analysis only) Special placement of two rows of reinforcement conforming to ASTM box culvert specifications. (Intended to be used in conjunction with level 2 – Box mesh for analysis only)

Parameter (columns) (format) (units)	Input Options	Description
Yield stress of reinforcing steel (PFSY) (11-20) (F10.0) (lb/in ²)	Yield stress of reinforcing steel Default = 60,000 psi	Reinforcement is modeled as elastic-perfectly plastic where PFSY represents the maximum stress attainable
Young's modulus of reinforcing steel (PSE) (21-30) (F10.0) (lb/in ²)	Young's modulus of reinforcing steel Default = 29×10^6 psi	Slope of steel's stress-strain curve in linear range. Behavior is assumed identical in tension and compression.
Poisson's ratio (PSNU) (31-40) (F10.0) (--)	Poisson's ratio of reinforcing steel Default = 0.3	Poisson's ratio is used for plane-strain formulation
Inner surface spacing between rows of reinforcement (SLI) (41-50) (F10.0) (inches)	Spacing between rows of rebar on inner surface (Default = 2.0 in)	CANDE uses the SLI parameter only for predicting crack-width in the Gergely-Lutz formula and the Heger-McGrath formula.
Outer surface spacing between rows of reinforcement (SLO) (51-60) (F10.0) (inches)	Spacing between rows of rebar on outer surface (Default = 2.0 in)	CANDE uses the SLO parameter only for predicting crack-width in the Gergely-Lutz formula and the Heger-McGrath formula.
Number of inner cage layers of reinforcement (NI) (61-65) (I5) (integer)	Number of layers of reinforcement to form inner cage steel area. (Default = 1)	CANDE uses the NI parameter only for predicting crack-width using the Heger-McGrath formula. (Note, a maximum value of NI = 2 is used in formula for n, see comment following line B-2)
Number of outer cage layers of reinforcement (NO) (66-70) (I5) (integer)	Number of layers of reinforcement to form outer cage steel area. (Default = 1)	CANDE uses the NO parameter only for predicting crack-width using the Heger-McGrath formula. (Note, a maximum value of NO = 2 is used in formula for n, see comment following line B-2)

Parameter (columns) (format) (units)	Input Options	Description
Type of Reinforcement (NC1) (71-75) (15) (integer)	Code number for type of reinforcement: =1, Smooth wire or plain bars. =2, Welded or deformed wire. =3, Deformed bars or with stirrups. (Default = 2)	CANDE uses the NC1 parameter only for predicting crack-width using the Heger-McGrath formula. The code value, NC1 = 1, 2, or 3 corresponds to the Heger-McGrath variable C_1 set to 1.0, 1.5 or 1.9, respectively. See Heger-McGrath crack-width equation following line B-2.
Nonlinear behavior selection (NONLIN) (76-80) (15) (integer)	Code to select level of nonlinear behavior: =1, cracking only =2, add concrete plastic behavior =3, also include steel yielding behavior Default = 3	As a general rule, concrete cracking and nonlinear compressive behavior along with steel yielding should be used for all real-world problems (NONLIN = 3). Lesser degrees of nonlinearity may be useful for comparative studies.

Guide for next lines of input

The next lines of input starting with Line B-4, depends upon the previous choices of XMODE, LRFD and RSHAPE as shown in table below

Case #	Pre-selected Input			Go to line B-4 with the description that matches the pre-selected input:
	XMODE	LRFD	RSHAPE	
1	Analysis	0 or 1	Standard or Ellipse	B4 – Analysis with uniform walls and circular or elliptical reinforcement (Level 1, 2 or 3)
2	Analysis	0 or 1	Arbitrary	B4 – Analysis with arbitrary walls and placement of reinforcement (Level 2 or 3)
3	Analysis	0 or 1	Boxes	B4, B4b – Analysis for ASTM box culvert walls and rebar placement (used with Level 2-Box)
4	Design	0	Standard or Ellipse	B4 -- Design for uniform walls and circular or elliptical rebar (working stress Level 1, 2 or 3)
5	Design	1	Standard or Ellipse	B4, B5 -- Design for uniform walls and circular or elliptical rebar (LRFD Level 1, 2 or 3)

5.4.3.4 B-4 – Concrete-Case 1– Wall Thickness and Reinforcement Properties

B-4.Concrete.Case1_2**Wall thickness and reinforcement properties (Case 1)**

Use if	Comments
A-2.PTYPE = 'CONCRETE'	One or more pipe groups is Concrete
B-3.RSHAPE = 'STAND' or 'ELLIP'	This command is only applicable if the 'Reinforcement Shape' set on the previous command is set to 'Standard' or 'Elliptical'.
A-1.XMODE = 'ANALYS'	This command is only applicable if the 'Design/Analysis' parameter is set to 'ANALYS' NOTE: This input is not valid for 'DESIGN'

Parameter (columns) (format) (units)	Input Options	Description
Concrete wall thickness (PT) (01-10) (F10.0) (inches)	Concrete wall thickness (Default = none)	This specified thickness is constant for all elements in this group. Enter a non-zero value.
Steel area in cage 1 (ASI) (11-20) (F10.0) (in ² /in)	Steel area in cage # 1, a smeared average per unit length of pipe. (Default = 0.0 in ² /in)	If RSHAPE = STAND, ASI (cage # 1) is the rebar paralleling the inner wall. If RSHAPE = ELLIP, ASI (cage # 1) is the only line of rebar in the wall and transitions from inner wall to outer wall as described. See Figure 5.4-3.
Steel area in cage 2 (ASO) (21-30) (F10.0) (in ² /in)	Steel area in cage # 2, a smeared average per unit length of pipe. (outer cage) (Default = 0.0 in ² /in)	If RSHAPE = STAND, ASO (cage # 2) is the rebar paralleling the outer wall. If RSHAPE = ELLIP, ASO is not used. See Figure 5.4-3.
Concrete cover to c.l. of cage 1 (TBI) (31-40) (F10.0) (inches)	Concrete cover thickness to centerline of cage # 1 (Default = 1.25 in)	IF RSHAPE = STAND, TBI is the uniform cover thickness of the inner wall cage. IF RSHAPE = ELLIP, TBI is the minimum cover thickness at crown, invert and spring line. See Figure 5.4-3


Parameter (columns) (format) (units)	Input Options	Description
Concrete cover to c.l. of cage 2 (TBO) (41-50) (F10.0) (inches)	Concrete cover thickness to centerline of cage # 2 (outer cage) (Default = 1.25 in)	IF RSHAPE = STAND, TBO is the uniform cover thickness of the outer wall cage. IF RSHAPE = ELLIP, TBI is not used. See Figure 5.4-3

If XMODE = ANALYSIS and LRFD = 0, Part B is now complete.

Go to Part C (or return to line A-2 if more pipe groups need to be defined).

If XMODE = ANALYSIS and LRFD = 1, Proceed to line B-5

Figure 5.4-3 – Cross sections for RSHAPE = STAND or ELLIP



5.4.3.5 B-4 – Concrete – Case 2 – Arbitrary Specified Wall Thickness

B-4.Concrete.Case1_2**Arbitrary specified wall thickness and reinforcement steel (Case 2)**

For the Arbitrary option, line B-4 must be repeated for each node sequence in the pipe group. Note the total number of nodes in a group = number pipe elements in group + 1. (Start with N = 1).

For level 2 this number is preset and is described in Table 5.3-1

For Level 3 this number is set by the user as NPMATX (see section 5.3.1).

Use if	Comments
A-2.PTYPE = 'CONCRETE'	One or more pipe groups is Concrete
B-3.RSHAPE = 'ARBIT'	This command is only applicable if the 'Reinforcement Shape' set on the previous command is set to 'Arbitrary'.
A-1.XMODE = 'ANALYS'	This command is only applicable if the 'Design/Analysis' parameter is set to 'ANALYS' NOTE: This input is not valid for 'DESIGN'
A-1.LRFD = 0 or 1	This is command is input for either LRFD or Service.
A-1.LEVEL = 2 or 3	This option is NOT available for Solution Level 1.

Parameter (columns) (format) (units)	Input Options	Description
Concrete wall thickness at node N. PT(N) (01-10) (F10.0) (inches)	Concrete wall thickness at node N for current node sequence. (Default = none)	The specified concrete wall thickness may differ from node sequence to node sequence along element group as desired. The current node sequence is defined by the local node numbers NSEQ1 through NSEQ2. See comments below (*See Note).
Area of steel, cage 1 (ASI(N)) (11-20) (F10.0) (in ² /in)	Steel area of cage # 1 for node sequence. This is a smeared average area per unit pipe length. (Default = 0.0 in ² /in)	Cage # 1 is associated with the inner pipe wall. Steel areas may vary from node sequence to node sequence as desired, including the case of no steel ASI(N) = 0.0.
Area of steel, Cage 2 (ASO(N)) (21-30) (F10.0) (in ² /in)	Steel area of cage # 2 for node sequence. This is a smeared average area per unit pipe length. (Default = 0.0 in ² /in)	Cage # 2 is associated with the outer pipe wall. Steel areas may vary from node sequence to node sequence as desired, including the case of no steel ASO(N) = 0.0.
Concrete cover, cage 1 (TBI(N)) (31-40) (F10.0) (inches)	Concrete cover thickness to centerline of cage # 1 for node sequence (Default = 1.25 in)	Concrete cover thickness for cage # 1 is relative to the inner wall surface. Cover thickness may vary from node sequence to node sequence as desired.

Parameter (columns) (format) (units)	Input Options	Description
Concrete cover, cage 2 (TBO(N)) (41-50) (F10.0) (inches)	Concrete cover thickness to centerline of cage # 2 for node sequence (outer cage) (Default = 1.25 in)	Concrete cover thickness for cage # 2 is relative to the outer wall surface. Cover thickness may vary from node sequence to node sequence as desired
Node sequence start (NSEQ1) * (51-55) (15) (integer)	First local node number in a sequence of nodes with common properties (see *Note) Default = none	NSEQ1 is the first local node number in a consecutive set of node numbers that share the same geometric properties for the concrete cross section and reinforcing steel as defined above. See *NOTE and comment below
Node sequence end (NSEQ2) * (56-60) (15) (integer)	Last local node number in a sequence of nodes with common properties (see *Note) Default = none	NSEQ2 is the last local node number in a consecutive set of node numbers that share the same geometric properties for the concrete cross section and reinforcing steel as defined above. See *NOTE and comment below.

*NOTE: The node sequencing is not implemented in the 'Input Menus' (i.e. GUI Input). A row must be entered for each node. To facilitate the entry of these values, a 'Copy Row' button is available in the input menus. With this command, the user may input one row of section properties and then copy those values to a group of rows (i.e. a group of nodes).

Comment. In the simplest case, if all beam nodes in this group have the same section properties, set $NSEQ1 = 1$ and $NSEQ2 = NPMAT + 1$, and all geometric section properties are defined with one input line for B-4.

More generally, the above input feature allows the user to change the section properties within this pipe group using multiple input lines for B-4. Note however, the material properties are fixed for this group. To change material properties, such as the strength of the concrete or steel, the user would need to define a separate pipe group.

As an example of changing section properties, suppose that the current pipe group is defined with 24 pipe elements (25 nodes). Suppose further that the first 10 elements have the same set of section properties, element 11 is a transition element, and the remaining 13 elements have another set of common section properties. In this case, we would input the first node sequence as $NSEQ1 = 1$ and $NSEQ2 = 11$ to define common section properties to the first 10 elements. Next, we would input the second node sequence as $NSEQ1 = 12$ and $NSEQ2 = 25$ to define common section properties for elements 12 to 24. Note that the transition element, bounded by nodes 11 and 12, would be implicitly defined by the average of the two sets of geometric properties. Note for the last sequence we must always have, $NSEQ2 = NPMAT + 1$.

In the most general case if each node has a different section property, then line B-4 must be repeated for each node so that the node sequences would be defined as: $(NSEQ1, NSEQ2) = (1,1), (2,2), (3,3) \dots (NPMAT+1, NPMAT+1)$. For this most general case, CANDE will automatically compute the paired values for NSEQ1 and NSEQ2 if they are all left blank in the input stream

If XMODE = ANALYSIS and LRFD = 0, Part B is now complete.

Go to Part C (or return to line A-2 if more pipe groups need to be defined).

If XMODE = ANALYSIS and LRFD = 1, Proceed to line B-5

5.4.3.6 B-4 – Concrete – Case 3 – ASTM Box Wall Thicknesses and Haunches

B-4.Concrete.Case3**ASTM box wall thicknesses and haunches(Case 3)**

This command is used in tandem with “B-4b – Concrete – Case 3 – ASTM Steel Placement for Boxes”.

Use if	Comments
A-2.PTYPE = 'CONCRETE'	One or more pipe groups is Concrete
B-3.RSHAPE = 'BOXES'	This command is only applicable if the 'Reinforcement Shape' set on the previous command is set to 'Boxes'.
A-1.XMODE = 'ANALYS'	This command is only applicable if the 'Design/Analysis' parameter is set to 'ANALYS' NOTE: This input is not valid for 'DESIGN'
A-1.LRFD = 0 or 1	This is command is input for either LRFD or Service.
A-1.LEVEL = 2	This option is NOT available for Solution Levels 1 or 3.

Parameter (columns) (format) (units)	Input Options	Description
Nominal concrete wall thickness (PT) (01-10) (F10.0) (inches)	Nominal concrete wall thickness of box culvert (Default = 0.0)	This value for wall thickness is used as the default value for the three slab thicknesses defined below.
Top slab concrete thickness (PTT) (11-20) (F10.0) (inches)	Top slab concrete thickness (Default = PT)	Each of the three slab thicknesses (top, sides and bottom) may be defined separately. Or if all slab thicknesses are the same, the default PT value may be used. See Figure 5.4-4.
Side slabs concrete thickness (PTS) (21-30) (F10.0) (inches)	Side slabs concrete thickness (Default = PT)	Each of the three slab thicknesses (top, sides and bottom) may be defined separately. Or if all slab thicknesses are the same, the default PT value may be used. See Figure 5.4-4.

Parameter (columns) (format) (units)	Input Options	Description
Bottom slab concrete thickness (PTB) (31-40) (F10.0) (inches)	Bottom slab concrete thickness (Default = PT)	Each of the three slab thicknesses (top, sides and bottom) may be defined separately. Or if all slab thicknesses are the same, the default PT value may be used. See Figure 5.4-4.
Horizontal haunch dimension (HH) (41-50) (F10.0) (inches)	Horizontal haunch dimension (Default = 0.0)	Horizontal haunch thickness at interior corners. See Figure 5.4-4. CANDE increases the wall thickness at the corner nodes in accordance with the specified haunch dimensions.
Vertical haunch dimension (HV) (51-60) (F10.0) (inches)	Vertical haunch dimension (Default = 0.0)	Vertical haunch thickness at interior corners. See Figure 5.4-4 . CANDE increases the wall thickness at the corner nodes in accordance with the specified haunch dimensions.

Proceed to line B-4b to complete ASTM box input data

5.4.3.7 B-4b – Concrete – Case 3 – ASTM Steel Placement for Boxes

B-4b.Concrete.Case3**ASTM box wall thicknesses and haunches(Case 3)**

This command should be preceded by “B-4 – Concrete – Case 3 – ASTM Box Wall Thicknesses and Haunches”.

Use if	Comments
A-2.PTYPE = 'CONCRETE'	One or more pipe groups is Concrete
B-3.RSHAPE = 'BOXES'	This command is only applicable if the 'Reinforcement Shape' set on the previous command is set to 'Boxes'.
A-1.XMODE = 'ANALYS'	This command is only applicable if the 'Design/Analysis' parameter is set to 'ANALYS' NOTE: This input is not valid for 'DESIGN'
A-1.LRFD = 0 or 1	This is command is input for either LRFD or Service.
A-1.LEVEL = 2	This option is NOT available for Solution Levels 1 or 3.


Parameter (columns) (format) (units)	Input Options	Description
Steel area for outer sidewalls and connecting slabs. (AS1) (01-10) (F10.0) (in ² /in)	Steel area for outer sidewalls and connecting slabs. Default = 0.0 in ² /in	See Figure 5.4-4 for placement of AS1 rebar. As always steel area is input as area per unit length of pipe.
Steel area for inner wall of top slab. (AS2) (11-20) (F10.0) (in ² /in)	Steel area for inner wall of top slab. Default = 0.0 in ² /in	See Figure 5.4-4 for placement of AS2 rebar. As always steel area is input as area per unit length of pipe.
Steel area for inner wall of bottom slab. (AS3) (21-30) (F10.0) (in ² /in)	Steel area for inner wall of bottom slab. Default = 0.0 in ² /in	See Figure 5.4-4 for placement of AS3 rebar. As always steel area is input as area per unit length of pipe.
Steel area for inner wall of side slabs. (AS4) (31-40) (F10.0) (in ² /in)	Steel area for inner wall of side slabs. Default = 0.0 in ² /in	See Figure 5.4-4 for placement of AS4 rebar. As always steel area is input as area per unit length of pipe.

Parameter (columns) (format) (units)	Input Options	Description
Ratio of length of AS1 in steel in top and bottom slabs. (XL1) (41-50) (F10.0) (--)	Ratio of length of AS1 in steel in top and bottom slabs. Default = 0.0	This ratio is the steel length (L1) to one-half span length (R1) as shown in Figure 5.4-4.
Uniform concrete cover thickness to all steel centers. (TC) (51-60) (F10.0) (inches)	Uniform concrete cover thickness to all steel centers. (Default = 1.25 in)	All steel cages, inner walls and outer walls, are assigned the same concrete cover thickness specified with TC. See Figure 5.4-4.


If XMODE = ANALYSIS and LRFD = 0, Part B is now complete. Go to Part C (or return to line A-2 if more pipe groups need to be defined).

If XMODE = ANALYSIS and LRFD = 1, Proceed to line B-5

Figure 5.4-4 – ASTM Concrete box geometry and steel placement for box culverts with a minimum 2-foot cover depth.



Level 2 Box: Box geometry and steel placement



Level 2 Box: Node numbering and Cross-Section view

5.4.3.8 B-4 – Concrete – Case 4 – Specified Wall Thickness and Working Stress SF

B-4.Concrete.Case4**Specified wall thickness and working stress design.**

Use if	Comments
A-2.PTYPE = 'CONCRETE'	One or more pipe groups is Concrete
B-3.RSHAPE = 'STAND' or 'ELLIP'	This command is only applicable if the 'Reinforcement Shape' set on the previous command is set to 'STAND' or 'ELLIP'.
A-1.XMODE = 'DESIGN'	This command is only applicable if the 'Design/Analysis' parameter is set to 'DESIGN'
A-1.LRFD = 0	This is command is input for service design.
A-1.LEVEL = 1, 2 or 3	This option is available for all Solution Levels 1, 2, or 3.

Parameter (columns) (format) (units)	Input Options	Description
Concrete wall thickness (PT) (01-10) (F10.0) (inches)	Concrete wall thickness used for design problem (Default = none)	The design wall thickness is uniform around the pipe. Specify a non-zero value. (Note the design solution will provide required steel reinforcement area)
Steel yielding safety factor (PFS(1)) (11-20) (F10.0) (--)	Desired safety factor against steel yielding (Default = 1.6)	This is the fundamental working-stress design criterion for steel reinforcement. Typically this safety factor is specified in the range from 1.5 to 2.0
Concrete crushing stress safety factor (PFS(2)) (21-30) (F10.0) (--)	Desired safety factor against concrete crushing stress. (Default = 2.0)	This is the working-stress criterion that the concrete compressive stress does not reach ultimate strength (f_c') by the specified factor of safety. Typical range is 1.7 to 2.0
Concrete shear failure safety factor (PFS(3)) (31-40) (F10.0) (--)	Desired safety factor against concrete shear failure (Default = 2.0)	This safety factor, which depends on the selected shear-strength model, may need to be satisfied with the use of stirrups and/or increased wall thickness, which is the responsibility of the designer.

Parameter (columns) (format) (units)	Input Options	Description
Radial tension failure safety factor (PFS(4)) (41-50) (F10.0) (--)	Desired safety factor against concrete radial tension failure (Default = 2.0)	The radial tension stress and the corresponding strength of concrete subjected to inner-wall steel tension is adapted from Heger/McGrath (ACI-1983). Satisfying this safety factor may require the designer to use traverse steel.
Allowable maximum crack width (ALCW) (51-60) (F10.0) (inches)	Allowable maximum crack width. (Default = 0.01 in)	The allowable crack width is a performance criterion, not a failure criterion. The design process will allow cracking up to ALCW (that is, safety factor = 1)
Concrete cover to c.l. of steel rebar cage (TBI) (61-70) (F10.0) (inches)	Concrete cover to centerline of steel rebar cage(s) (Default = 1.25 in)	If RSHAPE = STAND, TBI is uniform concrete cover for both inner and outer cages. If RSHAPE = ELLIP, TBI is minimum cover of the cage at crown, spring-line and invert.
Ratio of steel areas of outer-to-inner cages (SRATIO) (71-80) (F10.0) (--)	Desired ratio of steel areas of outer-to-inner cages (Default = 0.75)	Typically the outer cage steel area is specified with less steel area than the inner cage. This only applies to RSHAPE = Standard. If RSHAPE = ELLIP, SRATIO is not used.

If XMODE = DESIGN and LRFD = 0, Part B is now complete.

Go to Part C (or return to line A-2 if more pipe groups need to be defined).

5.4.3.9 B-4 – Concrete – Case 5 – Specified Wall Thickness/LRFD Design Weights

B-4.Concrete.Case5**Specified wall thickness and design weights for LRFD.**

The specification of the WLRFD design weights has the following consequences:

- WLRFD = 1.0, Standard LRFD (factored resistance = factored loads)
- WLRFD > 1.0 More conservative (factored resistance > factored loads)
- WLRFD < 1.0 Less conservative (factored resistance < factored loads)

WLRFD = -1.0 Exclude the corresponding design criterion

Use if	Comments
A-2.PTYPE = 'CONCRETE'	One or more pipe groups is Concrete
B-3.RSHAPE = 'STAND' or 'ELLIP'	This command is only applicable if the 'Reinforcement Shape' set on the previous command is set to 'STAND' or 'ELLIP'.
A-1.XMODE = 'DESIGN'	This command is only applicable if the 'Design/Analysis' parameter is set to 'DESIGN'
A-1.LRFD = 1	This is command is input for LRFD.
A-1.LEVEL = 1, 2 or 3	This option is available for all Solution Levels 1, 2, or 3.

Parameter (columns) (format) (units)	Input Options	Description
Concrete wall thickness (PT) (01-10) (F10.0) (inches)	Concrete wall thickness (Default = none)	The design wall thickness is uniform around the pipe. Specify a non-zero value. Note the CANDE design solution will provide required steel reinforcement area(s).
Steel tension failure due to yielding (WLRFD(1)) (11-20) (F10.0) (--)	Weight for steel tension yielding. (Default weight = 1)	The design goal is to determine the steel area so that the weighted-factored-tension-steel-stress is just less than factored-yield-strength resistance.
Concrete crushing failure at outer fibers (WLRFD(2)) (21-30) (F10.0) (--)	Weight for concrete crushing failure (Default weight = 1)	The design goal is to determine the steel area (or, new wall thickness) so that the weighted-factored-concrete compressive-stress is just less than the factored-compressive-resistance.

Parameter (columns) (format) (units)	Input Options	Description
Concrete shear failure (w/o shear steel) (WLRFD(3)) (31-40) (F10.0) (--)	Weight for concrete shear failure (without shear steel) (Default weight = 1)	The design goal is to maintain the weighted-factored-shear-force to be less than the factored-shear-capacity. If needed, the excess shear force to be carried by stirrups.
Concrete failure due to radial tension from curved rebar (WLRFD(4)) (41-50) (F10.0) (--)	Weight for concrete radial tension failure from curved rebar (Default weight = 1)	The design goal is to maintain the weighted-factored-radial-tension-stress to be less than the factored-radial-tension-resistance. If needed, excess load to be carried by stirrups.
Service load allowable crack width (WLRFD(5)) (51-60) (F10.0) (--)	Service load allowable crack width (Default weight = 1)	The design goal is to determine the steel area so that the weighted-service-load-crack-width is less than the allowable-crack-width.
Concrete cover to c.l. of steel rebar cage (TBI) (61-70) (F10.0) (inches)	Concrete cover to centerline of steel rebar cage(s) (Default = 1.25 in)	If RSHAPE = STAND, TBI is uniform concrete cover for both inner and outer cages. If RSHAPE = ELLIP, TBI is minimum cover of the cage at crown, spring-line and invert.
Ratio of steel areas of outer-to-inner cages (SRATIO) (71-80) (F10.0) (--)	Desired ratio of steel areas of outer-to-inner cages (Default = 0.75)	Typically the outer cage steel area is specified with less steel area than the inner cage. This only applies to RSHAPE = Standard. If RSHAPE = ELLIP, SRATIO is not used.

Proceed to line B-5 (LRFD = 1)

5.4.3.10 B-5 – Concrete – Resistance Factors for LRFD

B-5.Concrete**Resistance factors for LRFD limit states.**

Use if	Comments
A-2.PTYPE = 'CONCRETE'	One or more pipe groups is Concrete
A-1.XMODE = 'DESIGN' or 'ANALYS'	This command is applicable if the 'Design/Analysis' parameter is set to 'DESIGN' or 'ANALYS'
A-1.LRFD = 1	This command is input for LRFD.
A-1.LEVEL = 1, 2 or 3	This option is available for all Solution Levels 1, 2, or 3.

Parameter (columns) (format) (units)	Input Options	Description
Resistance factor for steel rebar yielding due to tension stress (PHI(1)) (01-10) (F10.0) (--)	Resistance factor for steel rebar yielding due to tension stress (Default = 0.9)	Factored steel stress resistance = $\text{PHI}(1) \times \text{PFSY} (f_y)$
Resistance factor for concrete crushing (PHI (2)) (11-20) (F10.0) (--)	Resistance factor for concrete crushing due to thrust and moment (Default = 0.75)	Factored concrete crushing stress resistance = $\text{PHI}(2) \times \text{PFPC} (f'_c)$
Resistance factor for concrete shear failure (PHI(3)) (21-30) (F10.0) (--)	Resistance factor for concrete shear failure (Default = 0.9)	Factored shear strength resistance = $\text{PHI}(3) \times \text{Selected shear strength option.}$
Resistance factor for radial concrete tension (PHI (4)) (31-40) (F10.0) (--)	Resistance factor for radial concrete tension (Default = 0.9)	Factored radial tension resistance = $\text{PHI}(4) \times \text{concrete tension stress limit as proposed by Heger/McGrath (ACI-1983)}$

Parameter (columns) (format) (units)	Input Options	Description
Allowable crack width for service load (ACW) (41-50) (F10.0) (inches)	Allowable crack width for service load (Default = 0.01inch)	Allowable crack width for service limit loading. CANDE approximates the crack width at service loading by dividing steel stress in crack width formulas by load factors.

Comment: The above resistance factors are used for both the design and analysis modes. In the analysis mode, CANDE will show the five numerical values of the above factored resistances along with the corresponding factored demands.

In the design mode, the designer is given additional control on the previous page to design with more or less conservatism and to permit turning on or off any of the criterion to fit the problem at hand.

This completes the current B-set input.

Go to Part C (or return to line A-2 if more pipe groups need to be defined).

5.4.4 Plastic Pipe Types

5.4.4.1 B-1 – Plastic – Plastic Load Controls

B-1.Plastic
Plastic load controls.

Use if	Comments
A-2.PTYPE = 'PLASTIC'	One or more pipe groups are Plastic.

Parameter (columns) (format) (units)	Input Options	Description
Wall section type (WTYPE) (01-10) (A7,3X) (word)	A word selecting the type of wall section. = SMOOTH = GENERAL = PROFILE Default = GENERAL	SMOOTH refers to uniform smooth wall (gun barrel) whose only independent cross section property is the wall thickness. Applies to design & analysis. GENERAL refers to arbitrary cross-section properties for area and moment of inertia without local buckling consideration. Applies only to analysis. PROFILE refers to a spectrum of profile shapes such as corrugated with or without liners, ribbed walls, etc. Profile shapes require additional geometry input and include local buckling analysis. Applies only to analysis.
Type of plastic (PTYPE) (11-20) (A5,5X) (word)	A word selecting the type of plastic. = HDPE = PVC = PP = OTHER Default = HDPE	PTYPE is used to provide default material properties for HDPE (high density polyethylene), PVC (Polyvinyl Chloride), or PP (Polypropylene) as shown in Table B-Plastic-1. Setting PTYPE = OTHER means all material properties will be defined by the user.
Load duration (LOADT) (21-25) (15) (integer)	Code number to select load duration: = 1, Short term = 2, long term Default = short term	Plastic material properties depend on load duration, short term is appropriate for live loads and long term is appropriate for earth loads. If need be, the problem can be run twice, once with short duration properties and once with long duration properties to bracket the responses of each load step.
Analysis mode (IBUCK) (26-30) (15) (integer)	Code to select large-deformation and buckling analysis: = 0, small deformation = 1, large deformation = 2, plus buckling. Default = small deform.	IF IBUCK = 0, small deformation theory and simplified buckling equations are used. If BUCK = 1, the pipe elements will include large deformation theory (geometric stiffness). In addition if IBUCK=2, an estimate of the remaining buckling capacity will be computed at each load step.

Proceed to Line B-2

5.4.4.2 B-2 – Plastic – Material Properties for Plastic

B-2.Plastic		
Plastic load controls.		
Use if	Comments	
A-2.PTYPE = 'PLASTIC'	One or more pipe groups are Plastic.	
Parameter (columns) (format) (units)	Input Options	Description
Young's modulus for short-term loading (PESHRT) (01-10) (F10.0) (lb/in ²)	Young's modulus for short-term loading (Default from table 1)	Depending on the type of plastic, enter the effective elastic stress-strain modulus for short-term loading. If left blank, default values from Table 5.4-3 are provided depending on the type of plastic (PTYPE) . See Figure 5.4-5.
Ultimate stress limit for short-term loading (PUSHRT) (11-20) (F10.0) (lb/in ²)	Ultimate stress limit for short-term loading (Default from table 1)	The short-term ultimate stress is the maximum stress sustainable by the plastic used to evaluate the safety of the stress level. If left blank, default values from Table 5.4-3 are provided depending on the type of plastic (PTYPE).See Figure 5.4-5.
Young's modulus for long-term loading (PELONG) (21-30) (F10.0) (lb/in ²)	Young's modulus for long-term loading (Default from table 1)	Depending on the type of plastic, enter the effective elastic stress-strain modulus for long-term loading. If left blank, default values from Table 5.4-3 are provided depending on the type of plastic (PTYPE) . See Figure 5.4-5.
Ultimate stress limit for long-term loading (PULONG) (31-40) (F10.0) (in ² / in ²)	Ultimate stress limit for long-term loading (Default from table 1)	The long-term ultimate stress is the maximum stress sustainable by the plastic used to evaluate the safety of the stress level. If left blank, default values from Table 5.4-3 are provided depending on the type of plastic (PTYPE). See Figure 5.4-5.
Poisson's ratio (PNU) (41-50) (F10.0) (--)	Poisson's ratio for short- and long-term loading Default = 0.3	Poisson's ratio is used for plane-strain formulation wherein effective modulus is $PE^* = PE/(1-PNU^2)$. Poisson's ratio is taken the same for short and long term loading
Density of plastic material used for body weight. (PDEN) (51-60) (F10.0) (lb/in ³)	Density of plastic material used for body weight. (Default = 0.0 lb/in ³)	Applies only to Level 2 and 3. This value produces the self-weight of the plastic structure in the loading schedule. Leave blank to ignore self-weight deformations.

Comment. Although the CANDE solution for structural responses is based on either short-term or long-term properties (depending on choice of LOADT), both short-term and long-term properties must be input (or defaulted) for each problem. This is because the both the short-term and long-term properties are used in the evaluation of the plastic pipe performance in terms of design criteria.


Although most plastics exhibit significant time-dependent stress-strain response, it is customary to treat them as elastic materials with a modulus dependent on load duration. Short-term properties are appropriate for shallow burial situations wherein live loads dominate. Long-term properties are suitable to deep burial conditions wherein design life for soil weight is on the order of 50 years. The table below shows the range of short-term and long-term properties for three common types of plastics used as culverts and storm chambers. Default values are in parenthesis. Sometimes it is wise to run the same problem twice, once with short term and once with long-term properties.

Proceed to B-3 Analysis or B-3 Design

Table 5.4-3 – Plastic: Typical range of plastic properties from AASHTO LRFD Specification

Type of plastic	Effective Young's Modulus (PE) (see Figure 5.4-5)		Ultimate strength (PU) (see Figure 5.4-5)	
	Short-term (ksi)	Long-term (ksi)	Short-term (ksi)	Long-term (ksi)
HDPE – High Density Polyethylene	80.0 -112.0 (110.0)	22.0 (22.0)	3.00 (3.00)	0.85 – 1.44 (0.90)
PVC – Polyvinyl Chloride	400.0 (400.0)	135.0 – 158.0 (140.0)	6.00 – 7.00 (6.00)	2.60 – 3.70 (2.60)
PP – Polypropylene	125.0 – 145.0 (135.0)	31.0 (31.0)	3.10 (3.10)	0.95-1.05 (1.00)

Figure 5.4-5 - Plastic – Elastic stress-strain model for plastic in tension and compression, short term and long term loading



5.4.4.3 B-3 – Plastic – Cross Sectional Properties for Smooth or General

B-3.Plastic.A.Smooth**Cross-sectional properties of plastic wall for smooth or general.**

Use if	Comments
A-2.PTYPE = 'PLASTIC'	One or more pipe groups are Plastic.
A-1.XMODE = 'ANALYS'	This command is only applicable if the 'Design/Analysis' parameter is set to 'ANALYS' NOTE: This input is not valid for 'DESIGN'
B-1.Plastic.WTYPE = 'SMOOTH' or 'GENERAL'	This input line is for cases where the 'Wall Section Type' is either 'SMOOTH' or 'GENERAL'.

Parameter (columns) (format) (units)	Input Options	Description
Total height of wall cross section. (PT) (11-20) (F10.0) (inches)	Total height of wall cross section. (No default)	For the case of a SMOOTH wall type, PT is the wall thickness. This completes smooth wall input. For the case of the GENERAL wall type, PT is the profile height from the inner most fiber to outer most fiber.
Area of general wall-section per unit length of pipe (PA) (21-30) (F10.0) (in ² /in)	Area of general wall-section per unit length of pipe (No default)	For the case of the GENERAL wall type PA is the wall cross-sectional area per unit length of pipe, which provides resistance to hoop (or column) compression or tension. (PA need not be input for smooth walls) This input only applies for 'Wall Type (B3.Plastic.WTYPE) = 'GENERAL''
Moment of inertia of general wall section/unit length (PI) (31-40) (F10.0) (in ⁴ /in)	Moment of inertia of general wall section per unit length (No default)	For the case of the GENERAL wall type PI is the wall moment inertia per unit length of pipe, which provides resistance to ovaling (or bending) deformation. (PI need not be input for smooth walls) This input only applies for 'Wall Type (B3.Plastic.WTYPE) = 'GENERAL''
Distance to general wall centroid from inner wall. (PC) (41-50) (F10.0) (inches)	Distance to general wall centroid from inner wall. Default = PT/2	For the case of the GENERAL wall type PC measures the distance from the inner fiber to the geometric centroid of the general wall. The value is used to compute maximum fiber stresses. (PC not needed for smooth walls) This input only applies for 'Wall Type (B3.Plastic.WTYPE) = 'GENERAL''

For LRFD = 0, Part B is complete for Analysis of SMOOTH or GENERAL walls.

For LRFD = 1, Proceed to line B-4

5.4.4.4 B-3 – Plastic – Profile Wall Cross Sectional Properties-1

B-3.Plastic.A.Profile**Cross-sectional properties of plastic wall for wall type Profile**

Use if	Comments
A-2.PTYPE = 'PLASTIC'	One or more pipe groups are Plastic.
A-1.XMODE = 'ANALYS'	This command is only applicable if the 'Design/Analysis' parameter is set to 'ANALYS' NOTE: This input is not valid for 'DESIGN'
B-1.Plastic.WTYPE = 'PROFILE'	This input line is for cases where the 'Wall Section Type' is 'PROFILE'.


Parameter (columns) (format) (units)	Input Options	Description
Length of profile period (PERIOD) (01-10) (F10.0) (inches)	Length of generic Profile period. Default = none	PERIOD = horizontal distance of the repeating profile shape along the pipe's length as shown in Figure 5.4-6. The repeating profile shape always includes two web elements.
Total height of profile section (HEIGHT) (11-20) (F10.0) (inches)	Total height of profile section. Default = none	HEIGHT is the distance from the inner most fiber to the outer most fiber. See Figure 5.4-6.
Web angle with the horizontal (WEBANG) (21-30) (F10.0) (degrees)	Web angle measured from the horizontal. Default = 90 degrees	The orientation of the two web elements are mirror symmetric with their inclination defined by the web angle, measured from the horizontal. See Figure 5.4-6. By themselves, the two webs may be used to form a saw-tooth profile.
Web thickness (WEBT) (31-40) (F10.0) (inches)	Web Thickness Default = none	Web thickness is measured normal to web surface (web thickness is independent of the web angle).
Web "k" value for edge support coefficient (WEBK) (41-50) (F10.0) (dimensionless)	The web "k" value for the edge support coefficient. Default = 4.0	The web's k-value is used for local buckling computations. The k-value may be taken as 4.0 for elements with both edges supported by other elements. For a freestanding element with only one edge supported, the k-value is 0.43.

Parameter (columns) (format) (units)	Input Options	Description
Number of horizontal elements in profile (NHEL) (51-55) (15) (integer)	Number of horizontal elements that are to be included in profile Minimum = 0 Maximum = 4 Default = 0	Various profile shapes may be constructed by including up to four horizontal elements (or element pairs) attached to the web. For example, set NHEL = 2 to form a straight rib or unlined corrugated profile; NHEL = 3 for a T-rib or lined profile; NHEL = 4 for a box-like or trapezoidal-shaped profile.
Include local buckling calculations (LOCALB) (56-60) (15) (integer)	Code for local buckling = 1, include local buckling calculations. = -1, ignore local buckling calculations. Default = 1	If local buckling is activated (LOCALB=1), the cross-sectional properties are reduced for each beam element that experiences thrust strain above the threshold value that causes local buckling. If LOCALB = -1, local buckling is not activated and cross-section properties remain constant.

If NHEL > 0, Proceed to Line B-3b, repeat as needed

If NHEL = 0 and LRFD = 1, Proceed to Line 4B.

Otherwise, Set B is complete.

Figure 5.4-6 – Example Profile Shapes that can be constructed in CANDE

5.4.4.5 B-3b – Plastic – Cross Sectional Properties (2) (Profile)

B-3b.Plastic.A.Profile

Additional cross-sectional properties of plastic wall for wall type Profile.

Note: This command is only required if the ‘Number of Horizontal Elements’ (NHEL) is greater than zero. Repeat line B-3b for each horizontal element (NHEL times).

Use if	Comments
A-2.PTYPE = ‘PLASTIC’	One or more pipe groups are Plastic.
A-1.XMODE = ‘ANALYS’	This command is only applicable if the ‘Design/Analysis’ parameter is set to ‘ANALYS’ NOTE: This input is not valid for ‘DESIGN’
B-1.Plastic.WTYPE = ‘PROFILE’	This input line is for cases where the ‘Wall Section Type’ is ‘PROFILE’.
B-3.Plastic.A.Profile.NHEL >0	This input line is required for each horizontal element specified by NHEL.

Parameter (columns) (format) (units)	Input Options	Description
Element identifier (IDENT(I)) (01-05) (15) (integer)	Horizontal element identification number = 1, inner wall valley = 2, inner wall liner = 3, outer wall crest = 4, outer wall link Default = none	Identification number of the horizontal element being added to the profile configuration whose length, width and edge condition are defined in the following entries. Note, Line B-3b is repeated for the number of specified horizontal elements, i.e., NHEL times. See Figure 5.4-6.
Length (XLONG(I)) (06-15) (F10.0) (inches)	Full length of horizontal element. Default = 0.0	The length of the valley (#1) or crest (#3) element includes the overlapping distance of the web thicknesses. The length of the liner (#2) or link (#4) element does not include the web thicknesses. See Figure 5.4-6.
Thickness (THICK(I)) (16-25) (F10.0) (inches)	Thickness of horizontal element. Default = 0.0	Uniform thickness of the current element. The thicker the element the more it resists local buckling.
Edge support coeff (EDGEK(I)) (26-35) (F10.0) (dimensionless)	The so-called “k” value for the edge support coefficient. Default = 4.0	The k-value may be taken as 4.0 for elements with both edges supported by other elements. For a freestanding element with only one edge supported, the k-value is 0.43. See comments below.

Comment on Section Properties. CANDE uses the web and horizontal element input data to calculate the cross-sectional area per inch, the moment of inertia per inch, and the distance to the neutral axis measured from the inner fiber. The computed properties are displayed in the CANDE output.

Comment on Local Buckling. CANDE uses AASHTO Equations 12.12.3.5.3c to determine if the thrust strain induces local buckling in the web and/or horizontal profile elements. If so, the cross-sectional properties are appropriately reduced, which results in increased stresses due to loss of effective area. Subsequent load steps utilize the reduced section properties, which in turn can lead to an increased rate of local buckling. Every element of the pipe group is examined to determine its individual state of local buckling.

If LRFD = 1, Proceed to Line 4B.

Otherwise, Set B is complete

5.4.4.6 B-3 – Plastic – Safety Factors for Working Stress Design

B-3.Plastic.D.WSD**Working Stress safety factors and performance requirements.**

Use if	Comments
A-2.PTYPE = 'PLASTIC'	One or more pipe groups is Plastic
A-1.XMODE = 'DESIGN'	This command is only applicable if the 'Design/Analysis' parameter is set to 'DESIGN'
B-1.Plastic.WTYPE = 'SMOOTH'	This input line is for cases where the 'Wall Section Type' is 'SMOOTH'.
A-1.LRFD = 0	This is command is input for service design (WSD).

Parameter (columns) (format) (units)	Input Options	Description
Safety factor – maximum thrust stress (PFS(1)) (01-10) (F10) (--)	Desired safety factor against maximum thrust stress (PULT) Default = 2.0	Maximum thrust stress is the average stress over the cross section (not extreme fiber stress). This safety factor guards against material failure of entire cross section. The default safety factor is typically used.
Safety factor – global buckling (PFS(2)) (11-20) (F10) (--)	Desired safety factor against global buckling. Default = 3.0	This safety factor guards against the thrust stress exceeding global buckling capacity. If IBUCK = 2, Buckling capacity is determined by large deformation theory in CANDE. Otherwise buckling capacity is determined by the simplified AASHTO equation.
Safety factor – excessive outer fiber straining (PFS(3)) (21-30) (F10) (--)	Desired safety factor against excessive outer fiber straining Default = 2.0	This safety factor protects against excessive straining in outer fibers (tension or compression) wherein excessive strain is defined as the minimum of 1.5(PULT/PE) or 5%. Typical PFS range is 1.5 to 2.5
Allowable percent deflection (ADISP) (31-40) (F10.0) (%)	Allowable deflection percent (Default = 5%)	Allowable deflection is measured as percent of the average vertical diameter, typically taken as 5%. For automated design, the allowable displacement is used as a performance limit.

Parameter (columns) (format) (units)	Input Options	Description
Allowable maximum tensile strain (TSTRN) (41-50) (F10.0) (in/in)	Allowable maximum tensile strain: (Default = 0.05 in/in)	Allowable maximum tensile strain is intended to limit crazing or cracking. Currently AASHTO specifies the allowable long-term strain as 0.05 for HDPE. For automated design, the allowable tensile strain is used as a performance limit.

Comment: CANDE's working-stress automated design methodology will determine the required smooth-wall thickness such that the controlling desired safety factor nearly matches the corresponding actual safety factor. The remaining actual safety factors will be equal to or greater than the corresponding desired safety factors. Also the selected wall thickness will limit the maximum displacement and tensile strain to be less than or equal to the allowable limits.

**If XMODE = DESIGN and LRFD = 0, Part B is now complete.
Go to Part C (or return to line A-2 if more pipe groups need to be defined).**

5.4.4.7 B-3 – Plastic – Design Weights for LRFD

B-3.Plastic.D.LRFD**Design weights for LRFD – Smooth wall.**

The specification of the WLRFD design weights has the following consequences:

- WLRFD = 1.0, Standard LRFD (factored resistance = factored loads)
- WLRFD > 1.0 More conservative (factored resistance > factored loads)
- WLRFD < 1.0 Less conservative (factored resistance < factored loads)
- WLRFD = -1.0 Exclude the corresponding design criterion

Use if	Comments
A-2.PTYPE = 'PLASTIC'	One or more pipe groups is Plastic
A-1.XMODE = 'DESIGN'	This command is only applicable if the 'Design/Analysis' parameter is set to 'DESIGN'
B-1.Plastic.WTYPE = 'SMOOTH'	This input line is for cases where the 'Wall Section Type' is 'SMOOTH'.
A-1.LRFD = 1	This is command is input for LRFD design.

Parameter (columns) (format) (units)	Input Options	Description
Wall area failure due to maximum thrust (WLRFD(1)) (01-10) (F10.0) (--)	Wall area failure due to maximum thrust stress (Default weight = 1)	Controls the factored thrust stress loading to be less than the factored-material-strength resistance times this weight. Typically this weight is always 1 for plastic structures. See comment below.
Global buckling due to thrust stress (WLRFD(2)) (11-20) (F10.0) (--)	Global buckling due to thrust stress (Default weight = 1)	Controls the factored thrust stress loading to be less than the factored-global-buckling resistance times this weight. Typically this weight is always 1 for plastic structures.
Combined strain limit on outer surfaces (WLRFD(3)) (21-30) (F10.0) (--)	Combined strain limit on outer surfaces (Default weight = 1)	Controls the maximum wall-surface strain from thrust and bending due to factored loads to be less than the factored limiting strain resistance.
Service deflection limit (WLRFD(4)) (31-40) (F10.0) (--)	Service deflection limit (Default weight = 1)	Controls the service load vertical deflection to be less than the allowable limit. Typically this weight = 1 when used with 5%, allowable deflection.

Parameter (columns) (format) (units)	Input Options	Description
Service tensile stain limit (WLRFD(5)) (41-50) (F10.0) (--)	Service tensile stain limit (Default weight = 1)	Controls the maximum tensile strain to be less than the allowable limit under service load. Typically this weight = 1.

Comment: The above design weights give the designer control over the degree of conservatism for the LRFD process. By choosing the design weights = 1, CANDE will determine the required smooth-wall thickness such that the controlling factored load nearly matches the corresponding factored resistance. If, however, a designer desires a 25% more conservative design solution against, say for global buckling, the designer may specify $WLRFD(2) = 1.25$. Any design criterion is excluded by setting the weight = -1.

Proceed to line B-4 (LRFD = 1)

5.4.4.8 B-4 – Plastic – Resistance Factors for LRFD

B-4.Plastic
Specified resistance factors for LRFD

Use if	Comments
A-2.PTYPE = 'PLASTIC'	One or more pipe groups is Plastic
A-1.XMODE = 'DESIGN' or 'ANALYS'	This command is applicable if the 'Design/Analysis' parameter is set to either 'DESIGN' or 'ANALYS'
A-1.LRFD = 1	This command is input for LRFD evaluation.

Parameter (columns) (format) (units)	Input Options	Description
Resistance factor for thrust stress yielding (PHI(1)) (01-10) (F10.0) (--)	Resistance factor for wall area yielding due to thrust stress (Default = 1.0)	Factored thrust stress resistance = PHI(1) x PYIELD.
Resistance factor for global buckling (PHI(2)) (11-20) (F10.0) (--)	Resistance factor for global buckling due to thrust stress (Default = 1.0)	Factored global buckling resistance = PHI(2) x Buckling-Capacity. If IBUCK = 2, Buckling capacity is determined by large deformation theory in CANDE. Otherwise buckling capacity is determined by the simplified AASHTO equation.
Resistance factor for limiting stain (PHI(3)) (21-30) (F10.0) (--)	Resistance factor for limiting stain (Default = 1.0)	Factored limiting strain resistance = PHI(3) x 1.5 x (PULT/PE)
Allowable percent deflection under service load (ADISP) (31-40) (F10.0) (%)	Allowable percent deflection under service load. (Default = 5%)	Allowable vertical deflection is percent of average diameter, typically taken as 5%. CANDE estimates the service load deflections by dividing by the specified load factors.
Allowable maximum tensile strain under service load (TSTRN) (41-50) (F10.0) (in/in)	Allowable maximum tensile strain under service load conditions. (Default = 0.05 in/in)	Allowable maximum tensile strain is specified by AASHTO as 0.05 for HDPE. CANDE estimates the service load strains by dividing by the specified load factors.

Comment: The above resistance factors and service limits are used for both the design and analysis modes. In the analysis mode CANDE will show the numerical values of the above factored resistances along with the corresponding factored responses as well as the service limits along with the corresponding service responses.

In the design mode, the designer is given additional control on the previous page to design with more or less conservatism and to permit turning on or off any of the criterion to fit the problem at hand.

**This completes the current B-set input for PLASTIC.
Go to Part C (or return to line A-2 if more pipe groups need to be defined).**

5.4.5 Steel Pipe Type

5.4.5.1 B-1 – Steel – Material Properties and Control


B-1.Steel
Material properties and control

Use if	Comments
A-2.PTYPE = 'STEEL'	One or more pipe groups are Steel.
A-1.XMODE = 'DESIGN' or 'ANALYS'	This command is applicable if the 'Design/Analysis' parameter is set to either 'DESIGN' or 'ANALYS'

Parameter (columns) (format) (units)	Input Options	Description
Young's modulus for steel (PE) (01-10) (F10.0) (lb/in ²)	Elastic Young's modulus of steel pipe material Default = 29x10 ⁶ psi	Linear stress-strain modulus for pipe material, see Figure 5.4-7
Poisson's ratio (PNU) (11-20) (F10.0) (--)	Poisson's ratio of pipe material Default = 0.3	Poisson's ratio is used for plane-strain formulation. This means that the effective linear modulus is $PE^* = PE/(1-PNU^2)$.
Yield stress of pipe (PYIELD) (21-30) (F10.0) (lb/in ²)	Yield Stress of pipe material Default = 33,000 psi	Stress at end of elastic range, same in tension and compression. See the bilinear stress-strain curve in Figure 5.4-7.
Yield stress of pipe seam (PSEAM) (31-40) (F10.0) (lb/in ²)	Yield strength of pipe seam Default = PYIELD	Strength of longitudinal seams in corrugations that are bolted, riveted, or welded may be less than PYIELD. For seamless pipes, PSEAM = PYIELD.
Density of steel (PDEN) (41-50) (F10.0) (lb/in ³)	Density of material Density = 0.0 lb/in ³	Applies only to Level 2 and 3. This value produces the self-weight of the steel structure in the loading schedule, (for steel, PDEN = 0.282 pci). Leave blank to ignore self-weight.

Parameter (columns) (format) (units)	Input Options	Description
Modulus of upper bilinear model (PE2) (51-60) (F10.0) (lb/in ²)	Modulus of upper portion of bilinear model. Default = 0.0 psi	This value is only used when NONLIN = 2. It is the slope of the stress-strain curve after yielding. See Figure 5.4-7. For structural grade steel, PE2 = 0.0 is recommended.
Joint slip (JOINT) (61-65) (I5) (integer)	Joint slip option: = 0, no joint slippage = 1, yes joint slippage = 2, yes with print trace Default = 0	This option allows the representation of slipping joint behavior like the so-called “key- hole slot”, wherein joint slippage is intended to reduce thrust stress. Further input is required.
Material behavior (NONLIN) (66-70) (I5) (integer)	Code to select material behavior: = 1, linear stress-strain = 2, bilinear stress- strain Default = 2	This parameter controls the material law to be used. The linear model only uses the modulus PE, whereas the bilinear model uses both PE and PE2. Recommend NONLIN = 2.
Large deformation mode (IBUCK) (71-75) (I5) (integer)	Code to select large- deformation and buckling analysis: = 0, small deformation = 1, large deformation = 2, plus buckling.	IF IBUCK = 0, small deformation theory and simplified buckling equations are used. If BUCK = 1, the pipe elements will include large deformation theory (geometric stiffness). In addition if IBUCK=2, an estimate of the remaining buckling capacity will be computed at each load step.

Proceed to line B-2

Figure 5.4-7 – Steel-1: Bilinear stress-strain parameters

5.4.5.2 B-2 – Steel – Section Properties

B-2.Steel.A
Section Properties

Use if	Comments
A-2.PTYPE = 'STEEL'	One or more pipe groups are Steel.
A-1.XMODE = 'ANALYS'	This command is ONLY applicable if the 'Design/Analysis' parameter is set to 'ANALYS'

Parameter (columns) (format) (units)	Input Options	Description
Area of pipe wall / unit length (PA) (01-10) (F10.0) (in ² /in)	Area of pipe wall section per unit length (No default)	The cross-sectional area of one corrugation period divided by the period length. See Table 5.4-4 and Table 5.4-5 for section properties of standard corrugated steel shapes.
Moment of inertia of pipe wall / unit length (PI) (11-20) (F10.0) (in ⁴ /in)	Moment of inertia of pipe wall section per unit length (No Default)	Moment of inertia of one corrugation period divided by period length. Centroid is assumed at mid-depth of cross section. See Table 5.4-4 and Table 5.4-5 for section properties of standard corrugated steel shapes.
Section modulus of pipe wall / unit length (PS) (21-30) (F10.0) (in ³ /in)	Section modulus of pipe wall per unit length. (No Default)	The section modulus is equal to the moment of inertia divided by one-half of the corrugation depth, $PI/(h/2)$.

If **JOINT > 0**, Proceed to input lines B-2b to define slotted joint parameters.

If **JOINT = 0** and **XMODE = ANALYSIS** and **LRFD = 0**, Part B is now complete.
Go to Part C (or return to line A-2 if more pipe groups need to be defined).

If **JOINT = 0** and **XMODE = ANALYSIS** and **LRFD = 1**, Proceed to line B-3

Table 5.4-4 – Steel -1: Section Properties for Standard Steel Corrugation Sizes

Corrugation Profile	Section Properties	Corrugation thickness -- inches						
		0.040	0.052	0.064	0.079	0.109	0.138	0.168
1-1/2 x 1/4	PA in ² /in	0.03800	0.05070	0.06340	0.07920	0.11090	0.14270	0.17480
	PI in ⁴ /in	0.00025	0.00034	0.00044	0.00057	0.00086	0.00121	0.00164
	PS in ³ /in	0.00172	0.00225	0.00280	0.00347	0.00479	0.00624	0.00785
2-2/3 x 1/2	PA in ² /in	0.03880	0.05160	0.06460	0.08070	0.11300	0.14530	0.17780
	PI in ⁴ /in	0.00112	0.00150	0.00189	0.00239	0.00342	0.00453	0.00573
	PS in ³ /in	0.00415	0.00543	0.00670	0.00826	0.01123	0.01420	0.01716
3 x 1	PA in ² /in	0.04450	0.05930	0.07420	0.09280	0.13000	0.16730	0.20480
	PI in ⁴ /in	0.00515	0.00689	0.00866	0.01088	0.01546	0.02018	0.02509
	PS in ³ /in	0.00990	0.01310	0.01628	0.02017	0.02788	0.03547	0.04296
5 x 1	PA in ² /in	0.00000	0.00000	0.06620	0.82670	0.11580	0.14900	0.18220
	PI in ⁴ /in	0.00000	0.00000	0.00885	0.01109	0.01565	0.02032	0.02509
	PS in ³ /in	0.00000	0.00000	0.01664	0.02056	0.02822	0.03571	0.04296

Table 5.4-5 – Steel 2 – Section Properties for 6"x 2" Structural Plate

Section Properties	Corrugation thickness -- inches								
	0.110	0.140	0.170	0.188	0.218	0.249	0.280	0.318	0.380
PA in ² /in	0.12970	0.16690	0.20410	0.22830	0.26660	0.30420	0.34330	0.38930	0.46780
PI in ⁴ /in	0.06041	0.07816	0.09616	0.10800	0.12691	0.14616	0.16583	0.19000	0.23200
PS in ³ /in	0.05726	0.07305	0.08863	0.09872	0.11444	0.12998	0.14546	0.16393	0.19496

Nomenclature

Thickness = Specified thickness of metal gage in inches

Corrugation size = nominal height x pitch measured in inches.

Nominal height = Inside valley to corrugation crest (i.e., actual height minus thickness)

Actual height = nominal height plus thickness

PA = Cross-sectional area per unit inch

PI = Moment of Inertia per unit inch

PS = Section modulus per unit inch (PI divided by one-half of actual height)

5.4.5.3 B-2 – Steel – Design Safety Factors for Working Stress

B-2.Steel.D.WSD**Design safety factors for working stress design.**

Use if	Comments
A-2.PTYPE = 'STEEL'	One or more pipe groups are Steel.
A-1.XMODE = 'DESIGN'	This command is ONLY applicable if the 'Design/Analysis' parameter is set to 'DESIGN'
A-1.LRFD = 0	This command is only applicable for working stress design.

Parameter (columns) (format) (units)	Input Options	Description
Safety factor against thrust yielding (PFS(1)) (01-10) (F10.0) (--)	Desired safety factor against thrust yielding; (Default = 2.0)	Safety factor protects against excessive thrust force causing steel material yielding of the entire cross-section (tension or compression). Typical PFS range is 2.0 to 3.0
Safety factor against global buckling (PFS(2)) (11-20) (F10.0) (--)	Desired safety factor against global buckling. (Default = 2.0)	Safety factor protects against excessive thrust force causing global buckling of the pipe's walls in soil-structure system. Typical PFS range is 2.0 to 3.0
Safety factor against seam failure due to thrust stress (PFS(3)) (21-30) (F10.0) (--)	Desired safety factor against seam failure due to thrust stress (Default = 2.0)	Safety factor protects against excessive thrust force causing seam failure. For seamless pipe this is equal to material yielding, PFS = 2.0. For structural plate, recommend PFS = 3.0
Safety factor against full plastic hinge penetration (PFS(4)) (31-40) (F10.0) (--)	Desired safety factor against full plastic hinge penetration (Default = 3.0)	Safety factor protects against excessive plastic hinge penetration from thrust and bending. PFS = (100% depth)/(% allowable depth). Thus, for 33% allowable penetration, PFS= 3.0
Maximum allowable vertical deflection (ADISP) (41-50) (F10.0) (%)	Maximum allowable vertical deflection percentage (Default = 5%)	ADISP is the maximum allowable percentage of vertical deflection with respect to the vertical height. For pipes and pipe arches, 5% of the vertical height is typical. For long-span structures, 2% of total rise is typical

Comment: The working–stress design output provides a list of corrugation sizes along with the required metal thickness to meet the above design criteria. CANDE determines the design output by performing a series of analyses beginning with a trial cross-section and successively modifying it after each analysis until the specified safety factors are satisfied in an optimum manner. CANDE selects the least weight corrugation for a final analysis and evaluation.

If JOINT > 0, Proceed to input lines B-2b to define slotted joint parameters.

**If JOINT = 0 and XMODE = DESIGN and LRFD = 0, Part B is now complete.
Go to Part C (or return to line A-2 if more pipe groups need to be defined).**

If JOINT = 0 and XMODE = DESIGN and LRFD = 1, Proceed to line B-2 (next)

5.4.5.4 B-2 – Steel – Design Weights for LRFD

B-2.Steel.D.LRFD**Design weights for LRFD**

Design weights for LRFD limit states, typically all WLRFD = 1 (default)

The specification of the WLRFD design weights has the following consequences:

- WLRFD = 1.0, Standard LRFD (factored resistance = factored loads)
- WLRFD > 1.0 More conservative (factored resistance > factored loads)
- WLRFD < 1.0 Less conservative (factored resistance < factored loads)
- WLRFD = -1.0 Exclude the corresponding design criterion

Use if	Comments
A-2.PTYPE = 'STEEL'	One or more pipe groups are Steel.
A-1.XMODE = 'DESIGN'	This command is ONLY applicable if the 'Design/Analysis' parameter is set to 'DESIGN'
A-1.LRFD = 1	This command is only applicable for LRFD design.

Parameter (columns) (format) (units)	Input Options	Description
Wall area failure due to maximum thrust stress (WLRFD(1)) (01-10) (F10.0) (--)	Wall area failure due to maximum thrust stress (Default weight = 1)	The design goal is to determine the corrugated wall area so that the weighted-factored-thrust-stress is just less than the factored-yield-strength-resistance of steel.
Global buckling due to thrust stress (WLRFD(2)) (11-20) (F10.0) (--)	Global buckling due to thrust stress (Default weight = 1)	The design goal is to determine the corrugated wall moment of inertia so that the weighted-factored-thrust-stress is just less than the factored-thrust-resistance for global buckling.
Seam failure due to thrust stress (WLRFD(3)) (21-30) (F10.0) (--)	Seam failure due to thrust stress (Default weight = 1)	The design goal is to determine the corrugated wall area so that the weighted-factored-thrust-stress is just less than the factored-yield-strength-of longitudinal seams
Cross-section failure due to plastic penetration (WLRFD(4)) (31-40) (F10.0) (--)	Cross-section failure due to plastic penetration. (Default weight = 1)	The design goal is to determine the corrugated wall moment of inertia so that the weighted-factored-plastic-penetration due to thrust and bending is less than the factored-complete-plastic wall penetration. **

Parameter (columns) (format) (units)	Input Options	Description
Service deflection limit (WLRFD(5)) (41-50) (F10.0) (--)	Service deflection limit (Default weight = 1)	The design goal is to determine the corrugated wall moment of inertia so that the weighted-service-load deflection is less than or equal to the allowable deflection.

Comment: Similar to the working-stress approach, the above design weights give the designer control over the degree of conservatism for the LRFD process. By choosing the design weights = 1, CANDE will determine the required corrugation size and thickness such that the controlling factored load nearly matches the corresponding factored resistance. If, however, a designer desires a 25% more conservative design solution against global buckling, the designer may specify $WLRFD(2) = 1.25$. Alternatively, a designer may exclude any design criterion that does not apply to the problem at hand by setting the corresponding design weight = -1.

** Limiting the plastic penetration in corrugated metal is a newly proposed strength criterion that replaces the ineffectual plastic moment criterion for metal box culverts

**If JOINT > 0, Proceed to input lines B-2b to define slotted joint parameters.
Otherwise, proceed to line B-3 (LRFD = 1)**

5.4.5.5 B-2b – Steel – Joint Properties

B-2b.Steel
Joint properties


Use if	Comments
A-2.PTYPE = 'STEEL'	One or more pipe groups are Steel.
B-1.Steel.JOINT > 0	Only enter this command if the value for 'Joint Slip (JOINT)' entered on the B-1 command is greater than 0
A-1.XMODE = 'DESIGN' or 'ANALYS'	This command is applicable if the 'Design/Analysis' parameter is set to 'DESIGN' or 'ANALYS'.
A-1.LRFD = 0 or 1	This command is applicable for both Service and LRFD design.
A-1.LEVEL = 1, 2, or 3	This command is applicable for ALL solution levels.

Parameter (columns) (format) (units)	Input Options	Description
Thrust stress at initial joint slippage (PSLIP) (01-10) (F10.0) (lb/in ²)	Thrust stress at initial joint slippage. Default = 4,950 psi	The default value of 4,950 psi is based on experimental tests and is recommended for the "keyhole slots" tightened with standard bolt torque. See Figure 5.4-8.
Thrust stress at initial joint yielding (PFAIL) (11-20) (F10.0) (lb/in ²)	Thrust stress at initial yielding of joint material Default = 33,000 psi	The default value of 33,000 psi is based on experimental tests and is recommended for the 8 gauge steel plates or heavier. Lighter gauges (e.g., #10 or #12) may require a lower value.
Ratio of slipping modulus to elastic steel modulus (RPES) (21-30) (F10.0) (--)	Ratio of slipping modulus to elastic steel modulus Default = 0.0003	The slipping behavior of keyhole slots is not perfectly plastic, but rather exhibits a slight hardening slope = 0.0003 x PE. Thus, RPES = 0.0003 is recommended. See Figure 5.4-8.
Ratio of post-slipping modulus to elastic steel modulus (RPEP) (31-40) (F10.0) (--)	Ratio of post-slipping modulus to elastic steel modulus. Default = 0.5	Post slipping behavior prior to material yielding typically exhibits a hardening slope less than 0.5 x PE. Thus, RPEP = 0.5 is conservative and recommended for design. See Figure 5.4-8.

Parameter (columns) (format) (units)	Input Options	Description
Ratio of yielding zone modulus to elastic steel modulus (RPEF) (41-50) (F10.0) (--)	Ratio of yielding zone modulus to elastic steel modulus Default = 0.0	When the joint thrust stress reaches yield, the joint typically behaves perfectly plastic so that RPEP = 0.0 is recommended. See Figure 5.4-8.
Slot travel length (SLOTL) (51-60) (F10.0) (inches)	Slot travel length Default = 1.0 in	This is the net distance the two plates can slip relative to each other prior to slot closure. For standard keyhole slots, a travel length of 1.0 inch is recommended.
Number of joints in this pipe group (NUMJ) (61-65) (I5) (integer)	Total number of joints in this pipe group. Max = 15. Default = 1	This is the actual number of joints (longitudinal seams) in the pipe-group model. The model for Level 1 is the whole circular pipe, whereas Level 2 is modeled using a symmetric half shape. For Level 1, NUMJ is the number of joints around the full circumference. See comment for Level 2.
Vary joint travel length (JSLTLR) (66-70) (I5) (integer)	Option to vary joint travel length around the pipe periphery. = 0, same lengths = 1, different lengths	This option applies to solution levels 2 & 3. One main utility of this option is to model “half joints”. This occurs in level 2 meshes when the axis of symmetry cuts through a joint at the crown or invert, which produces a half-joint with the same properties as a full joint except the slot length is one-half its full value.

If Level = 1 and LRFD = 0, B-input data is complete.

For Level 2 & 3, complete lines B-2c and B-2d on the next page.

Figure 5.4-8 – Steel-2 – Pseudo stress-strain model for slotted joints

5.4.5.6 B-2c – Steel – Joint Locations and Properties

B-2c.Steel
Joint locations and properties

Use if	Comments
A-2.PTYPE = 'STEEL'	One or more pipe groups are Steel.
B-1.Steel.JOINT > 0	Only enter this command if the value for 'Joint Slip (JOINT)' entered on the B-1 command is greater than 0
A-1.XMODE = 'DESIGN' or 'ANALYS'	This command is applicable if the 'Design/Analysis' parameter is set to 'DESIGN' or 'ANALYS'.
A-1.LRFD = 0 or 1	This command is applicable for both Service and LRFD design.
A-1.LEVEL = 2, or 3	This command is applicable ONLY for solution levels 2 and 3.

Parameter (columns) (format) (units)	Input Options	Description
Pipe element sequence number for first joint (JLOC(1)) (01-04) (I4) (integer)	Pipe element sequence number containing first joint (No Default)	JLOC(1) = local element sequence number that identifies the pipe element containing the first joint. Level 2 elements are numbered clockwise starting with no.1 at the crown
Pipe element sequence number for second joint (JLOC(2)) (05-08) (I4) (integer)	Pipe element sequence number containing second joint. (No Default)	JLOC(2) = local element sequence number that identifies the pipe element containing the second joint.
• • •		
Pipe element sequence number for last joint (JLOC(NUMJ)) (xx-xx) (I4) (integer)	Pipe element sequence number containing last joint	JLOC(NUMJ) = local element sequence number that identifies the pipe element containing the last joint. The format for column data is up to 15 fields of I4 integers.

Comment: The above local element numbers locate where the slipping joints are located in the pipe's circumference. Consider, for example, a circular pipe with a total of four slipping joints that are located near the crown, invert and each spring line. If we simulate this system with the Level 2 – Pipe mesh, which is a 10 element half-pipe mesh, then we would set $NUMJ = 3$ representing the sum of one spring line joint plus one crown half joint plus one invert half joint (mirror symmetric system).

Accordingly, we would set $JLOC(1) = 1$ (representing crown joint), $JLOC(2) = 5$ or 6 (representing spring line joint) and $JLOC(3) = 10$ (representing invert joint).

As a side note, Level 1 is not sensitive to the location of the joints only the total joint travel path, which is $NUMJ * SLOTL$. For Level 1, $NUMJ$ is the number of joints around the full circumference.

If half joints are to be modeled ($JSLTLR = 1$) complete line B-2d.

Otherwise input is complete unless $LRFD = 1$ wherein you proceed to line B-3.

5.4.5.7 B-2d – Steel – Joint Locations and Properties (2)

B-2d.Steel
Joint locations and properties (2)

Use if	Comments
A-2.PTYPE = 'STEEL'	One or more pipe groups are Steel.
B-1.Steel.JOINT > 0	Only enter this command if the value for 'Joint Slip (JOINT)' entered on the B-1 command is greater than 0
B-2b.Steel.JSLTLR = 1, different lengths	Only enter this command if the 'Vary joint travel length' parameter is equal to 'different lengths' (1).
A-1.XMODE = 'DESIGN' or 'ANALYS'	This command is applicable if the 'Design/Analysis' parameter is set to 'DESIGN' or 'ANALYS'.
A-1.LRFD = 0 or 1	This command is applicable for both Service and LRFD design.
A-1.LEVEL = 2, or 3	This command is applicable ONLY for solution levels 2 and 3.

Parameter (columns) (format) (units)	Input Options	Description
Ratio of joint/ standard length # 1 (SLOTLR(1)) (01-04) (F4.0) (--)	Ratio of joint # 1 slot length to standard length (Default = 1.0)	This ratio redefines the slot length of joint 1 = SLOTLR(1) x SLOTL. This is useful for correctly defining joints that are on lines of symmetry whose slot length is ½ of standard.
Ratio of joint/ standard length # 2 (SLOTLR(2)) (05-08) (F4.0) (--)	Ratio of joint # 2 slot length to standard length (Default = 1.0)	This ratio redefines the slot length of joint 2 = SLOTLR(2) x SLOTL
• • •		
Ratio of joint/ standard length # NUMJ (SLOTLR(NUMJ)) (xx-xx) (F4.0) (--)	Ratio of joint # NUMJ slot length to standard length (Default = 1.0)	This ratio redefines the slot length of joint NUMJ = SLOTLR(NUMJ) x SLOTL. The format for column data is up to 15 fields of F4 floating point numbers.

Comment: The above slot lengths correspond to the specific element numbers defined for each joint in line B-2c. Following the same example defined on the previous page with $NUMJ = 3$ for a Level 2 – Pipe mesh with joints that are located near the crown, invert and each spring line, we would set $SLOTLR(1) = 0.5$ (representing crown's half-joint length), $SLOTLR(2) = 1.0$ (representing the standard length spring line joint) and $SLOTLR(3) = 0.5$ (representing invert half-joint length).

If LRFD = 0, input is complete for Steel.

If LRFD = 1, proceed to line B-3

5.4.5.8 B-3 – Steel – Resistance Factors for LRFD

B-3.Steel.AD.LRFD**Resistance factors for LRFD**

Use if	Comments
A-2.PTYPE = 'STEEL'	One or more pipe groups are Steel.
A-1.XMODE = 'DESIGN' or 'ANALYS'	This command is applicable if the 'Design/Analysis' parameter is set to 'DESIGN' or 'ANALYS'.
A-1.LRFD = 1	This command is ONLY applicable for LRFD design.
A-1.LEVEL = 1, 2, or 3	This command is applicable for ALL solution levels.

Parameter (columns) (format) (units)	Input Options	Description
Resistance factor for thrust stress yielding (PHI(1)) (01-10) (F10.0) (--)	Resistance factor for wall area yielding due to thrust stress (Default = 1.0)	Factored thrust stress resistance = $\text{PHI}(1) \times \text{PYIELD}$. Choosing $\text{PFS}(1) = 1$ is generally recommended
Resistance factor for global buckling (PHI (2)) (11-20) (F10.0) (--)	Resistance factor for global buckling due to thrust stress (Default = 1.0)	Factored global buckling resistance = $\text{PHI}(2) \times \text{Buckling-Capacity}$. Buckling capacity is determined by large deformation theory in CANDE if $\text{IBUCK} = 2$. Otherwise simplified buckling equations are used.
Resistance factor for seam strength due to thrust stress (PHI (3)) (21-30) (F10.0) (--)	Resistance factor for Seam strength due to thrust stress (Default = 1.0)	Factored seam strength resistance = $\text{PHI}(3) \times \text{PSEAM}$. For metal structures with longitudinal seams, set $\text{PHI}(3) = 0.67$
Resistance factor for plastic-penetration (PHI (4)) (31-40) (F10.0) (--)	Resistance factor for cross-section capacity for plastic-penetration (Default = 0.90)	Factored cross-section capacity resistance = $\text{PHI}(4) \times 100\%$ of cross-section depth. This criterion applies to the percentage of cross-section that becomes plastic due to both thrust and bending stresses.**

Parameter (columns) (format) (units)	Input Options	Description
Allowable deflection at service load (DISP) (41-50) (F10.0) (%)	Allowable deflection at service load (Default = 5%)	Allowable deflection is the relative vertical deflection, typically taken as 5% of vertical diameter or rise. For long-span structures, allowable deflection is 2% total rise. The criterion applies to service loading conditions, which is approximated by reducing the predicted displacements by the load factors.

Comment: The above resistance factors are used for both the design and analysis modes. In the analysis mode CANDE will show the five numerical values of the above factored resistances along with the corresponding factored responses.

In the design mode, the designer is given additional control on line B-2 to design with more or less conservatism or turn off any of the criterion to fit the problem at hand.

** Limiting the plastic penetration in corrugated metal is a newly proposed strength criterion that replaces the ineffectual plastic moment criterion for metal box culverts. It is suggested that designers evoke this criterion for all metal culverts.

This completes the current B-set input for STEEL.

Go to Part C (or return to line A-2 if more pipe groups need to be defined).

5.5 Part C- Solution Levels

This section provides input instructions for the chosen solution level. The solution level input is specified in command A-1 (see Section 5.3.1 A-1 – Master Control Input Data) with further selection for level 2 options specified in command A-2 (see 5.3.2 A-2 –Pipe Selection). Based on this input, go to one of the following sections:

- Solution Level 1
- Solution Level 2 – Pipe
- Solution Level 2 – Box
- Solution Level 2 – Arch
- Solution Level 3

5.5.1 Solution Level 1

5.5.1.1 C-1 – Level 1 – Major Input Parameters

C-1.L1
Major input parameters

Use if	Comments
A-1.LEVEL = 1	Use ONLY if the ‘Solution Level’ is set to 1.


Parameter (columns) (format) (units)	Input Options	Description
Average diameter of pipe (PDIA) (01-10) (F10.0) (inches)	Average diameter of pipe No Default	$PDIA = (OD + ID)/2$, average diameter from mid wall to mid wall. This applies to all circular pipe types in deep burial installations. See Figure 5.5-1 as a conceptual illustration of the boundary value problem.
Soil density of backfill material (SDEN) (11-20) (F10.0) (lb/ft ³)	Soil density of backfill material No default	Average density of soil placed over the pipe. A typical range of soil density is 100 to 140 pcf. CANDE uses soil density to assign increments of overburden pressure to the pipe-soil system.
Number of load steps (NINC) (21-25) (I5) (integer)	Number of soil lifts (load steps) Default = 1	NINC permits the placement of up to 10 intermediate layers of soil up to the final soil cover height above the crown. This, in turn, will permit the change of soil stiffness properties as a function of the current fill height in line C-2.
Pipe-soil interface (ISLIP) (26-30) (I5) (integer)	Code to specify the pipe-soil interface bonding = 0, fully bonded (no slip) = 1, frictionless (full slip) Default = 0	Level 1, based on the Burns and Richard elasticity solutions, permits the selection of two pipe-soil interface conditions. For ISLIP = 0, the interface is fully bonded so that both normal and shear forces are transmitted across the interface. For ISLIP = 1, the interface is frictionless so that only normal forces are transmitted across the interface. It is generally recommended to use ISLIP = 0 to be conservative in assessing pipe distress.

Comment: Level 1 is based on the Burns and Richard elasticity solution for a deeply buried circular pipe in an ideal homogenous soil system wherein the fill height above the crown is at least 2 pipe diameters. See Figure 5.5-1 as a conceptual illustration of the boundary value problem. Level 1 is not appropriate for shallow covers or simulating concentrated live loads.

Although the Burns and Richards solution is based on linear elasticity, CANDE provides a pseudo nonlinear representation in two ways. First, the soil stiffness may change with each load step to reflect the

fact that soil tends to get stiffer as the overburden pressure increases. Second, CANDE uses an average of pipe stiffness values around the pipe, which may change from load step to load step, as determined from the nonlinear pipe-type models.

Proceed to line C-2

Figure 5.5-1 – Level 1 – Illustration of Level 1 boundary value problem

5.5.1.2 C-2 – Level 1 – Fill Heights and Soil Parameters

C-2.L1**Fill heights and soil parameters**

Line C-2 (Repeat line C-2 for each load step, 1 to NINC)

Use if	Comments
A-1.LEVEL = 1	Use ONLY if the ‘Solution Level’ is set to 1.
C-1.L1.NINC times.	Repeat this line for each load step (NINC).

Parameter (columns) (format) (units)	Input Options	Description
Soil height (HT(I)) (01-10) (F10.0) (ft)	Soil height above crown for load step I (No Default)	HT(I) = current soil height for which the soil properties specified below will apply. For subsequent entries it is required that HT(I+1) > HT(I), and HT(NINC) = final fill height. The incremental overburden pressure for any load step I = SDEN x (HT(I) – HT(I-1)). Thus, the current total overburden pressure at load step I = SDEN x HT(I)
Young’s Modulus (SEH(I)) (11-20) (F10.0) (lb/in ²)	Young’s modulus of soil in vicinity of pipe for load step I (No default)	As a general rule the Young’s modulus of soil increases as current total overburden pressure increases. Table 5.5-1 provides guidance for specifying Young’s modulus dependent on soil class, initial compaction effort, and the overburden pressure.
Poisson’s ratio (SVH(I)) (21-30) (F10.0) (--)	Poisson’s ratio of soil in vicinity of pipe for load step I (No default)	See Table 5.5-1 for guidance on specifying Poisson’s ratio. A typical value for all soil is 0.33

If LRFD = 0, the input for this CANDE run is complete. Enter a STOP command (see line A-1) if no additional CANDE problems are to be included in this input file.

Table 5.5-1 – Level 1 – Conservative values for Young’s soil modulus and Poisson’s ratio

Soil Class→ Compaction→	Granular		Mixed		Cohesive	
	Good	Fair	Good	Fair	Good	Fair
Overburden Pressure psi	Young’s Modulus psi	Young’s Modulus psi	Young’s Modulus psi	Young’s Modulus psi	Young’s Modulus psi	Young’s Modulus psi
5	1,100	550	600	400	250	150
10	1,300	750	850	550	325	200
15	1,500	850	1,000	600	375	225
20	1,650	1,000	1,100	700	375	250
25	1,800	1,100	1,200	750	400	250
30	1,900	1,150	1,250	800	400	250
40	2,100	1,300	1,350	900	400	250
50 & above	2,250	1,400	1,450	900	400	250
Poisson’s Ratio (all overburden)	0.30	0.35	0.30	0.38	0.33	0.40

Example use of Table. A pipe is buried under 30 feet of fill, which is classified as a Good Mixed soil weighing 144 lbs/ft³. If this fill height is applied in one load step, then for line C-2 we set HT(1) = 30 feet and compute the overburden as $30 \times 144 = 4320$ lbs/ft² or 30 psi. From the above table we find Young’s modulus, SEH(1) = 1,250 psi. Thus, we obtain a solution using one load step.

Alternatively if applied the fill height in three load steps, we would determine the following input values:

Step 1: HT(1) = 10 feet, overburden pressure 10 psi, and SEH(1) = 850 psi.

Step 2: HT(2) = 20 feet, overburden pressure 20 psi, and SEH(2) = 1,100 psi.

Step 3: HT(3) = 30 feet, overburden pressure 30 psi, and SEH(3) = 1,250 psi.

In all cases Poisson’s ratio remains constant for each load step SVH (I) = 0.3

5.5.1.3 C-3 – Level 1 – Load Factors for LRFD

C-3.L1
Load factors for LRFD: Repeat line C-3 as needed

Use if	Comments
A-1.LEVEL = 1	Use ONLY if the ‘Solution Level’ is set to 1.
C-1.L1.NINC	This line must be repeated until load factors for all load steps are defined.

Parameter (columns) (format) (units)	Input Options	Description
Starting load step (INCRS) (01–05) (15) (integer)	Starting load step number to apply the same load factor Default = 1	INCRS is the load step at which the load factor below will be applied. The first C-3 input must specify INCRS = 1. Subsequent C-3 inputs for INCRS, if needed, must specify INCRS = INCRL(previous) + 1.
Ending load step (INCRL) (06–10) (15) (integer)	Last load step number to apply the same load factor Default = INCRS	INCRL is the last load step in this sequence of load steps that share the same load factor specified below. When INCRL = NINC, the input of C-3 data is complete.
LRFD load factor (FACTOR) (11–20) (F10.0) (dimensionless)	LRFD load factor applied to the load steps INCRS through INCRL, inclusive Default = 1.00	Based on 2004 AASHTO LRFD specifications maximum load factors for vertical earth pressure on buried pipes are: Rigid pipe (concrete) = 1.30 Flexible pipe (corrugated metal and plastic) = 1.95 Level 1 is not suited for live load simulation.
Comment (COMMENT) (21–60) (A40) (words)	User supplied comments to explain load factor value Default = none	The comment, which can be up to 40 characters in length, is printed out with value FACTOR for each load step. The purpose of the comment is to document the rationale for the load factor value including load modifiers, etc.

Comment: If all load steps are assigned the same load factor, then the C-3 data need only be entered once with INCRS = 1, INCRL = NINC, and the specified FACTOR common to each increment. At the other extreme, if each load step is assigned a different load factor (for whatever reason), then the C-3 would be repeated NINC times. In this case, the first C-3 entry would be INCRS = 1, INCRL = default, and the specified FACTOR for the first load step. The second C-3 entry would be INCRS = 2, INCRL = default, and the specified FACTOR for the second load step, and so on through the last C-3 entry, which would be INCRS = NINC, INCRL = default, and the specified FACTOR for the last load step.

Level 1 is only suited for load factors associated with earth loads. See Part E for a discussion on load factors.

The input for this CANDE run is now complete.
Enter a STOP command (see line A-1)

5.5.2 Solution Level 2 – Pipe Mesh

5.5.2.1 C-1 – Level 2 – Pipe Mesh – Control Commands and Title

C-1.L2.Pipe
Control commands and title

Use if	Comments
A-1.LEVEL = 2	Use ONLY if the ‘Solution Level’ is set to 2.
A-2.NPCAN = 1 (Pipe Mesh)	Use ONLY if the ‘Canned Mesh Code’ is set to 1 (‘Pipe Mesh’).

Parameter (columns) (format) (units)	Input Options	Description
Mesh pattern (WORD) (01-04) (A4) (word)	<p>Name to select mesh pattern for soil</p> <p>= EMBA (embankment)</p> <p>= TREN (trench)</p> <p>= HOMO (homogenous)</p>	<p>Level 2 – Pipe Mesh provides an automatic finite element mesh for a circular or elliptical shaped pipe. The type of soil construction is controlled by the choice for WORD.</p> <p>For WORD = EMBA, an embankment mesh is generated as illustrated in Figure C-Level 2-1. The in-situ soil surface is at pipe’s invert and backfill soil is placed in lifts around and above the pipe. The fill soil’s lateral extent is assumed indefinitely wide.</p> <p>For WORD = TREN, a trench mesh is generated as illustrated in Figure C-Level 2-2. Any trench depth may be specified, measured from the in-situ soil surface to the pipe invert. Similarly, any trench width may be specified. Backfill soil is placed in lifts to fill the trench plus overfill.</p> <p>For WORD = HOMO, an embankment-like mesh is generated, similar to Figure C-Level 2-1, except that all the soil zones (bedding, in-situ soil, fill soil, etc.) are all assigned a common material model. That is, the entire soil system is one homogenous material to be defined by the user. This produces an idealized system similar to Level 1.</p>
Title (TITLE) (05-72) (17A4) (words)	User description of mesh to be printed with output	TITLE is a descriptive phrase up to 68 characters that will be printed with the output to describe the mesh options selected by the user.

Parameter (columns) (format) (units)	Input Options	Description
Interface elements (WORD1) (73-76) (A4) (word)	<p>A command word to add frictional interface elements to basic mesh:</p> <p>= SLIP (pipe-soil interface)</p> <p>= SLPT (trench-insitu interface)</p> <p>Default = <i>blank</i> (Interface element not added)</p>	<p>WORD1 provides options for including frictional interfaces between pipe and soil or between trench soil and in-situ soil. Default (blank) means no interface elements are added.</p> <p>For WORD1 = SLIP, the mesh is automatically altered to include eleven interface elements at the common nodes between the pipe and soil. This feature allows for frictional slippage, separation and re-bonding of the pipe-soil interface during the loading schedule. The user must subsequently input interface material properties for each of the eleven interface elements as described in Part D.</p> <p>For WORD = SLPT, the trench mesh option is automatically altered to include seven interface elements at the common nodes between the trench wall and in-situ soil starting from the spring line to the top of the trench. This feature allows the trench soil to slip along the vertical during the backfilling loading schedule. The user must subsequently input interface material properties for each of the eleven interface elements as described in Part D</p>
Make changes to the basic mesh (WORD2) (77-80) (A4) (word)	<p>A command word to subsequently make changes to basic mesh:</p> <p>= MOD (mesh will be modified)</p> <p>Default = <i>blank</i> (No modification)</p>	<p>For WORD2 = MOD, the user will have the opportunity to change the basic mesh in terms of nodal locations, element properties and prescribed loads. This is accomplished by supplying additional data in lines CX-1 through CX-4 after the basic C-1 through C-4 data is complete.</p> <p>Motivations for changing the basic mesh include: add a live load(s), simulate voids or rocks in the soil system, and to change shapes such as the bedding. The default case (no modifications) applies to many basic problems without the need for modifications.</p>

Comment: The Level 2 – Pipe Mesh generates a half mesh, symmetric about the vertical centerline, implying that all geometry and loading is mirror symmetric on both sides of the centerline. The node numbering and element connectivity remains the same for all choices of soil mesh type (WORD). The distinction between soil mesh types (EMBA, TREN or HOMO) is accomplished internally by assigning different material numbers and load step numbers to the soil elements. See Figure 5.5-2 through Figure 5.5-5 for views of all mesh topologies.

Proceed to line C-2

5.5.2.2 C-2 – Level 2 – Pipe Mesh – Major Geometry and Loading Parameters

C-2.L2.Pipe**Major geometry and loading parameters**

Use if	Comments
A-1.LEVEL = 2	Use ONLY if the 'Solution Level' is set to 2.
A-2.NPCAN = 1 (Pipe Mesh)	Use ONLY if the 'Canned Mesh Code' is set to 1 ('Pipe Mesh').

Parameter (columns) (format) (units)	Input Options	Description
Average vertical diameter of pipe (PDIA) (01-10) (F10.0) (inches)	Average vertical diameter of pipe No Default	PDIA = is the average diameter from mid wall of crown to mid wall of invert. This measure is also used to compute % vertical deflection.
Ratio of horizontal -to- vertical diameter (RDIA) (11-20) (F10.0) (--)	Ratio of horizontal -to- vertical diameter: = 1.0, circle > 1.0, h-ellipse < 1.0, v-ellipse Default = 1.0	The default value, RDIA = 1.0, defines a perfect circle with mid-depth diameter = PDIA. The horizontal distance from mid-wall spring line to mid-wall spring line = RDIA*PDIA. This produces a horizontal ellipse if RDIA > 1 or a vertical ellipse if RDIA < 1.

Parameter (columns) (format) (units)	Input Options	Description
Height of soil cover (HTCOVER) (21-30) (F10.0) (feet)	Height of soil cover as measured from: (1) Spring line for embankment mesh, or (2) From top of trench for trench mesh	<p>HTCOVER is defined differently for the embankment mesh (WORD1 = EMBA or HOMO) than it is for the trench mesh (WORD1 = TREN).</p> <p>For the embankment mesh, HTCOVER is the total fill height above the spring line level of the pipe in which the default minimum is $HTCOVER = 0.5 * PDIA + 3.0 * TPAC$. The default minimum coincides with the mesh's minimum uniform surface height. At the other extreme, if $HTCOVER > 2.0 * PDIA$, the mesh surface will be truncated at the surface height of $2.0 * PDIA$ and the remaining soil weight will be automatically applied as increments of overburden pressure for the remaining load steps.</p> <p>For the trench mesh, HTCOVER is the additional height of over-fill soil above the top of the trench. In this case the default minimum = 0.0 ft. On the other hand, if the combined trench height plus over-fill height is $> 2.0 * PDIA$, the mesh surface will be truncated at the surface height of $2.0 * PDIA$ and the remaining soil weight will be applied as increments of overburden pressure for the remaining load steps.</p>
Density of soil above truncated mesh (DENSTY) (31-40) (F10.0) (lb/ft ³)	DENSTY of soil above truncated mesh. Default = 0.0 pcf	When the mesh is truncated at $2 * PDIA$ above the spring line, the subsequent soil loading is simulated by increments of overburden pressure = (height-increment)*DENSTY. Typically the user should set DENSTY = soil density defined in Part D.

Comment: See Figure 5.5-2 through Figure 5.5-5 for view of all mesh topologies and illustration of soil height definitions for embankment and trench meshes. When interface elements are added to the mesh see Table 5.5-2 and Table 5.5-3 to see the changes in the nodal numbering scheme.

Proceed to line C-3

5.5.2.3 C-3 – Level 2 – Pipe Mesh – Control Variables

C-3.L2.Pipe**Control variables**

Use if	Comments
A-1.LEVEL = 2	Use ONLY if the 'Solution Level' is set to 2.
A-2.NPCAN = 1 (Pipe Mesh)	Use ONLY if the 'Canned Mesh Code' is set to 1 ('Pipe Mesh').

Parameter (columns) (format) (units)	Input Options	Description
Number of load steps (NINC) (01-05) (15) (integer)	Number of load steps to be executed = N (any number from 1 to say 20) = -1 (lump all loads into 1 step) = -N (mimic Level 1 loading) Default = 0, No load steps applied	Any number of load steps may be specified for execution in a given problem. The first five load steps include the gravity loads from the components listed below. After load-step 5, the soil cover height above the truncated mesh height (2*PDIA) is applied in increments (NINC-5) of equivalent overburden pressure. In summary, the steps are: (1) Pipe structure, in-situ soil and bedding. (2) Fill soil to pipe spring-line (3) Fill soil to pipe crown (4) Fill soil to PDIA/4 above crown (5) Fill soil to 2*PDIA above crown (6-N) = steps of overburden pressure
Plot control (IPLLOT) (05-10) (15) (integer)	Control for plot files units 10 & 30 =0, No plot files =1, Create 10 =2, Create 30 =3, Create 10 & 30 Note: For the GUI, this value is ALWAYS set to 3.	Unit 10 contains all the finite-element mesh data plus all the structural responses for each load step; it is intended as the data source for plotting mesh configurations, deformed shapes and contours. Unit 30 contains the detailed pipe responses (RESULT) at each node for each load step; it is intended as the data source for pipe response plots.

Parameter (columns) (format) (units)	Input Options	Description
Response data output (IWRT) (11-15) (I5) (integer)	Control for print of response data to the CANDE output file: =0, minimal =1, standard =2, plus Duncan =3, plus interface Default = 0	CANDE's output file is the primary source of readable output showing the structural responses at each load step. IWRT = 0 means only the pipe responses (RESULT) are printed, no soil-system responses. IWRT = 1 means the pipe responses plus the soil-system responses are printed (recommended). IWRT = 2 means the standard print plus an iteration trace of the Duncan-model soil elements. IWRT = 3 means the standard print plus an iteration trace of the Interface soil elements
Mesh output (MGENPR) (16-20) (I5) (integer)	Control for print of mesh data to the CANDE output file: =1, control data =2, mirror input =3, created data =4, maximum Default = 3	As a companion control to IWRT, MGENPR controls the amount of mesh data written to the CANDE output file. MGEN = 1, prints only the control information MGEN = 2, above plus node and element input MGEN = 3, above plus generated mesh data MGEN= 4, above plus Laplace generated nodes

Proceed to line C-4

5.5.2.4 C-4 – Level 2 – Pipe Mesh – Embankment/Trench Mesh Dimensions

C-4.L2.Pipe**Embankment/Trench mesh dimensions**

Use if	Comments
A-1.LEVEL = 2	Use ONLY if the 'Solution Level' is set to 2.
A-2.NPCAN = 1 (Pipe Mesh)	Use ONLY if the 'Canned Mesh Code' is set to 1 ('Pipe Mesh').

Parameter (columns) (format) (units)	Input Options	Description
Number of backpacking elements (NUMPEL) (01-05) (15,5X) (integer)	Number of backpacking elements: = N, choose up to 10 elements (N = 1 to 10) This feature only applies for the embankment mesh (WORD = EMBA). Default = 0	Backpacking is a soft material like polystyrene foam placed over the pipe's periphery, starting at the crown, to induce positive soil arching. If N = 1, then first soil element immediately above the crown (an 18 degree segment on either side of crown) will be assigned to backpacking material instead of fill soil. Similarly if N= 2, then two sequential elements will be assigned backpacking properties, and so on until N = 10 which means a complete backpacking ring surrounds the pipe. Default implies no backpacking will be used.
Thickness of backpacking (TPAC) (11-20) (F10.0) (inches)	Thickness of backpacking This feature only applies for the embankment mesh (WORD = EMBA) and NUMPEL>0. Default = PDIA/12 inches	All NUMPEL backpacking elements will be assigned the same thickness. Minimum thickness is TPAC = PDIA/16 and maximum thickness is TPAC = 3*PDIA/16.
Trench depth (TRNDEP) (21-30) (F10.0) (feet)	Trench depth This entry only applies to the trench mesh (WORD = TREN). Default = PDIA/4 feet	The trench depth, specified in feet, is the distance from the pipe invert to the trench surface. The trench depth is automatically scaled up to the nearest quarter diameter depth. Thus, the actual mesh trench depths are 0.25, 0.50, 0.75, 1.00, 1.25 times the diameter. For trench depths above 1.25 diameters, the additional trench fill soil (material zone 4) is modeled as equivalent overburden pressure applied to the truncated mesh.

Parameter (columns) (format) (units)	Input Options	Description
Trench width (TRNWID) (31-40) (F10.0) (feet)	Trench width This entry only applies to the trench mesh (WORD = TREN). Default = none	The trench width is specified in feet from trench wall to trench wall. The minimum allowable width is 1.25 times horizontal diameter and the maximum is 1.50 times the horizontal diameter.

If WORD2 = MOD, Proceed to Level 2 – Extended (CX lines)
Otherwise go to Part D for soil material definitions.

Figure 5.5-2 – Level 2-Pipe-Embankment/Homogeneous mesh with load steps and materials




Figure 5.5-3 – Level 2-Pipe-Trench mesh with load steps and material zones




Figure 5.5-4 – Element numbering scheme for Level 2 pipe mesh (CAN1)

Figure 5.5-5 – Nodal numbering scheme for Level 2 Pipe Mesh, (embankment and trench)




Table 5.5-2 – Pipe Level 2 – Node renumbering scheme for inserting eleven pipe-soil interface elements around the pipe

Basic Scheme Nodes ⁽²⁾	Pipe & Soil Scheme Node ⁽¹⁾	Basic Scheme Nodes ⁽²⁾	Pipe & Soil Scheme Nodes ⁽¹⁾
1	1	50	62
2	2	51	63
.	.	.	.
.	.	.	.
37	37	55	67
38	38, 40, 39	56	68, 70, 69
39	41, 43, 42	57	71, 73, 72
40	44, 46, 45	58	74, 76, 75
41	47, 49, 49	59	77, 79, 78
42	50, 52, 51	60	80, 82, 81
43	53	61	83
44	54	62	84
.	.	.	.
.	.	.	.
48	58	.	.
49	59, 61, 60	110	132

Notes:

- (1) Instead of one node at the pipe-soil interface locations, three nodes are defined at the same location to from the interface element. For every node triplet above (a, b, c),
a = pipe node IX(1)
b = soil node IX(2)
c = “free node” IX(3)
- (2) The eleven interface elements are numbered 97 through 107, beginning at the invert and continuing counterclockwise to the crown.

Table 5.5-3 – Pipe Level 2 – Node renumbering scheme for inserting seven pipe-soil interface elements along the trench wall

Basic Scheme Nodes ⁽²⁾	Trench Wall Slip Scheme Node ⁽¹⁾	Basic Scheme Nodes ⁽²⁾	Trench Wall Slip Scheme Nodes ⁽¹⁾
1	1	89	97
2	2	90	98,100,99
.	.	91	101
50	50	.	.
51	51,53,52	97	107
52	54	98	108,110,109
.	.	99	111
61	63	.	.
62	64,66,65	105	117
63	67	106	118,120,119
.	.	107	121
70	74	108	122
71	75,77,76	109	123
72	78	110	124
.	.	.	.
81	87		
82	88,90,89		
83	91		

Notes:

- (1) Instead of one node at the trench wall interface, three nodes are defined at seven locations on the trench wall to form seven interface elements. For every node triplet above (a, b, c),
 - a = pipe node IX(1)
 - b = soil node IX(2)
 - c = "free node" IX(3)
- (2) The seven interface elements are numbered 97 through 103, beginning near the trench bottom and increasing to the trench top.

5.5.3 Solution Level 2 – Box Mesh

5.5.3.1 C-1 – Level 2 – Box Mesh – Control Commands and Title

C-1.L2.Box
Control commands and title

Use if	Comments
A-1.LEVEL = 2	Use ONLY if the ‘Solution Level’ is set to 2.
A-2.NPCAN = 2 (Box Mesh)	Use ONLY if the ‘Canned Mesh Code’ is set to 2 (‘Box Mesh’).

Parameter (columns) (format) (units)	Input Options	Description
Mesh Pattern (WORD) (01-04) (A4) (word)	Name to select mesh pattern for soil = EMBA (embankment) = TREN (trench)	Level 2 – Box Mesh provides an automatic finite element mesh for a rectangular shaped culvert. The type of soil construction is controlled by the choice for WORD. For WORD = EMBA, an embankment mesh is generated as illustrated in Figure 5.5-6. The in-situ soil surface is at pipe’s invert and backfill soil is placed in lifts along side and above the culvert. The fill soil’s lateral extent is assumed indefinitely wide. For WORD = TREN, a trench mesh is generated as illustrated in Figure 5.5-7. Any trench depth may be specified, measured from the in-situ soil surface to the box invert. Similarly, any trench width may be specified. Backfill soil is placed in lifts to fill the trench plus overfill.
Title (TITLE) (05-72) (17A4) (words)	User description of mesh printed with output	TITLE is a descriptive phrase up to 68 characters that will be printed with the output to describe the mesh options selected by the user.

Parameter (columns) (format) (units)	Input Options	Description
Make changes to the basic mesh (WORD1) (73-76) (A4) (word)	A command word to subsequently make changes to basic mesh: = MOD (mesh will be modified) Default = <i>blank</i> (No modification)	For WORD1 = MOD, the user will have the opportunity to change the basic mesh in terms of nodal locations, element properties and prescribed loads. This is accomplished by supplying additional data in lines CX-1 through CX-4 after the basic C-1 through C-4 data is complete. Motivations for changing the basic mesh include: add live load(s), simulate voids or rocks in the soil system, and to change shapes such as the bedding. The default case (no modifications) applies to many basic problems.

Comment: The Level 2 – Box Mesh generates a half mesh, symmetric about the vertical centerline, implying that all geometry and loading is mirror symmetric on both sides of the centerline.

Proceed to Line C-2.

5.5.3.2 C-2 – Level 2 – Box Mesh – Control Variables/Installation Dimensions

C-2.L2.Box**Control variables/installation dimensions**

Use if	Comments
A-1.LEVEL = 2	Use ONLY if the ‘Solution Level’ is set to 2.
A-2.NPCAN = 2 (Box Mesh)	Use ONLY if the ‘Canned Mesh Code’ is set to 2 (‘Box Mesh’).

Parameter (columns) (format) (units)	Input Options	Description
Plot control (IPLOT) (01-05) (15) (integer)	Control for plot files units 10 & 30 =0, No plot files =1, Create 10 =2, Create 30 =3, Create 10 & 30 Note: For the GUI, this value is ALWAYS set to 3.	Unit 10 contains all the finite-element mesh data plus all the structural responses for each load step; it is intended as the data source for plotting mesh configurations, deformed shapes and contours. Unit 30 contains the detailed pipe responses (RESULT) at each node for each load step; it is intended as the data source for pipe response plots.
Response data output (IWRT) (06-10) (15) (integer)	Control for print of response data to the CANDE output file: =0, minimal =1, standard =2, plus Duncan =3, plus interface	CANDE’s output file is the primary source of readable output showing the structural responses at each load step. IWRT = 0 means only the pipe responses (RESULT) are printed, no soil-system responses. IWRT = 1 means the pipe responses plus the soil-system responses are printed (recommended). IWRT = 2 means the standard print plus an iteration trace of the Duncan-model soil elements. IWRT = 3 means the standard print plus an iteration trace of the Interface soil elements
Mesh output (MGENPR) (11-15) (15) (integer)	Control for print of mesh data to the CANDE output file: =1, control data =2, mirror input =3, created data =4, maximum Default = 3	As a companion control to IWRT, MGENPR controls the amount of mesh data written to the CANDE output file. MGEN = 1, prints only the control information MGEN = 2, above plus node and element input MGEN = 3, above plus generated mesh data MGEN = 4, above plus Laplace generated nodes

Parameter (columns) (format) (units)	Input Options	Description
Number of load steps (NINC) (16-20) (I5) (integer)	Number of load steps to be executed = N (any positive number) = -1 (signal to lump all loads into one step) Default = 0, No load steps are processed.	Any number load steps may be specified for execution in a given problem. The first nine load steps include the gravity loads from the components listed below followed by increments of overburden pressure for soil height increments above $3 \times R2$. In summary the load steps are: (1) Box structure, in-situ soil and bedding. (2) Fill soil to 1/3 of box rise (3) Fill soil to 2/3 of box rise (4) Fill soil to level of box height (5-9) Cover soil increments up to $3 \times R2$ (10-N) Increments of overburden pressure
One half of horizontal span (R1) (21-30) (F10.0) (inches)	One half of horizontal span Default = none	R1 is the box dimension in the horizontal direction from the centerline of the box to the mid-depth of the sidewall. See Figure 5.5-6.
One half of vertical rise (R2) (31-40) (F10.0) (inches)	One half of vertical rise Default = none	R2 is the one-half the vertical distance from the mid-depth of the bottom slab to mid-depth of the top slab. See Figure 5.5-6.
Height of soil cover above box. (HTCOVR) (41-50) (F10.0) (feet)	Height of soil cover above box. Default = none	HTCOVR is the actual height of soil placed on top of the box; it is defined the same for trench and embankment installations. If HTCOVR is specified greater than $3 \times R2$, the mesh's top boundary is truncated at $3 \times R2$ and the remaining fill soil is placed in equivalent increments of overburden pressure.
Density of soil above truncated mesh (DENSTY) (51-60) (F10.0) (lb/ft ³)	Density of soil above truncated mesh. Default = 0.0 pcf	When the soil mesh is truncated at $3 \times R2$ above the box surface, the subsequent soil loading is simulated by increments of overburden pressure = (height-increment)*DENSTY. Typically the user should set DENSTY = soil density in Part D.
Trench Gap (TRWID) (61-70) (F10.0) (feet)	Trench gap Note: This is only required if the 'Mesh Pattern (WORD) = TREN' Default = none	This entry only applies to the trench mesh (WORD = TREN). TRWID is the distance in feet from mid-depth of the box's sidewall to trench wall. The minimum allowable gap width is $0.1 \times R1$. If TRWID is greater than $4.0 \times R1$ the trench installation becomes an embankment installation.

Parameter (columns) (format) (units)	Input Options	Description
Bedding depth (BDEPTH) (71-80) (F10.0) (inches)	Bedding depth Default = 12 inch	This entry applies to both the embankment and trench mesh. BDEPTH is the thickness of the bedding placed uniformly beneath the bottom slab and extending $0.25 \cdot R1$ beyond the sidewalls.

If WORD1 = MOD, Proceed to Level 2 – Extended (CX lines)

Otherwise go to Part D for soil material definitions.


Figure 5.5-6 – Level 2 Box – Embankment mesh configuration for box with load steps and material zones

Figure 5.5-7 – Level 2 Box – Trench mesh configuration for box with construction increments and material zones




Figure 5.5-8 – Level 2 Box – Element numbering scheme for box mesh for embankment and trench

141	142	143	144	145	146	147	148	149	150
131	132	133	134	135	136	137	138	139	140
121	122	123	124	125	126	127	128	129	130
111	112	113	114	115	116	117	118	119	120
101	102	103	104	105	106	107	108	109	110
1	2	3	4	5	95	96	97	98	100
				6	89	90	91	92	94
				7	83	84	85	86	88
				8	77	78	79	80	82
				9	71	72	73	74	76
				10	65	66	67	68	70
				11					
14	13	12	11		55	56	57	58	59
					60	61	62	63	64
					45	46	47	48	49
					50	51	52	53	54
					35	36	37	38	39
					40	41	42	43	44
					25	26	27	28	29
					30	31	32	33	34
					15	16	17	18	19
					20	21	22	23	24

Pipe elements
1 to 14

Figure 5.5-9 – Level 2 Box – Nodal numbering scheme for box mesh for embankment and trench

157	158	159	160	161	162	163	164	165	166	167
146	147	148	149	150	151	152	153	154	155	156
135	136	137	138	139	140	141	142	143	144	145
124	125	126	127	128	129	130	131	132	133	134
113	114	115	116	117	118	119	120	121	122	123
102	103	104	105	106	107	108	109	110	111	112
				95	96	97	98	99	100	101
				88	89	90	91	92	93	94
				81	82	83	84	85	86	87
				74	75	76	77	78	79	80
				67	68	69	70	71	72	73
56	57	58	59	60	61	62	63	64	65	66
45	46	47	48	49	50	51	52	53	54	55
34	35	36	37	38	39	40	41	42	43	44
23	24	25	26	27	28	29	30	31	32	33
12	13	14	15	16	17	18	19	20	21	22
1	2	3	4	5	6	7	8	9	10	11

5.5.4 Solution Level 2 – Arch Mesh

5.5.4.1 C-1 – Level 2 – Arch Mesh – Control Commands and Title

C-1.L2.Arch

Control commands and title

Use if	Comments
A-1.LEVEL = 2	Use ONLY if the 'Solution Level' is set to 2.
A-2.NPCAN = 3 (Arch Mesh)	Use ONLY if the 'Canned Mesh Code' is set to 3 ('Arch Mesh').

Parameter (columns) (format) (units)	Input Options	Description
Mesh Pattern (WORD) (01-04) (A4) (word)	<p>Name to select mesh pattern for soil</p> <p>= EMBA (embankment)</p> <p>= TREN (trench)</p> <p>= HOMO (homogenous)</p>	<p>Level 2 – Arch Mesh provides an automatic finite element mesh for arch-shaped or 3-sided box culverts. Shapes are defined with 2 or 3 curved (or straight) segments defining half of the symmetrical arch or box. The type of soil construction is controlled by the choice for WORD:</p> <p>For WORD = EMBA, an embankment mesh is generated as illustrated in Figure 5.5-10. The in-situ soil surface is level with arch footing and backfill soil is placed in lifts around and above the arch. The fill soil's lateral extent is assumed indefinitely wide.</p> <p>For WORD = TREN, a trench mesh is generated as illustrated in Figure 5.5-11. Any trench depth may be specified, measured from the in-situ soil surface to the arch footing. Similarly, any trench width may be specified. Backfill soil is placed in lifts to fill the trench plus overfill.</p> <p>For WORD = HOMO, an embankment-like mesh is generated, similar to the embankment mesh, except that all the soil zones (footing, fill soil, etc.) are all assigned a common material model. That is, the entire soil system is one homogenous material to be defined by the user.</p>

Parameter (columns) (format) (units)	Input Options	Description
Title (TITLE) (05-72) (17A4) (words)	User description of mesh to be printed with output	TITLE is a descriptive phrase up to 68 characters that will be printed with the output to describe the mesh options selected by the user.
Make changes to the basic mesh (WORD2) (73-76) (A4) (word)	A command word to subsequently make changes to basic mesh: = MOD (mesh will be modified) Default = <i>blank</i> (No modification)	For WORD2 = MOD, the user will have the opportunity to change the basic mesh in terms of nodal locations, element properties and prescribed loads. This is accomplished by supplying additional data in lines CX-1 through CX-4 after the basic C-1 through C-4 data is complete. Motivations for changing the basic mesh include: add a live load(s), simulate voids or rocks in the soil system, and to change shapes such as the bedding. The default case (no modifications) applies to many basic problems without the need for modifications.

Comments: Like all Level 2 options, the arch mesh is assumed symmetrical about the vertical centerline so that only one half of the system is modeled with finite elements. The automated subroutine generates all nodal points and elements to define the arch, in-situ soil, footing, backfill soil and interface elements between the arch and backfill soil.

The number of elements used to define the soil over the arch is dependent on the specified soil cover height above the crown. A maximum number of elements (269 total) are used for soil cover heights greater or equal to the arch rise. For cover heights greater than 1.5 times the arch rise, the mesh surface is truncated at this level and equivalent increments of overburden pressure are applied to account for the remaining cover height, if any.

Interface elements are always generated with the arch mesh so that the user must define the interface properties in Part D. There are 19 interface elements starting at the crown node and proceeding clockwise around the arch to node 19, the second to the last node before the connection to the footing. The last arch node, number 20, connected to the footing is not assigned an interface element since relative slippage is restrained by the footing. To simulate a fully bonded condition between the arch and backfill soil, the user may prescribe arbitrarily large values for the coefficient of friction and tensile breaking force in Part D or assign frictional properties as desired. See Table 5.5-4 and Table 5.5-5 for a listing of interface elements.

Proceed to line C-2

5.5.4.2 C-2 – Level 2 – Arch Mesh – Plot and Print Control

C-2.L2.Arch**Plot and print control**

Use if	Comments
A-1.LEVEL = 2	Use ONLY if the ‘Solution Level’ is set to 2.
A-2.NPCAN = 3 (Arch Mesh)	Use ONLY if the ‘Canned Mesh Code’ is set to 3 (‘Arch Mesh’).

Parameter (columns) (format) (units)	Input Options	Description
Plot control (IPLOT) (01-05) (15) (integer)	Control for plot files units 10 & 30 =0, No plot files =1, Create 10 =2, Create 30 =3, Create 10 & 30 Note: For the GUI, this value is ALWAYS set to 3.	Unit 10 contains all the finite-element mesh data plus all the structural responses for each load step; it is intended as the data source for plotting mesh configurations, deformed shapes and contours. Unit 30 contains the detailed pipe responses (RESULT) at each node for each load step; it is intended as the data source for pipe response plots.
Response data output (IWRT) (06-10) (15) (integer)	Control for print of response data to the CANDE analysis output file: =0, minimal =1, standard =2, plus Duncan =3, plus interface	The CANDE output file is the primary source of readable output showing the structural responses at each load step. IWRT = 0 means only the pipe responses (RESULT) are printed, no soil-system responses. IWRT = 1 means the pipe responses plus the soil-system responses are printed (recommended). IWRT = 2 means the standard print plus an iteration trace of the Duncan-model soil elements. IWRT = 3 means the standard print plus an iteration trace of the Interface soil elements
Mesh output (MGENPR) (11-15) (15) (integer)	Control for print of mesh data to the CANDE output file: =1, control data =2, mirror input =3, created data =4, maximum Default = 3	As a companion control to IWRT, MGENPR controls the amount of mesh data written to the CANDE output file. MGEN = 1, prints only the control information MGEN = 2, above plus node and element input MGEN = 3, above plus generated mesh data MGEN = 4, above plus Laplace generated nodes

Parameter (columns) (format) (units)	Input Options	Description
Number of load steps (NINC) (16-20) (I5) (integer)	Combination of load steps to be executed: = 1, all loads applied in step 1. = 2, apply load 1 then all others lumped in step 2. = N, apply loads 1 to N-1, all others lumped in step N. Default = 0, No steps processed.	Up to 20 load steps may be specified to simulate placement of soil around and above the arch. The first eleven load steps include the gravity loads from the elements listed below followed by load steps of equivalent overburden pressure if needed: (1) Arch structure, in-situ soil and bedding. (2-3) Fill soil lifts to spring line (4) Fill soil lift above spring line (sloped) (5-6) Top-loading layers on arch only (7-11) Cover soil layers up to 1.5 times rise (12-N) Increments of overburden pressure
Height of soil cover above crown of arch (HTCOVR) (21-30) (F10.0) (feet)	Height of soil cover above crown of arch. Default = none	HTCOVR is the actual height of soil placed on top of the arch; it is the distance from the arch crown to the fill soil surface. If HTCOVR is specified greater than 1.5 times the arch rise (RISE), the mesh's top boundary is truncated at this level and the remaining fill soil is placed in equivalent increments of overburden pressure.
Density of soil above truncated arch (DENSTY) (31-40) (F10.0) (lb/ft ³)	Density of soil above truncated mesh. Default = 0.0 pcf	When the soil mesh is truncated at 1.5*RISE above the arch crown, the subsequent soil loading is simulated by increments of overburden pressure = (height-increment)*DENSTY. Typically the user should set DENSTY = soil density in Part D.
Trench depth (TRNDEP) (41-50) (F10.0) (feet)	Trench depth This value is ONLY input for trench mesh pattern (WORD=TREN) Default = none	This entry only applies to the trench mesh (WORD = TREN). The trench depth, specified in feet, is the distance from the arch footing to the trench surface. The trench depth is automatically scaled up to the nearest horizontal mesh-grid line, approximately spaced at intervals ¼ the arch rise. The maximum trench depth allowed is the minimum of 2.5 times arch rise or the arch rise plus HTCOVR.
Trench width (TRNWID) (51-60) (F10.0) (feet)	Trench gap at footing level. This value is ONLY input for trench mesh pattern (WORD=TREN) Default = none	This entry only applies to the trench mesh (WORD = TREN). TRNWID is the horizontal distance in feet from the arch leg at the footing level to the trench wall. The minimum allowable gap width is 0.15 times the arch span. The maximum allowable trench gap is 0.5 times the arch span.

Parameter (columns) (format) (units)	Input Options	Description
Slope of trench wall (TRNSLP) (61-70) (F10.0) (horizontal/vertical)	Slope of trench wall This value is ONLY input for trench mesh pattern (WORD=TREN) Default = 0.0	This entry only applies to the trench mesh (WORD = TREN). TRNSLP is the slope of the trench wall measured as horizontal-run divided by vertical rise. Thus for a perfectly vertical trench wall, TRNSLP = 0.0. The maximum allowable slope is 1.0 (45% wall angle from vertical).

Comment: Figure 5.5-10 and Figure 5.5-11 show the mesh topology, material zones and construction increments for the embankment and trench installations, respectively.

Proceed to line C-3

5.5.4.3 C-3 – Level 2 – Arch Mesh – Arch and Footing Dimensions

C-3.L2.Arch**Arch and footing dimensions**

Use if	Comments
A-1.LEVEL = 2	Use ONLY if the 'Solution Level' is set to 2.
A-2.NPCAN = 3 (Arch Mesh)	Use ONLY if the 'Canned Mesh Code' is set to 3 ('Arch Mesh').

Parameter (columns) (format) (units)	Input Options	Description
Total rise of arch structure (RISE) (01-10) (F10.0) (inches)	Total rise of arch structure Default = none	RISE is the vertical distance in inches from the footing level to the crown location. This applies to all arch shapes (including 2- and 3-segment arches with curved or straight line segments)
One-half of arch span at footing level (HFSPAN) (11-20) (F10.0) (inches)	One-half of arch span at footing level Default = none	HFSPAN is the horizontal distance in inches from the arch centerline to the arch leg connection at the footing. This applies to all arch shapes.
Vertical rise of side segment (SDRISE) (21-30) (F10.0) (inches)	Vertical rise of side segment. (3 rd segment) Default = 0.0 (2-segments)	A non-zero entry means a 3-segment arch will be generated wherein SDRISE = vertical distance from the footing to the junction point of the side (3 rd) segment with the corner (2 nd) segment. If SDRISE = 0.0, a 2-segment arch will be constructed. See Figure 5.5-10 through Figure 5.5-13.
Footing depth (FTDEP) (31-40) (F10.0) (inches)	Footing depth (thickness) Default = none	The footing depth is the vertical thickness of concrete slab supporting the arch leg. In order to control the aspect ratio of the footing elements, the minimum and maximum values are: $FTDEP(\text{minimum}) = 0.05 * RISE$ $FTDEP(\text{maximum}) = 0.30 * RISE$
Outside footing width (FTWIDO) (41-50) (F10.0) (inches)	Outside footing width Default = none	FTWIDO is the horizontal length that the footing extends beyond the arch connection point on the exterior side. In order to control the aspect ratio of the mesh elements, the minimum and maximum values are: $FTWIDO(\text{minimum}) = 0.1 * (RISE + HFSPAN)$ $FTWIDO(\text{maximum}) = 0.25 * (RISE + HFSPAN)$

Parameter (columns) (format) (units)	Input Options	Description
Inside footing width FTWIDI (51-60) (F10.0) (inches)	Inside footing width Default = none	FTWIDI is the horizontal footing length on the interior side of the arch connection point. (Note, FTWIDO + FTWIDI = total footing width). In order to control the aspect ratio of the mesh: FTWIDI (minimum) = $0.1 * (HFSPAN)$ FTWIDI (maximum) = $0.5 * (HFSPAN)$
Spacing factor for mesh grid around arch (SPCFAC) (61-70) (F10.0) (ratio)	Spacing factor for mesh grid around arch. (Range 1.0 to 1.3) Default = 1.0	This factor controls the proportional sizing of elements around the arch to achieve a more optimal grid pattern in terms of element shapes and aspect ratios. This feature is problem dependent and should be used in a trial and error fashion with graphical output of mesh topology. In general use SPCFAC = 1.0

Comment:. Figure 5.5-13 through Figure 5.5-17 show the element and nodal numbering of the entire arch mesh as well as magnified views in the vicinity of the arch. Table 5.5-4 shows additional nodes and elements that are added as a function of cover height. Finally, Table 5.5-5 identifies the nodes of the interface elements and Table 5.5-6 identifies interface element re-numbering as a function of cover height.

Proceed to Line C-4

5.5.4.4 C-4 – Level 2 – Arch Mesh – Arch and Footing Dimensions

C-4.L2.Arch**Arch segments and angles**

Use if	Comments
A-1.LEVEL = 2	Use ONLY if the 'Solution Level' is set to 2.
A-2.NPCAN = 3 (Arch Mesh)	Use ONLY if the 'Canned Mesh Code' is set to 3 ('Arch Mesh').

Parameter (columns) (format) (units)	Input Options	Description
Radius of top arc (segment 1) (R1) (01-10) (F10.0) (inches)	Radius of top arc (arc segment 1) Default = 0.0 (straight line)	If $R1 > 0$, R1 is taken as the radius of the top arc segment also called the 1 st segment. If $R1 = 0$, the top segment is defined as a straight line. See Figures C-Level 2-Arch-3&4.
Angle for R1 segment (THETA1) (11-20) (F10.0) (degrees)	Angle for R1 segment Default = none	If $R1 > 0$, THETA1 is the included angle of the top arc measured from vertical centerline to the junction point with 2 nd segment. If $R1 = 0$, THETA1 is the counter-clockwise angle from the horizontal to the straight-line segment # 1, shown negative in figure.
Radius of 2nd segment (R2) (21-30) (F10.0) (inches)	Radius of 2 nd segment Default = 0.0 (straight line)	If $R2 > 0$, R2 is taken as the radius of the corner arc segment also called the 2 nd segment. If $R2 = 0$, the 2nd segment is defined as a straight line. See Figure 5.5-10 through Figure 5.5-13.
Angle for R2 segment (THETA2) (31-40) (F10.0) (degrees)	Angle for R2 segment Default = none	If $R2 > 0$, THETA2 is the included angle of the corner arc measured from the junction point of segments 1 and 2 to the end of segment 2. If $R2 = 0$, THETA2 is the counter-clockwise angle from the horizontal axis to the straight-line segment # 2 (usually more than 90 degrees)
Radius of 3rd segment (R3) (41-50) (F10.0) (inches)	Radius of 3 rd segment This value is ONLY input for 3 segment arches (SDRIZE>0). Default = 0.0 (straight line)	R3 only applies to 3-segment arch, (SDRIZE>0). If $R3 > 0$, R3 is taken as the radius of the side arc segment also called the 3rd segment. If $R3 = 0$, the 3rd segment is defined as a straight line. See Figure 5.5-12 and Figure 5.5-13.

Parameter (columns) (format) (units)	Input Options	Description
Angle for R3 segment (THETA3) (51-60) (F10.0) (degrees)	Angle for R3 segment This value is ONLY input for 3 segment arches (SDRIZE>0). Default = blank	This only applies to 3-segment arch, SDRIZE>0. If R3 > 0, THETA3 is the included angle of the side arc measured from the junction point of segments 2 and 3 to the end of segment 3. If R3 = 0, THETA3 is the counter-clockwise angle from the horizontal axis to the straight-line segment # 3 (usually at least 90 degrees)
Base angle of R3 segment (THETA4) (61-70) (F10.0) (degrees)	Base angle of R3 segment This value is ONLY input for 3 segment arches (SDRIZE>0). Default = blank	This only applies to 3-segment arch (SDRIZE>0) and curved segments (R3 > 0). THETA4 is the base angle defined by the line perpendicular to the end of the 3 rd segment and the horizontal footing line. THETA4 may be positive or negative wherein the positive direction is measured counter clockwise from the horizontal. (Note THETA4 is negative for a re-entrant arch such as shown in the figures.)
Nodes assigned to segment 1 (NTN) (71-75) (15) (integer)	Nodes assigned to segment #1 (top segment) Default = 10 (3-segment arch) Default = 13 (2-segment arch)	The automated Arch Mesh uses a total of 20 Nodes to define all arch shapes and sizes. Node 1 is located at the crown and node numbering proceeds clockwise around the arch with Node 20 assigned to the footing connection. The Arch Mesh assigns 10 or 13 nodes (default values) to the first arc segment depending on whether it is a 3-segment or 2-segment arch, respectively. NTN allows the user to prescribe a better distribution of nodes to the top arch to fit the problem at hand. In general the goal is to define the distribution of the nodes between the segments to achieve equal uniform lengths between all nodes.
Nodes assigned to segment 2 plus segment 1 (NCN) (76-80) (15) (integer)	Nodes assigned to segment #2 plus segment #1 (top and corner segments) This value is ONLY input for 3 segment arches (SDRIZE>0). Default = 16 (3-segment arch) Default = blank (2-segment arch)	NCN only applies to 3-segment arch, (SDRIZE>0). (Note, the nodal assignment for 2-segment arch is already complete, that is, segment 1 = NTN nodes and segment 2 = 20-NTN nodes). The Arch Mesh assigns NCN =16 nodes (default value) to the first and second arc segments, which means segment 2 is assigned NCN-NTN nodes beyond the common node. NCN allows the user to prescribe a better distribution of nodes to the corner arch segment in order to fit the problem at hand with uniform lengths between nodes. The remaining number of nodes assigned to the 3 rd segment is 20-NCN beyond the common node.

If WORD2 = MOD, Proceed to Level 2 – Extended (CX lines)

Otherwise proceed to Part D






Figure 5.5-10 – Level 2 Arch – Embankment mesh configuration for Arch with load steps and material zones**Figure 5.5-11 – Level 2 Arch – Trench mesh configuration for Arch showing load steps and material zones**


Figure 5.5-12 - Level 2 Arch - Illustration of parameters for 3-segment and 2-segment arch with curved segments



Input parameters for 2-segment arch with curved segments

Figure 5.5-13 – Level 2 Arch – Illustration of parameters for 3-segment and 2-segment arch with straight segments

Input parameters for 3-segment arch with straight segments



Input parameters for 2-segment arch with straight segments

Table 5.5-4 – Level 2 Arch – Values for the basic arch parameters as a function of height cover

Item	<u>Basic values vs. Height of Cover</u> (Range of HTCOVR)			
	≤ 0.4 (rise)	≤ 0.7 (rise)	≤ 1.0 (rise)	≤ 1.5 (rise) ⁽¹⁾
	≥ 0.1 (rise)	> 0.4 (rise)	> 0.7 (rise)	> 1.0 (rise)
	KCOVER = 0	KCOVER = 1	KCOVER = 2	KCOVER = 3
Basic no. load steps ⁽²⁾	8	9	10	11
Total nodes (NPT)	244	265	286	307
Total elements (NELEM)	209	229	249	269
Basic no. boundary conditions (NBPTC) ⁽³⁾	35	37	39	41

Notes:

- (1) For HTCOVR > 1.5 (rise) the mesh is truncated at 1.5" (rise) above crown and the remaining soil weight is added in increments of overburden pressure. The number of increments employed to place overburden pressure = NINC-11.
- (2) The total number of load steps. NINC, is user specified where: $1 \leq \text{NINC} \leq 20$.
- (3) Increments of overburden pressure increase the total number of boundary conditions to the sum of the basic number plus $21 * (\text{NINC}-11)$.

Table 5.5-5 – Level 2 Arch – Identification of arch and soil nodes that are tied together by interface elements.Identification of interface element nodal connectivity

Number of Nodes from Crown	Pipe-soil Interface Nodes ⁽¹⁾	Number of Nodes from Crown	Pipe-soil Interface Nodes ⁽¹⁾
1	198,200,199	11	132,143,133
2	194,196,195	12	130,144,131
3	190,192,191	13	128,145,129
4	167,169,168	14	118,120,119
5	164,166,165	15	115,117,116
5	164,166,165	15	115,117,116
6	161,163,162	16	109,111,110
7	158,160,159	17	103,105,104
8	138,140,139	18	97,99,98
9	136,141,137	19	91,93,92
10	134,142,135	20	(2)

Notes:

- (1) Three nodes define the pipe-soil interface at each pipe node around the arch. For every node triplet above (a, b, c),
a = pipe node IX(1)
b = soil node IX(2)
c = “free node” IX(3)
- (2) Note that position #20, the arch connection into the footing, is not assigned an interface element.

Table 5.5-6- Level 2 Arch – Identification of element numbers for interface elements as a function of cover height.

Number of Nodes from Crown	Interface Element Numbers			
	See Table 5.5-4 for KCOVER definition			
	KCOVER=0	KCOVER=1	KCOVER=2	KCOVER=3
1	191	211	231	251
2	192	212	232	252
3	193	213	233	253
4	194	214	234	254
5	195	215	235	255
6	196	216	236	256
7	197	217	237	257
8	198	218	238	258
9	199	219	239	259
10	200	220	240	260
11	201	221	241	261
12	202	222	242	262
13	203	223	243	263
14	204	224	244	264
15	205	225	245	265
16	206	226	246	266
17	207	227	247	267
18	208	228	248	268
19	209	229	249	269
20

Note: KCOVER is an integer code representing certain ranges of fill height as defined in Table 5.5-4.

5.5.5 Extended Level 2

5.5.5.1 CX-1 – Level 2 Extended – Nodes, Elements and Boundary Condition Changes

CX-1
Nodes, elements and boundary condition changes

Extended Level 2 allows selective modifications to any Level 2 mesh configurations in order to specify changes in nodal coordinates, changes in element properties, and changes in loading conditions. To effectively use this feature, the user must refer to the relevant Level 2 mesh configuration, which are shown in previous figures, to identify nodes, elements and/or boundary conditions to be changed. Data for Extended Level 2 may only be input if the control word “MOD” was specified on command C-1

Use if	Comments
A-1.LEVEL = 2	Use ONLY if the ‘Solution Level’ is set to 2.
C-1.WORD1 = MOD (All three mesh options Pipe, Box or Arch)	Use ONLY if the ‘Make changes to the basic mesh’ parameter is set to MOD.

Parameter (columns) (format) (units)	Input Options	Description
Number of nodes to be changed with new coordinates (NEWXY) (01-05) (15) (integer)	Number of nodes to be changed with new coordinates Default = 0	Any number of nodes may be chosen to specify new x and y coordinates. Example reasons to change coordinates include modeling variations in the culvert shape (perhaps an imperfection), changing the dimensions of the bedding or footing elements, or altering the location of a live load on the soil surface. Nodes to be changed are defined on line CX-2, which is repeated NEWXY times.
Number of elements to be changed with new properties (NEWEL) (05-10) (15) (integer)	Number of elements to be changed with new properties Default = 0	Any number of elements may be chosen to specify new element properties. Example motivations to change element properties include changing the load step number and/or changing the material properties of an element or group of elements. Elements to be changed are defined on line CX-3, which is repeated NEWEL times.
Number of new loading/boundary conditions to be added (NEWBD) (11-15) (15) (integer)	Number of new loading/boundary conditions to be added Default = 0	Any number of new boundary conditions may be added into the loading schedule. The standard Level 2 loading is limited to gravity loads and uniform surface pressure loads. A prime reason for the NEWBD parameter is to permit the user is to add live loads into the loading schedule at any desired location and load step. Loading conditions to be added are defined on line CX-4, which is repeated NEWBD times.

Proceed to line CX-2

5.5.5.2 CX-2 – Level 2 Extended – Nodal Point Number and Changed Coordinates

CX-2**Nodal point number and changed coordinates**

Use if	Comments
A-1.LEVEL = 2	Use ONLY if the ‘Solution Level’ is set to 2.
C-1.WORD1 = MOD (All three mesh options Pipe, Box or Arch)	Use ONLY if the ‘Make changes to the basic mesh’ parameter is set to MOD.
CX-1.NEWXY > 0	Repeat this command for each node that is to be changed with new coordinates. Skip if NEWXY = 0

Parameter (columns) (format) (units)	Input Options	Description
Node number (NP) (01-05) (I5, 5X) (integer)	Node whose coordinates are to be changed Default = none	NP is a node number in one of the automated Level 2 canned meshes that is to be redefined here with new coordinates. The user should identify NP by referring to the figures and charts associated with particular Level 2 mesh configuration that is being revised.
X-Coordinate (XCOORD) (11-20) (F10.0) (inches)	X-coordinate location of node NP Default = none	XCOORD is the x-coordinate value for the node number NP (new or old position). Note that the automatic mesh checking routines in CANDE are by-passed in extended level 2 operations. Therefore, the user must exercise diligence in assigning new coordinates to avoid producing elements that are “badly shaped” or “inside out”.
Y-Coordinate (YCOORD) (21-30) (F10.0) (inches)	Y-coordinate location of node NP Default = none	YCOORD is the y-coordinate value for the node number NP (new or old position). Note that the automatic mesh checking routines in CANDE are by-passed in extended level 2 operations. Therefore, the user must exercise diligence in assigning new coordinates to avoid producing elements that are “badly shaped” or “inside out”.

Comment: The altered node coordinates are recorded in the CANDE output report under the heading Level 2 Extended, after the unaltered canned mesh nodes are printed.

Proceed to line CX-3.

5.5.5.3 CX-3 – Level 2 Extended – Element Number and Property Array

CX-3**Element number and property array**

Use if	Comments
A-1.LEVEL = 2	Use ONLY if the ‘Solution Level’ is set to 2.
C-1.WORD1 = MOD (All three mesh options Pipe, Box or Arch)	Use ONLY if the ‘Make changes to the basic mesh’ parameter is set to MOD.
CX-1.NEWEL > 0	Repeat this command for each element that is to be changed with new properties. Skip if NEWEL = 0.

Parameter (columns) (format) (units)	Input Options	Description
Modified element (NE) (01-05) (15) (integer)	Element whose properties are to be changed Default = none	NE is an element number from an automated Level 2 canned mesh whose property array (integer codes) is to be redefined. Of the six property array integers, the first four are the nodal connectivity, which are rarely revised. The last two property array integers, the material ID number and the load step number are well suited for revision.
Node I (NP(1)) (06-10) (15) (integer)	Node I of NE’s connectivity Default = blank (no change)	There is little motivation for the user to change the nodal connectivity array of any element. Nonetheless, the option is provided here for expert users wishing to use this option in special circumstances. In general leave this entry blank.
Node J (NP(2)) (11-15) (15) (integer)	Node J of NE’s connectivity Default = blank (no change)	There is little motivation for the user to change the nodal connectivity array of any element. Nonetheless, the option is provided here for expert users wishing to use this option in special circumstances. In general leave this entry blank.
Node K (NP(3)) (16-20) (15) (integer)	Node K of NE’s connectivity Default = blank (no change)	There is little motivation for the user to change the nodal connectivity array of any element. Nonetheless, the option is provided here for expert users wishing to use this option in special circumstances. In general leave this entry blank.
Node L (NP(4)) (21-25) (15) (integer)	Node L of NE’s connectivity Default = blank (no change)	There is little motivation for the user to change the nodal connectivity array of any element. Nonetheless, the option is provided here for expert users wishing to use this option in special circumstances. In general leave this entry blank.

Parameter (columns) (format) (units)	Input Options	Description
Material (NP(5)) (26-30) (I5) (integer)	New material ID number Default = blank (no change)	The material identification number for soil elements may be changed by setting NP(5) equal to any material ID number subsequently defined in Part D. To retain the material ID number assigned in Level 2, leave this entry blank.
Load step (NP(6)) (31-35) (I5) (integer)	New load step number Default = blank (no change)	The load step number (or load step number) of any element may be changed by setting NP(6) equal to the new desired load step number. To retain the original load step, leave blank

Comment: The altered element properties are recorded in the CANDE output report under the heading Level 2 Extended, after the unaltered canned mesh element properties are printed.

Proceed to line CX-4

5.5.5.4 CX-4 – Level 2 Extended – Nodal Loads and/or Displacements to be applied

CX-4
Nodal loads or displacements to be applied

Use if	Comments
A-1.LEVEL = 2	Use ONLY if the ‘Solution Level’ is set to 2.
C-1.WORD1 = MOD (All three mesh options Pipe, Box or Arch)	Use ONLY if the ‘Make changes to the basic mesh’ parameter is set to MOD.
CX-1.NEWBD > 0	Repeat this command for each element that is to be changed with new properties. Skip if NEWBD = 0.

Parameter (columns) (format) (units)	Input Options	Description
Node (NU) (01-05) (15) (integer)	Node where new loads/displacements are to be applied Default = none	NU is a node number from an automated Level 2 canned mesh whose boundary condition in terms of loads or displacements is to be revised. Note, since Level 2 is based on symmetry any load applied to the right-hand mesh is automatically applied to the mirror side of the mesh. Thus when applying a vertical point load on the system centerline, the actual load is twice the value of the specified load.
X-Condition (IFLAG(1)) (06-10) (15) (integer)	Code for x-loading condition: = 0, force specified = 1, disp. specified Default = 0	IFLAG(1) distinguishes whether the loading value in the x-direction (BV(1) next entry) is interpreted as a prescribed force in lbs/inch or a prescribed displacement in inches.
X-Value (BV(1)) (11-20) (F10.0) (lb/inch or inch)	Value of x-loading or x-displacement. Default = 0.0	Depending on IFLAG(1), BV(1) is the x-force that will be applied in load step IA. Or, BV(1) is the x-displacement that will be specified in load step IA.
Y-Condition (IFLAG(2)) (21-25) (15) (integer)	Code for y-loading condition: = 0, force specified = 1, disp. specified Default = 0	IFLAG(2) distinguishes whether the loading value in the y-direction (BV(2) next entry) is interpreted as a prescribed force in lbs/inch or a prescribed displacement in inches.
Y-Value (BV(2)) (26-35) (F10.0) (lb/inch or inch)	Value of y-loading or y-displacement. Default = 0.0	Depending on IFLAG(2), BV(2) is the y-force that will be applied in load step IA. Or, BV(2) is the y-displacement that will be specified in load step IA. Note that positive values are in the upward direction.

Parameter (columns) (format) (units)	Input Options	Description
Angle for skewed boundary input (BV(3)) (36-45) (F10.0) (degrees)	Angle for skewed boundary input. Default = 0.0 deg.	The x and y boundary conditions specified above are re-interpreted to a rotated coordinate system x' and y' . BV(3) is the counter-clockwise angle from the x-axis to the x' axis.
Load step (IA) (46-50) (I5) (integer)	Load step number for above loading Default = 1	Force loading conditions are applied only in load step number IA. Displacement loading conditions are applied in load step number IA and remain in effect for all subsequent increments.

Comment: The new boundary conditions are recorded in the CANDE output report under the heading Level 2 Extended, after the original canned mesh boundary conditions are printed.

Proceed to Part D

5.5.6 Solution Level 3

5.5.6.1 C-1 and C2 – Level 3 – Title and Control Variables

C-1.L3

Element number and property array

Level 3 is the traditional method of defining mesh data for input into a finite element program. Accordingly, the user must prepare finite element mesh data representative of the soil-structure system to be designed or analyzed.

Input commands C-1 and C-2 are control variables that are easily determined and entered into the input stream. Command C-3 is used repeatedly to define all nodal coordinates. Similarly, command C-4 is used repeatedly to define all element properties, and finally command C-5 is used as needed to define all displacement and force boundary conditions.

To assist the user, CANDE is equipped with many advanced mesh generation features that can greatly reduce the amount of labor in defining the input data. These features are discussed as they arise in commands C-3 and C-4.

Use if	Comments
A-1.LEVEL = 3	Use ONLY if the 'Solution Level' is set to 3.

Parameter (columns) (format) (units)	Input Options	Description
Preparation (WORD) (01-04) (A4,1X) (word)	A word to denote user defined mesh: = PREP, continue ≠ PREP, stop Default = stop	The control word PREP is a required word to continue inputting mesh data; otherwise CANDE will stop. For batch input files the word PREP distinguishes the beginning of Level 3 mesh input data. (Note the GUI automatically supplies this word without prompt by the user.)
Title (TITLE) (06-73) (17A4) (17 words)	User description of the mesh to built.	TITLE is printed out with mesh data as an aid to the user. TITLE may be any phrasing up to 68 characters.

Proceed to Line C-2

C-2.L3**Element number and property array**

Use if	Comments
A-1.LEVEL = 3	Use ONLY if the ‘Solution Level’ is set to 3.

Parameter (columns) (format) (units)	Input Options	Description
Number of load steps (NINC) (01-05) (15) (integer)	Number of load steps to be executed. Default = 1	Any number of load steps may be specified for execution in a given problem. Typically, the value of NINC matches the highest load step number defined in the element or loading schedule. However, NINC may be less than this number if desired.
Mesh output (MGENPR) (06-10) (15) (integer)	Control for print of mesh data to the CANDE output file: =1, control data =2, input data =3, created data =4, maximum Default = 3	MGENPR controls the amount of mesh data written to the CANDE output file. MGEN = 1, prints only the control information MGEN = 2, above plus node and element input MGEN = 3, above plus generated mesh data MGEN = 4, above plus Laplace generated nodes
Data check control (NPUTCK) (11-15) (15) (integer)	Control for data check only or run: = 0, run solution =1, data check only and stop Default = 0	During the course of processing input data, CANDE performs many checks on the validity of the input data. Some errors may be fatal such as an inside-out element other errors may just be a warning such as “skinny” elements. If the user desires to check the validity of the mesh without running the solution, set NPUTCK = 1
Plot file control (IPLOT) (16-20) (15) (integer)	Control for plot files units 10 & 30 =0, No plot files =1, Create 10 =2, Create 30 =3, Create 10 & 30 Note: For the GUI, this value is ALWAYS set to 3.	Unit 10 contains all the finite-element mesh data plus all the structural responses for each load step; it is intended as the data source for plotting mesh configurations, deformed shapes and contours. Unit 30 contains the detailed pipe responses (RESULT) at each node for each load step; it is intended as the data source for pipe response plots.

Parameter (columns) (format) (units)	Input Options	Description
Response data output (IWRT) (21-25) (15) (integer)	Control for print of response data to the CANDE output file: =0, minimal =1, standard =2, plus Duncan =3, plus interface	CANDE's output file is the primary source of readable output showing the structural responses at each load step. IWRT = 0 means only the pipe responses (RESULT) are printed, no soil-system responses. IWRT = 1 means the pipe responses plus the soil-system responses are printed (recommended). IWRT = 2 means the standard print plus an iteration trace of the Duncan-model soil elements. IWRT = 3 means the standard print plus an iteration trace of the Interface soil elements
Total number of nodes (NPT) (26-30) (15) (integer)	Total number of nodes defined in mesh. Default = none	NPT should correspond to the highest numbered nodal point used in the entire mesh. Note, it is permissible to skip node numbers so that not all sequential numbers correspond to a node used in the mesh. In this case set NPT = highest node number, not the actual node count.
Total number of elements (NELEM) (31-35) (15) (integer)	Total number of elements defined in mesh. Default = none	NELEM is the sum of all actual elements used in the mesh including beam elements (pipe), continuum elements (soil) and interface elements. Unlike nodes, the element count (NELEM) must exactly match the number of elements actually used in the mesh.
Total number of boundary conditions (NBPTC) (36-40) (15) (integer)	Total number of boundary conditions for this problem. Default = none	The actual count of boundary conditions is determined from the data in the C-5 input lines. NBPTC may be larger (but not smaller) than the actual number of conditions. Typically it is recommended to specify NBPTC as some sufficiently large number, say 200. If this number is insufficient, CANDE will provide a message.
Total number of soil materials (NSMAT) (41-45) (15) (integer)	Total number of soil materials Default = none	NSMAT is the total number of different soil material numbers to be identified in line C-4 with variable IX(5) for quadrilateral and triangular elements. This entry is only used by the GUI for Part D; it may be ignored for batch input.
Total number of interface materials (NXMAT) (46-50) (15) (integer)	Total number of interface materials Default = none	NXMAT is the total number of different interface materials numbers to be identified in line C-4 with variable IX(7) for interface elements. This entry is only used by the GUI for Part D; it may be ignored for batch input.

Parameter (columns) (format) (units)	Input Options	Description
Code to minimize bandwidth (MINBW) (51-55) (15) (integer)	Code for band-width minimizer: = 0, no action = 1, minimize = 2, min and print Default = 0	By setting MINBW > 0, CANDE will internally rearrange the user's node numbering scheme to minimize the bandwidth of the stiffness matrix. In all cases the output is displayed in the user's node numbering scheme. If MINBW = 2, the internal renumbering scheme is also displayed.

Proceed to line C-3

5.5.6.2 C-3 – Level 3 – Node Input**C-3.L3****Level 3 node input**

Repeat as necessary to define all nodes.

The options provided by input variables KRELAD and LGTYPE (see description below) activate the so-called advanced nodal generation methods provided by CANDE. For users who find these advanced options confusing or prefer to use just the basic node generation features, the KRELAD and LGTYPE variables may be completely ignored. That is, by defaulting the input for these two variables results in no action. The standard basic nodal generation is governed by the MODEG variable presented next.

Note, nodal numbers on line C-3 (NNP) may be input in any sequence, backward or forward. All nodes left undefined from the C-3 input but appear in C-4 element nodal-connectivity arrays will have their coordinates automatically determined by an averaging technique called Laplace generation. The same applies to those nodes identified with an LGTYPE =1 or 2

Use if	Comments
A-1.LEVEL = 3	Use ONLY if the ‘Solution Level’ is set to 3.

Parameter (columns) (format) (units)	Input Options	Description
Limit (LIMIT) (01-01) (A1) (letter)	Signal to indicate this is last node to be input: ≠ L, more C-3 lines to come. = L, this is last C-3 line. Default = blank	If LIMIT is a blank entry, then the program expects to read another line of C-3 nodal input. If LIMIT = L, this signals the program that this is the last nodal C-3 line to be processed after which the program advances to read element data in line C-4.
Node (NNP) (02-05) (I4) (integer)	Node number to be defined or referenced for node generation. Default = none	NNP may be a node number that is to be specified with x and y coordinates. Or, NNP may be a node number that has been previously defined and will be used as a beginning point to generate a sequence of nodes using data from the following line of C-3 data input. NNP may be any node number in the range of 1 to NPT.

Parameter (columns) (format) (units)	Input Options	Description
Special reference code (KRELAD) (06-08) (I3) (integer)	<p>Code number to allow options for defining NNP's coordinates:</p> <p>= 0, standard input without nodal reference</p> <p>=1, x-coordinate specified from previous node</p> <p>=2, y- coordinate specified from previous node</p> <p>=3, x and y- coordinates from previous nodes</p> <p>Default = 0</p>	<p>KRELAD is an advanced scheme that permits the coordinates of node NNP to be set equal to coordinates of previously defined nodes. Used with MODEG = 0 or 2.</p> <p>For KRELAD = 0, the actual x and y coordinates will be input by the user in variables XCOORD and YCOORD later in this the C-1 data line.</p> <p>For KRELAD = 1, the x coordinate of NNP will be set equal to the x coordinate of a previously defined node number entered into XCOORD.</p> <p>For KRELAD = 2, the y coordinate of NNP will be set equal to the y coordinate of a previously defined node number entered into YCOORD.</p> <p>For KRELAD = 3, the x coordinate of NNP will be set equal to the node entered into XCOORD and the y coordinate set equal to the node entered in YCOORD.</p>

Parameter (columns) (format) (units)	Input Options	Description
Special generation code (LGTYPE) (09-09) (I1) (integer)	<p>A code number to activate special node generation schemes:</p> <p>= 0, no special generation modes are activated.</p> <p>= 1, x-coordinates determined by Laplace scheme</p> <p>= 2, y-coordinates determined by Laplace scheme</p> <p>= 4, one quarter of an ellipse will be generated</p> <p>Default = 0</p>	<p>LGTYPE provides advanced nodal generation options that will automatically determine certain node coordinates between two consecutive lines of C-1 input. Used with MODEG = 2 or 3.</p> <p>For LGTYPE = 0, the special generation schemes are not activated. However the basic straight-line generation schemes are still available.</p> <p>For LGTYPE = 1 and MODEG = 2, the generated x-coordinates between NNP on the current C-3 line and NNP* from the previous C-3 line will be subsequently located by Laplace generation scheme. The y-coordinates will be immediately determined by the basic straight-line generation.</p> <p>For LGTYPE = 2 and MODEG = 2, the generated y-coordinates between NNP on the current C-3 line and NNP* from the previous C-3 line will be subsequently located by Laplace generation scheme. The x-coordinates will be immediately determined by the basic straight-line generation.</p> <p>For LGTYPE = 4 and MODEG = 2 or 3, the x- and y- nodal coordinates generated between NNP on the current C-3 line and NNP* from the previous C-3 line will be automatically determined to fit along the path of an elliptical quadrant. The elliptical quadrant is generated counterclockwise with convexity on the right when traveling from NNP* to NNP.</p>

Parameter (columns) (format) (units)	Input Options	Description
Basic generation code (MODEG) (10-10) (I1) (integer)	<p>Code number to select nodal input and generation of x & y coordinates</p> <p>= 0, basic input no generation</p> <p>=1, recalls NNP's coordinates from previous input, no generation</p> <p>=2, generates nodes between NNP* and NNP</p> <p>=3, generates nodes between NNP* and NNP previously known</p> <p>=5, input for generating non-sequential node numbers</p> <p>Default = 0</p>	<p>MODEG controls the basic options for node input and nodal generation of coordinates. The nodal generation refers to the spatially intermediate nodes between the current node number NNP and the previous node number NNP*</p> <p>For MODEG = 0, the x and y coordinates will be specified by the user in variables XCOORD and YCOORD. All other input variables in C-3 are irrelevant.</p> <p>For MODEG = 1, the coordinates for NNP are recalled from computer memory wherein it was previously input or generated. The motivation is to start a new generation sequence with this node serving as NNP*. All other input on this C-3 command is irrelevant.</p> <p>For MODEG = 2, the program will automatically generate the node numbers and coordinates between node number NNP* and NNP. The user has control over increment numbering, spacing, and line curvature with C-3 input variables.</p> <p>For MODEG = 3, the program will perform exactly like MODEG = 2 except that XCOORD and YCOORD need not be input for NNP because the coordinates will be recalled from memory. The remaining variables are specified as desired.</p> <p>For MODEG = 5, non-sequential numbering of generated nodes is permitted. This feature overrides the standard incrementing parameter NINC. To use MODEG = 5, first specify the previous node NNP* as always. Then repeatedly insert C-1 lines with MODEG = 5 and NNP = the desired node numbers until all interior nodes are identified. For the last node in the sequence use MOGEG = 2 or 3 and define the generation variables desired.</p>
X-coordinate/ Reference node (XCOORD) (11-20) (F10.0) (inches) (or node)	<p>X-coordinate for NNP (or reference node number for NNP)</p> <p>Default = none</p>	<p>Usually, XCOORD = the x-coordinate value in inches of node NNP specified on this C-3 line.</p> <p>For advanced generation if KRELAD = 1 or 3, then XCOORD = node number of a previously defined node with the same x-coordinate value.</p>

Parameter (columns) (format) (units)	Input Options	Description
Y-coordinate/ Reference node (YCOORD) (21-30) (F10.0) (inches) (or node)	Y-coordinate for NNP (or reference node number for NNP) Default = none	Usually, YCOORD = the y-coordinate value in inches of node NNP specified on this C-3 line. For advanced generation if KRELAD = 1 or 3, then YCOORD = node number of a previously defined node with the same y-coordinate value.
Increment (NPINC) (31-35) (I5,5X) (integer)	Increment added to generated nodes between NNP* and NNP (positive) Default = 1	When using MODEG = 2 or 3, NPINC is the increment “added” to each generated node between NNP* and NNP. Thus, the number of generated nodes = $\lfloor \text{NNP} - \text{NNP}^* \rfloor / \text{NPINC}$ and the last node is always numbered NNP as input. Incrementing will go in the negative direction if NNP* is greater than NNP, however NPINC must always be input as a positive integer.
Spacing (SPACNG) (41-50) (F10.0) (ratio)	Spacing ratio for generated node lengths Default = 1.0	When using MODEG = 2 or 3, the spacing ratio controls the distance between successive nodes. If SPACNG = 1, all nodes generated between NNP* and NNP will be evenly spaced. If SPACNG > 1 (or < 1), the successive distance between generated nodes will grow (or shrink) by the spacing ratio, respectively.
Radius (RADIUS) (51-60) (F10.0) (inches)	Path for node generation between NNP* and NNP: = 0.0, straight line ≠ 0.0, radius of circular arc. Default = 0.0	When using MODEG = 2 or 3, RADIUS controls the path along which the nodes are generated. If RADIUS = 0.0, the path is straight line between NNP* and NNP. If RADIUS is positive, then the path is a circular arc whose radius = RADIUS with convexity on the right in traveling from NNP* to NNP. Opposite curvature is obtained if RADIUS = negative value.

Proceed to line C-4.

5.5.6.3 C-4 – Level 3 – Element Input

C-4.L3**Level 3 element input**

Repeat as necessary to define all elements. **Unlike nodal number input, element number input and generation must be in sequential order, starting with element number 1 and ending with last element.**

Use if	Comments
A-1.LEVEL = 3	Use ONLY if the 'Solution Level' is set to 3.

Parameter (columns) (format) (units)	Input Options	Description
Limit (LIMIT) (01-01) (A1) (letter)	Signal to indicate the last element to be input: ≠ L, more C-4 lines to come. = L, this is last C-4 line. Default = blank	If LIMIT is a blank entry, then the program expects to read another line of C-4 element input. If LIMIT = L, this signals the program that this is the last element C-4 line to be processed after which the program advances to read boundary-condition data in line C-5.
Element Number (NE) (02-05) (14) (integer)	Element number to be defined Default = none	Each element in the mesh (regardless whether it be a quadrilateral, triangle, beam or interface element) is assigned a unique element number NE. Input for line C-4 must start with NE = 1, and subsequent values for NE must be in ascending order up to NELEM. Missing element numbers are automatically generated between NE* and NE where NE* is the input element number on the previous C-4 line. When numbering beam elements within a group of connected beam elements, the element numbering must progress from start of the sequence to the end of the sequence (see comment #1 below).
Node I (IX(1)) (06-10) (15) (integer)	Node I for element NE Default = none	IX(1) is the first node in the element connectivity array. All element types require a nonzero entry. See Figure 5.5-18 for element connectivity and comment #2 below.
Node J (IX(2)) (11-15) (15) (integer)	Node J for element NE Default = none	IX(2) is the second node in the element connectivity array. All element types require a nonzero entry. See Figure 5.5-18 for element connectivity and comment #2 below.

Parameter (columns) (format) (units)	Input Options	Description
Node K (IX(3)) (16-20) (15) (integer)	Node K for element NE Default = 0	IX(3) is the third node in the element connectivity array. For beam column elements IX(3) = 0 (default). For interface elements IX(3) = node number not shared with any other element, and IX(3) must be larger than either IX(1) or IX(2), preferably larger than both.
Node L (IX(4)) (21-25) (15) (integer)	Node L for element NE Default = 0	IX(4) is the fourth node in the element connectivity array. This only applies to quadrilateral elements. For all other element types set IX(4) = 0 (default)
Material Number (IX(5)) (26-30) (15) (integer)	Material identification number for element NE Default = none	Material identification numbers are associated with element types: Quadrilaterals and triangles, IX(5) = a material identification number ranging from 1 to 100. The soil model type and parameters of the soil model associated with IX(5) are defined by the user in Part D. Beam-Columns, IX(5) = a group number ranging from 1 to 30. The group numbers have already been established in Part A and B by defining one or more pipe types. If there is only one pipe group then set IX(5) = 1 for all beam-column elements. Interfaces, IX(5) = an interface property number ranging from 1 to 99. Two interface elements have the same property number if the friction coefficient, tension resistance and the angle of the interface are the same. Note that interfaces along curved surfaces have different interface angles at each element and, therefore, should be assigned a separate material property number. To be completed in Part D.
Load step (IX(6)) (31-35) (15) (integer)	Load step number for element NE Default = 1	The load step number defines the load step at which the element NE enters the system. Once the element enters the system it remains for all time. Typically the in situ soil zones and the culvert structure are assigned to the first load step, IX(6) = 1. The elements representing the first layer of fill soil are assigned IX(6) = 2, and so on
Interface (IX(7)) (36-40) (15) (integer)	Special code for interface element = 1, for interface element =0, for all other elements Default = 0	CANDE distinguishes one element type from the other by reading the number of nonzero entries in the nodal connectivity, IX(1)...IX(4). In order to distinguish the interface element from triangle element, set IX(7) = 1 to identify NE as an interface element.

Parameter (columns) (format) (units)	Input Options	Description
Node increment added (INTRAL) (41-45) (15) (integer)	Node increment added to compute node connectivity of a generated sequence of elements. Default = 1	Element numbers that are missing between NE and NE* (where NE* is the element number input on the previous C-4 line) are automatically generated with element numbers NE*+1, NE*+2, ... NE-1. The nodal connectivity of the generated elements is automatically computed by adding the value INTRAL to the node numbers (I, J, K, and L) of the previous element. The material number IX(5) and the load step IX(6) of the generated elements remain as specified on NE*. If it is desired to change the material number and/or load step in the generated sequence of elements, insert an intervening C-4 line specifying only the element number NE' where the change occurs along with the new values for IX(5) and IX(6). Do not input the nodal connectivity. Repeat as needed. See comment #3 below.
Number rows added (NUMLAY) (46-50) (15) (integer)	Number of element rows to be generated Default = 1	The automated computation of nodal connectivity for the generated elements may be extended over any number of rows by setting NUMLAY equal to the number of generated element rows. This option is used in conjunction the next variable INTERL, which specifies the "jump" in nodal numbering between rows.
Node increment between rows (INTERL) (51-55) (15) (integer)	Node number increment (jump) between element rows	When the element generation spans more than one row, the element nodal connectivity numbering of the new row has a "jump" value compared to the previous row. Set INTERL equal to the jump value. Typically, the jump value is the number of elements in the row plus 1. See Figure 5.5-19 for an example of the element generation variables.

Comment #1: Generally, the only purpose of numbering the elements is to identify them by their numbered name. For beam-column elements, however, the sequence of element numbering is also important because it establishes the local group numbering for the connected path of elements within the group. Beam-column elements are assigned to a group number by the input variable IX(5), introduced on next input page. The lowest numbered mesh-element number assigned to a beam-element group becomes element number 1 of the group's local numbering system. The second lowest mesh-element number assigned to the group becomes element number 2 of the group's local numbering system, and so on.

CANDE performs internal checks to make sure the beam-column elements that are assigned to a group do indeed form a sequence of elements, connected head-to-tail along some curvilinear path. If this is not the case, the user is notified of an input error.

The local numbering system for each group of beam-column elements is used to output data in sequential order for each group so that user can plot spatially-connected structural responses such as moment, thrust and shear diagrams.

Comment #2: There are four element types available in the CANDE program; the quadrilateral and triangle elements for representing soil (plane-strain solids), beam-column elements for representing culvert or structure, and interface elements for simulating sliding friction interfaces between structure and soil. Figure 5.5-18 illustrates these four elements and the nodal connectivity convention. As listed below, the nodal data in the so-called element connectivity array (IX(1), IX(2), IX(3), and IX(4)) are used to define each element type and distinguish one element type from another.

- (1) Quadrilateral: Input the four node numbers IX(1), IX(2), IX(3), and IX(4) connected to element NE in counterclockwise order.
- (2) Triangle: Input the three node numbers IX(1), IX(2), and IX(3) connected to element NE in counterclockwise order. Set IX(4) = 0 (default)
- (3) Beam-column: Input the two node numbers IX(1) and IX(2) connected to the ends of beam-element NE such that IX(1) is the “head node” advancing along the path of the connected beam-column elements, and IX(2) is the “tail node”, which trails behind the head node.
Set IX(3) = IX(4) = 0 (default)
- (4) Interface: Input two separate node numbers IX(1) and IX(2) representing two separate bodies on either side of a common interface usually sharing the same x,y spatial coordinates. If desired, however, the x,y coordinates may be separated to represent an initial gap between the bodies. Refer to input line D-2 of the interface material properties for the gap definition. In all cases, set IX(3) = to a node number not associated with any other element (node IX(3) will contain interface forces). Leave IX(4) = 0 (default). Lastly, set IX(7) = 1, which is how CANDE distinguishes the interface element from the triangle element since both have three non-zero nodal entries.


Node IX(3) of the interface must be assigned a node number that is larger than IX(1) or IX(2), preferably larger than both. This strange requirement is to avoid problems with the Gauss-elimination equation solver, which needs to process the stiffness degrees of freedom prior to pivoting on the unknown interface forces.

Comment #3: Up to this point (column 40 on line C-4), all the element properties have been defined including the nodal connectivity array, the material identification number and the load step number. The remainder of line C-4, provided on the next page, provides three element generation variables, named INTRAL, NUMLAY, and INTERL.


If the properties for each element were entered individually on a C-4 line, starting with element with #1 and ascending to the last element (NUMEL), then there would be no need for element generation and the following instructions may be left blank. However, CANDE has some very useful element generation techniques that greatly reduce the number of C4-lines that need be prepared.

Figure 5.5-19 shows an example of using the element generation variables to define the properties for 12 elements with two C-4 lines of input. Thus taking advantage of the element generation techniques is worth the effort to understand it.

Proceed to line C-5

Figure 5.5-18 - Level 3 – CANDE Elements with nodal connectivity

- **Quadrilateral:** 4 nodes with 2 translational d.o.f. per node
- **Triangle:** 3 nodes with 2 translational d.o.f. per node
- **Beam-column:** 2 nodes with 2 translational and one rotational d.o.f. per node
- **Interface:** 3 nodes with 2 translational d.o.f. for nodes I and J, and 2 interface forces for node K

Figure 5.5-19 – Level 3 – Illustration of element generation

Sample portion of mesh to be generated

The two C-4 lines of element input data shown below generate the 12 element mesh shown above

L	NE	IX(1)	IX(2)	IX(3)	IX(4)	IX(5)	IX(6)	IX(7)	INTRAL	NUMLAY	INTERL
.											
	20	101	102	107	106	1	1	0	0	0	0
	31	114	115	120	119	1	1	0	1	3	5
.											

5.5.6.4 C-5 – Level 3 – Boundary Condition Input**C-5.L3****Level 3 boundary condition input**

Repeat as necessary to define all boundary conditions.

The same boundary node NP may be repeated on subsequent C5 lines under the following rules:

- Each force boundary condition adds into the BIVD vector.
- A displacement boundary condition on any particular degree of freedom will override all previously specified force boundary condition.
- It is good practice to first specify force boundary conditions then displacement boundary conditions.

Use if	Comments
A-1.LEVEL = 3	Use ONLY if the 'Solution Level' is set to 3.

Parameter (columns) (format) (units)	Input Options	Description
Limit (LIMIT) (01-01) (A1) (letter)	Signal to indicate the last boundary-condition input: ≠ L, more C-5 lines to come. = L, this is last C-5 line. Default = blank	If LIMIT is a blank entry, then the program expects to read another line of C-5 boundary-condition input. If LIMIT = L, this signals the program that this is the last element C-5 line to be processed after which the program advances to read material property data in Part D
Node (NP) (02-05) (I4) (integer)	Node number where a boundary condition is to be specified. Default = none	NP may be any node number where either an imposed displacement constraint and/or a nonzero force boundary condition is to be imposed. Nodes that have no displacement constraints and no specified external forces do not require a C-5 line. NP may be repeated in subsequent C-5 lines.

Parameter (columns) (format) (units)	Input Options	Description
X-Code (IIFLG(1)) (06-10) (I5) (integer)	Boundary code for X-coordinate: = 0, x-force input (rotation free) = 1, x-disp. input (rotation fix) = 2, x-disp. input (rotation free) = 3, x-force input (rotation fix) Default = 0	If NP is only attached to continuum elements use IIFLG = 0 or 1 as needed. However if NP is also attached to a beam element (which includes rotational d.o.f.) use IIFLG = 0, 1, 2, or 3. Set IIFLG = 0 to specify an applied force in the x-direction. (rotational degree of freedom is free). Set IIFLG = 1 to specify a displacement in the x-direction. (rotational degree of freedom is fixed). Set IIFLG = 2 to specify a displacement in the x-direction. (rotational degree of freedom is free). Set IIFLG = 3 to specify an applied force in the x-direction. (rotational degree of freedom is fixed). See Table 5.5-7 for further understanding and summary of boundary condition codes.
X-Value (BIVD(1)) (11-20) (F10.0) (lb/in or inch)	Value of specified x-force or, x-displacement. Default = 0.0	If IIFLG(1) = 0 or 3, set BIVD(1) equal to the value of prescribed force in the x-direction, where the default is 0.0 lbs/inch. If IIFLG(1) = 1 or 2, set BIVD(1) equal to the value of displacement in the x-direction, where the default is 0.0 inches (fixed against x-motion)
Y-code (IIFLG(2)) (21-25) (I5) (integer)	Boundary code for Y-coordinate: = 0, y-force input (rotation free) = 1, y-disp. input (rotation fix) = 2, y-disp. input (rotation free) = 3, y-force input (rotation fix) Default = 0	If NP is only attached to continuum elements use IIFLG = 0 or 1 as needed. However if NP is also attached to a beam element (which includes rotational freedom) use IIFLG = 0, 1, 2, or 3. Set IIFLG = 0 to specify an applied force in the y-direction. (rotational degree of freedom is free). Set IIFLG = 1 to specify a displacement in the y-direction. (rotational degree of freedom is fixed). Set IIFLG = 2 to specify a displacement in the y-direction. (rotational degree of freedom is free). Set IIFLG = 3 to specify an applied force in the y-direction. (rotational degree of freedom is fixed). See Table 5.5-7 for further understanding and summary of boundary condition codes.

Parameter (columns) (format) (units)	Input Options	Description
Y-Value (BIVD(2)) (26-35) (F10.0) (lb/in or inch)	Value of specified y-force or, y-displacement. Default = 0.0	If IIFLG(2) = 0 or 3, set BIVD(2) equal to the value of prescribed force in the y-direction, where the default is 0.0 lbs/inch. If IIFLG(2) = 1 or 2, set BIVD(2) equal to the value of displacement in the y-direction, where the default is 0.0 inches (fixed against y-motion)
Angle of Rotation (THETA) (36-45) (F10.0) (degrees)	Angle of rotated coordinates to define boundary condition directions. Default = 0.0 deg	IF THETA = 0.0, the boundary conditions specified above refer to the global X-Y system. If THETA is specified nonzero the above boundary conditions are referred to a local x-y coordinate system that is rotated THETA degrees counterclockwise from the Global X-Y system. This is helpful for defining boundary conditions along sloped or skewed boundaries.
Load step (IA) (46-50) (I5) (integer)	Load step number when boundary condition is applied Default = 1	IA is the load step number that the boundary conditions defined on the current C-5 line are introduced into the system. Specified forces are applied only during load step IA and are not repeated on subsequent load steps. Specified displacements are applied during load step IA and remain in effect throughout the remaining steps.
Ending node (NNP) (51-55) (I5) (integer)	Ending node in a sequence of boundary conditions to be generated. Default = 0 (no action)	NNP is used to generate a sequence of identical boundary conditions starting with node number NP and ending at node number NNP. Boundary conditions are automatically generated for the intervening nodes (NP+1*INCR), (NP+2*INCR), (NP+3*INCR), ...NNP, where INCR is specified below. Note that NNP may be greater than or less than NP. However if NNP = 0, no generation will take place.
Node increment (INCR) (56-60) (I5) (integer)	Node increment used to generate boundary/conditions from NP to NNP (positive) Default = 1	INCR represents a uniform “jump” in nodal numbering along a path where boundary conditions are to be generated. INCR is input as a positive number and will automatically be set to a negative increment if NNP is less than NP.
Pressure at NP (PJ) (61-70) (F10.0) (lb/in ²)	Pressure magnitude at first node NP Default = 0.0 psi	Linear varying pressure loads can be specified between nodes NP and NNP (and the intervening generated nodes) by setting PJ = pressure at node NP and PK = pressure at node NNP. Pressure is normal to the line segment between successive pairs of nodes, remaining normal on curved surfaces. Positive pressure points to the left when traveling from NP to NNP.

Parameter (columns) (format) (units)	Input Options	Description
Pressure at NNP (PK) (71-80) (F10.0) (lb/in ²)	Pressure magnitude at second node NNP Default = 0.0 psi	If PK = PJ the pressure will be uniform over the surface from NP to NNP. Otherwise the pressure will vary linearly from the value PI at NP to the value PK at NNP. To use the pressure option, set IIFLG(1) = 0, and IIFLG(2) = 0

Comments:

- Any node that is not specified (or generated) on line C-5 is automatically assigned the force boundary code IIFLG (1) = IIFLG(2) = 0, and the specified external forces are set equal to zero, BIVD(1) = BIVD(2) = 0.
- For nodes that do not have beam elements attached (i.e., only quadrilaterals, triangles, and interface elements), there is no rotational degree of freedom associated with the node. Therefore, the first four rows in Table 5.5-7 provide the complete set of boundary condition options for specifying x and y forces and/or displacements.
- For nodes that do have a beam element attached, the user has the option to select a fixed rotation (clamped boundary) or free rotation (within the constraint of surrounding elements). The second set of rows in Table 5.5-7 allow the user to select the alternative rotational specification that was not provided in the first set. Note that rotational degree of freedom is automatically specified with either zero rotation or zero external moment. There is no provision in CANDE for specifying nonzero rotational boundary conditions.

Proceed to Part D**Table 5.5-7 – Classification of IIFLG Boundary Code numbers**

Input Code for node NP		Resulting implication for the variable BIVD and rotational degree of freedom		
X-direction IIFLG(1)	Y-direction IIFLG(2)	X-direction BIVD(1)	Y-direction BIVD(2)	Rotation (beam only)
0	0	Force	Force	(Free)
1	0	Disp.	Force	(Fixed)
0	1	Force	Disp.	(Fixed)
1	1	Disp.	Disp.	(Fixed)
3	3	Force	Force	(Fixed)
2	0	Disp.	Force	(Free)
0	2	Force	Disp.	(Free)
2	2	Disp.	Disp.	(Free)

5.6 Part D- Soil and/or Interface Property Input

This section provides input instructions for the soil and interface properties.

NOTE: This input is required for the following:

Use if	Comments
A-1.LEVEL = 2 or 3	<p>Use ONLY if the 'Solution Level' is set to 2 or 3.</p> <p>For Solution Level 2, the number of soil and interface elements is predetermined. The following sections provide descriptions on how many soil and interface materials are defined for each Level 2 mesh type.</p> <p>For Solution Level 3, the number of soil and interface materials is defined in section 5.5.6.1 and material numbers assigned to each element are defined in section 5.5.6.3.</p>
	This input is NOT required for Solution Level 1 or if there are <u>only</u> beam elements in the mesh.

INPUT OVERVIEW

- (1) Start at line D-1 to identify model type and identification data.
- (2) Proceed to line D-2 for the selected model type and complete input
 - Linear Elastic
 - Orthotropic Elastic
 - Duncan and Duncan/Selig
 - Overburden Dependent
 - Extended Hardin
 - Interface properties
- (3) Repeat steps 1 and 2 until all models are defined with input.

5.6.1 D-1 – Material Control Parameters for All Models

D-1
Material control parameters

Use if	Comments
A-1.LEVEL = 2 or 3	Use ONLY if the ‘Solution Level’ is set to 2 or 3.

Parameter (columns) (format) (units)	Input Options	Description
Limit (LIMIT) (01-01) (A1) (letter)	Signal to indicate the last material data input: ≠ L, more D-1 lines to come. = L, this is last D-1 line. Note: This value is not input in the GUI, but is determined implicitly.	If LIMIT is a blank entry, then the program expects to read another line of D-1 material input. If LIMIT = L, it signals the program that this is the last D-set of material data to be processed.
Material ID number (I) (02-05) (I4) (integer)	Material Zone identification number I No Default	Set I = material zone number to be characterized in this set of D lines. In Part C the continuum elements (quadrilaterals and triangles) have been assigned a material zone number ranging from 1 up to 100, and interface elements have been assigned a material number ranging from 1 to 999. For Level 2, material zone numbers were automatically assigned and are summarized in Table 5.6-2 and Table 5.6-3.

Parameter (columns) (format) (units)	Input Options	Description
Model Type (ITYP) (06-10) (I5) (integer)	Select material model to be associated with material zone I. =1, linear elastic (isotropic) =2, linear elastic (orthotropic) =3, Duncan and Selig models =4, Overburden dependent =5, Extended Hardin =6, Interface	Material zones composed of continuum elements may be assigned any of the material models, ITYP = 1, 2, 3, 4, or 5. Material numbers associated with interface elements must be assigned ITYP = 6. <ul style="list-style-type: none"> ▪ The elastic soil model is characterized by Young's modulus and Poisson's ratio. This model is often used for in situ soil. ▪ The orthotropic elastic model is characterized by four elastic parameters and an angle. This model is used in special cases such as soil reinforcement. ▪ Duncan and Duncan/Selig are nonlinear hyperbolic soil models that are extensively used to characterize backfill soil. ▪ The overburden soil model has elastic parameters whose stiffness properties are dependent on depth below the surface. Useful for deep embankments. ▪ Extended Hardin is a nonlinear hyperbolic soil model that includes parameters for degree of soil saturation. ▪ The interface model is characterized by a friction coefficient, tensile limit, and interface angle.
Density (DEN) (11-20) (F10.0) (lb/ft ³)	Density of material in zone I Default = 0.0 pcf	DEN is weight per cubic foot of the material in zone I, which is used to compute the gravity loads. For the fill soil in level 2 meshes, DEN should be equal to DENSITY defined in Part C. For interface elements, DEN is ignored.
Material name (MATNAM) (21-40) (5A4) (words)	Word or name to characterize the material zone and/or selection of model parameters Default none (See Table 5.6-1)	For ITYP = 1, 2 or 6, MATNAM is any user defined name that will be displayed with material zone number. For ITYP = 3, 4 and 5, MATNAM is a special command word used to signal CANDE which set of built-in parameters for the soil model are desired, or a command that signals user input. The special MATNAM names are summarized in Table 5.6-1 and further elaborated in line D-2. Note that the MATNAMs start in column 21 and are composed of 4 or 5 capital letters and/or numbers.

Parameter (columns) (format) (units)	Input Options	Description
Number of layers (overburden only) (41-42) (I2) (integer)	Number of layers used when Material Model Type 'overburden' is used. Note: This number is only required by the GUI for overburden dependent type soils.	Enter the number of layers that will be input for D-2 for overburden soil model type.

Proceed to line D-2

Table 5.6-1 – Summary of special material names (MATNAM)

Material ITYP	MATNAM to signal user input of model parameters	Special MATNAMs to select built-in parameters for various soil types and compaction levels	Description of special MATNAMs
ITYP = 3 ●Duncan (1980)	USER	CA105, CA95, CA90 SM100, SM90, SM85 SC100, SC90, SC85 CL100, CL90, CL85	CA=Coarse aggregates SM=Silty sands SC=Silty clayey sand CL=Silty clay (Number = % compaction T-99)
ITYP = 3 ●Duncan/Selig	USER	SW100, SW95, SW90, SW85, SW80, ML95, ML90, ML85, ML80, ML50 CL95, CL90, CL85, CL80	SW=Gravelly sand ML=Sandy silt CL=Silty clay (Number = % compaction T-99)
ITYP = 4 ●Overburden-dependent	USER	GGOOD, GFAIR MGOOD, MFAIR CGOOD, CFAIR	G=Granular soil M=Mixed soil C=Cohesive soil
ITYP = 5 ●Extended Hardin	USER	GRAN MIXED COHE	Granular soil Mixed soil Cohesive soil

Comments:

1. Detailed information on the “built-in” soil model parameters are provided in the D-2 section associated with each model type.
2. For ITYP = 3, the user distinguishes the Duncan-1980 version from the Duncan-Selig version by the parameter IBULK defined in line D2.
3. For ITYP = 4, input line D-2 is not required unless the user selected MATNAM = USER. The built-in parameters for the special MATNAMs are shown in Table 5.6-6.
4. For ITYP = 5, input line D-2 depends on whether MATNAM is a special name or MATNAM is defined as USER.

Table 5.6-2 – Material numbers for predefined level 2 material zones

Mesh Type	In situ soil material zone number	Bedding material zone number	Backfill soil material zone number	Special zone numbers
PIPE (NPCAN=1) • Homogenous • Embankment • Trench	1 1 1	1 2 2	1 3 3	- 4 (Backpack) 4 (Overfill)
BOX (NPCAN=2) • Embankment • Trench	1 1	2 2	3 3	- -
ARCH (NPCAN=3) • Homogenous • Embankment • Trench	1 1 1	- - -	1 3 3	- 2 (Footing) 2 (Footing)

Table 5.6-3 – Material numbers for predefined Level 2 interface numbers

Mesh Type (Selected in Part C)	Material number range	Description of interface material numbers
PIPE (NPCAN=1) • SLIP • SLPT	1 to 11 1 to 7	The SLIP command inserts 11 interface elements between soil and pipe. Interface material # 1 starts at the invert and progresses to # 11 at the crown; each element has a unique normal angle. The SLPT command inserts 7 interface elements between the trench wall and backfill soil. Interface material # 1 starts at the spring line and progresses to # 7 at the top of the trench, each material number requires input data.
BOX (NPCAN=2)	None	NOTE: For level 2 Box mesh, no interface elements are generated. Therefore, interface materials are not required for this mode.
ARCH (NPCAN=3) (interface is always included in mesh)	1 to 19	The Arch mesh automatically includes interface elements between the arch and surrounding soil for all mesh options. Interface material # 1 starts at the crown and proceeds down and around the arch to material # 19 located one node above the footing. Each element has a unique normal angle. If it is desired to simulate a bonded condition between the soil and the structure, insert large values for the tension resistance and friction coefficient (say, 1000.0)

Comment on soil resistance factor for LRFD = 1: The LRFD specifications states that soil stiffness values should be reduced by a resistance factor, $\phi_{\text{soil}} = 0.9$. However, all the canned and tabularized soil parameters in this manual and in the CANDE-2007 program are conservative approximations of the actual soil being represented. Thus further reduction of the canned or tabularized soil parameters by a resistance factor is not recommended since it may be assumed the resistance factor is already built in the model.

If the user wishes to reduce the soil stiffness by a soil resistance factor, then the user must input the key soil parameter with a value reduced by the factor ϕ_{soil} . For line D2 the key soil parameters for the five soil models are listed below:

- For ITYP = 1; input $E = \phi_{\text{soil}} * E_{\text{actual}}$
- For ITYP = 2 ; input $CP(i,j) = \phi_{\text{soil}} * CP(i,j)_{\text{actual}}$, for all i and j, 1 to 3
- For ITYP = 3; input $ZK = \phi_{\text{soil}} * ZK_{\text{actual}}$
- For ITYP = 4; input $E(n) = \phi_{\text{soil}} * EN(n)_{\text{actual}}$, for n = 1,2,3 ...
- For ITYP = 5; input $S1 = \phi_{\text{soil}} * S1_{\text{actual}}$

The above equations show the user the primary stiffness parameter for each soil model. If desired, the user may input a reduced value of the primary stiffness parameter to account for a soil resistance factor.

5.6.2 D-2 – Isotropic Linear Elastic – Elastic Parameters

D-2.Isotropic

Isotropic elastic parameters

Use if	Comments
A-1.LEVEL = 2 or 3	Use ONLY if the ‘Solution Level’ is set to 2 or 3.
D-1.ITYP = 1	Use only if the Material Model Type is Elastic Isotropic (1).

Parameter (columns) (format) (units)	Input Options	Description
Young’s modulus (E) (01-10) (F10.0) (lb/in ²)	Young’s modulus of material in zone I Default = 0.0 psi	Young’s modulus is the vertical stress per unit of vertical strain of a vertically loaded test specimen while maintaining no change in lateral pressure on the material specimen. See Table 5.6-6 for reasonable values.
Poisson’s ratio (GNU) (11-20) (F10.0) (--)	Poisson’s ratio of material in zone I Default = 0.0	Poisson’s ratio is the lateral strain divided by vertical strain of a vertically loaded test specimen while maintaining no change in lateral pressure on the material specimen.

Comment: The isotropic, linear elastic stress-strain relationship for plane strain is ultimately expressed by Young’s modulus (E) and Poisson’s ratio (ν) as follows:

$$\begin{Bmatrix} \sigma_x \\ \sigma_y \\ \tau \end{Bmatrix} = \begin{pmatrix} M_s & K_0 M_s & 0 \\ K_0 M_s & M_s & 0 \\ 0 & 0 & G \end{pmatrix} \begin{Bmatrix} \varepsilon_x \\ \varepsilon_y \\ \gamma \end{Bmatrix}$$

where, $M_s = E(1 - \nu)/((1 + \nu)(1 - 2\nu))$... Confined modulus
 $K_0 = \nu/(1 - \nu)$ Lateral Coefficient
 $G = E/(2(1 + \nu))$ Shear Modulus

And σ_x, σ_y, τ = two-dimensional engineering stress vector
 $\varepsilon_x, \varepsilon_y, \gamma$ = two-dimensional engineering strain vector

Return to line D-1 for more material definition if needed.

Proceed to Part E if LRFD = 1

Otherwise this completes the input stream for this problem (insert STOP command, line A-1).

5.6.3 D-2 – Orthotropic Linear Elastic – Elastic Parameters

D-2.Orthotropic**Orthotropic elastic parameters**

Use if	Comments
A-1.LEVEL = 2 or 3	Use ONLY if the ‘Solution Level’ is set to 2 or 3.
D-1.ITYP = 2	Use only if the Material Model Type is Orthotropic (2).

Parameter (columns) (format) (units)	Input Options	Description
Elastic parameter at position (1,1) (CP(1,1)) (01-10) (F10.0) (lb/in ²)	Elastic parameter at matrix position (1,1) Default = 0.0 psi	Confined modulus in x-direction (lateral). See constitutive relationship in matrix below.
Elastic parameter at position (1,2) (CP(1,2)) (11-20) (F10.0) (lb/in ²)	Elastic parameter at matrix position (1,2) Default = 0.0 psi	Orthogonal x-y stiffness modulus. See constitutive relationship in matrix below.
Elastic parameter at position (2,2) (CP(2,2)) (21-30) (F10.0) (lb/in ²)	Elastic parameter at matrix position (2,2) Default = 0.0 psi	Confined modulus in y-direction (vertical). See constitutive relationship in matrix below.
Elastic parameter at position (3,3) (CP(3,3)) CP(3,3) (31-40) (F10.0) (lb/in ²)	Elastic parameter at matrix position (3,3) Default = 0.0 psi	Shear modulus. See constitutive relationship in matrix below
Angle of material axis (THETA) (41-50) (F10.0) (lb/in ²)	Angle of material axis. Default = 0.0 deg	Theta = the angle that material axis makes with the global x-y axis. Typically, the material axis is aligned the global axis so that the default value is appropriate.

Comment: Orthotropic elastic properties are useful when the stiffness in the vertical direction differs from the stiffness in the lateral direction such as when reinforced earth is used to stiffen the soil in the lateral direction. The matrix is symmetric.

$$\begin{Bmatrix} \sigma_x \\ \sigma_y \\ \tau \end{Bmatrix} = \begin{pmatrix} CP(1,1) & CP(1,2) & 0 \\ CP(1,2) & CP(2,2) & 0 \\ 0 & 0 & CP(3,3) \end{pmatrix} \begin{Bmatrix} \varepsilon_x \\ \varepsilon_y \\ \gamma \end{Bmatrix}$$

And σ_x, σ_y, τ = two-dimensional engineering stress vector
 $\varepsilon_x, \varepsilon_y, \gamma$ = two-dimensional engineering strain vector

Return to line D-1 for more material definition if needed.

Proceed to Part E if LRFD = 1

Otherwise this completes the input stream for this problem, insert STOP command.

5.6.4 Duncan and Duncan/Selig Model Types

5.6.4.1 D-2 – Duncan – Fundamental Controls

D-2.Duncan
Duncan fundamental controls

Use if	Comments
A-1.LEVEL = 2 or 3	Use ONLY if the ‘Solution Level’ is 2 or 3.
D-1.ITYP = 3	Use only if the Material Model Type is Duncan/Selig(3).

Parameter (columns) (format) (units)	Input Options	Description
LRFD stiffness control (NON) (01-05) (15) (integer)	LRFD control for material stiffness : = 0, service load = 1, factored load Default = 0 (recommended)	This control only applies to LRFD = 1. Selecting NON = 0 signals the soil model to adjust its stiffness based on service-load stresses, not the higher factored stresses. Conversely if NON = 1, the factored stresses are used to compute each element soil stiffness. The default value is recommended.
Moduli averaging ratio (RATIO) (06-15) (F10.0) (--)	Moduli averaging ratio. Default = 0.5	During the iteration process CANDE determines the effective soil modulus over each load step as a weighted average of the tangent stiffness at the start and at the end of the load step. Setting RATIO = 0.5 is generally recommended and means an evenly balanced average. However, if one is modeling pre-existing soil (such as in-situ soil or beddings), then it is more appropriate to set RATIO = 1.0. This only applies to the first load step then automatically reverts back to RATIO = 0.5 on subsequent load steps.

Parameter (columns) (format) (units)	Input Options	Description
Soil model (IBULK) (16-20) (15) (integer)	<p>Selection of Duncan or Duncan/Selig soil model:</p> <p>= 0, Duncan formulation</p> <p>= 1, Duncan/Selig formulation</p> <p>(Default = 0)</p>	<p>The Duncan and Duncan/Selig models are the two most popular models used for characterizing the stress dependent stiffness of backfill soil in culvert installations. The models are very similar.</p> <p>Setting IBULK = 0 selects the Duncan hyperbolic model for tangent Young's modulus along with Duncan's power law for the tangent bulk modulus. See Table 5.6-4 for built-in parameters associated with MATNAM</p> <p>Setting IBULK = 1 selects the Duncan hyperbolic model for tangent Young's modulus along with Selig's hyperbolic law for tangent bulk modulus See Table 5.6-5 for built-in parameters associated with MATNAM</p> <p>If MATNAM = USER additional input information is required.</p>

If MATNAM = USER, proceed to lines D-3 and D-4

Otherwise input is complete for this material, next step options:

- **Return to line D-1 for more material input, or**
- **If LRFD= 1, Proceed to Part E, otherwise**
- **Input is complete, insert STOP command (line A-1)**

Table 5.6-4 – Material names (MATNAM) and values for Duncan model (IBULK=0)

MATNAM (word)*	Young's Tangent Modulus Parameters						Bulk Parameters		Density reference (lb/ft ³)
	K (--)	n (--)	C (psi)	ϕ_0 (deg)	$\Delta\phi$ (deg)	R_f (--)	K_b (--)	m (--)	
CA105	600	0.40	0.0	42	9	0.7	175	0.2	150
CA95	300	0.40	0.0	36	5	0.7	75	0.2	140
CA90	200	0.40	0.0	33	3	0.7	50	0.2	135
SM100	600	0.25	0.0	36	8	0.7	450	0.0	135
SM90	300	0.25	0.0	32	4	0.7	250	0.0	125
SM85	150	0.25	0.0	30	2	0.7	150	0.0	120
SC100	400	0.60	3.5	33	0	0.7	200	0.5	135
SC90	150	0.60	2.1	33	0	0.7	75	0.5	125
SC85	100	0.60	1.4	33	0	0.7	50	0.5	120
CL100	150	0.45	2.8	30	0	0.7	140	0.2	135
CL90	90	0.45	1.4	30	0	0.7	80	0.2	125
CL85	60	0.45	0.7	30	0	0.7	50	0.2	120

*MATNAM is composed of two letters and a number defined as follows:

CA = Course Aggregates, SM = Silty Sand, SC = Silty-Clayey Sand and CL = Silty Clay

Number = percent relative compaction, per AASHTO T-99

Table 5.6-5 – Material names (MATNAM) and values for Duncan/Selig model (IBULK=1)

MATNAM (word)**	Young's Tangent Modulus Parameters						Bulk Parameters***		Density reference (lb/ft ³)
	K (--)	n (--)	C (psi)	ϕ_0 (deg)	$\Delta\phi$ (deg)	R_f (--)	B_i/P_a (--)	ε_u (--)	
SW100	1300	0.90	0.0	54	15	0.65	108.8	0.01	148
SW95	950	0.60	0.0	48	8.0	0.70	74.8	0.02	145
SW90	640	0.43	0.0	42	4.0	0.75	40.8	0.05	140
SW85	450	0.35	0.0	38	2.0	0.80	12.7	0.08	130
SW80	320	0.35	0.0	36	1.0	0.90	6.1	0.11	120
ML95	440	0.40	4.0	34	0.0	0.95	48.3	0.06	135
ML90	200	0.26	3.5	32	0.0	0.89	18.4	0.10	130
ML85	110	0.25	3.0	30	0.0	0.85	9.5	0.14	122
ML80	75	0.25	2.5	28	0.0	0.80	5.1	0.19	115
ML50	16	0.95	0.0	23	0.0	0.55	1.3	0.43	66
CL95	120	0.45	9.0	15	4.0	1.00	21.2	0.13	130
CL90	75	0.54	7.0	17	7.0	0.94	10.2	0.17	125
CL85	50	0.60	6.0	18	8.0	0.90	5.2	0.21	120
CL80	35	0.66	5.0	19	8.5	0.87	3.5	0.25	112

**MATNAM is composed of two letters and a number defined as follows:

SW = Gravelly Sand, ML = Sandy Silt, and CL = Silty Clay

Number = percent relative compaction, per AASHTO T-99

*** Selig's bulk parameters are the original "hydrostatic" values that are more generally accepted than his subsequent set of "modified" values. Some investigators believe the original hydrostatic values are better for design because they are conservative.

5.6.4.2 D-3 – Duncan/Duncan Selig – Parameters for Tangent Young's Modulus

D-3.Duncan**Duncan/Duncan Selig parameters for tangent Young's Modulus**

Use if	Comments
A-1.LEVEL = 2 or 3	Use ONLY if the 'Solution Level' is 2 or 3.
D-1.ITYP = 3	Use only if the Material Model Type is Duncan or Duncan/Selig(3) .
D-1.MATNAM =USER	Use only if the Material Name (MATNAM) is defined as USER .

Parameter (columns) (format) (units)	Input Options	Description
Cohesion intercept (C) (01-10) (F10.0) (lb/in ²)	Cohesion intercept Default = 0.0 psi	Data to fit the tangent young's modulus model is generally obtained from a series of soil tri-axial tests. C = cohesion intercept of the shear failure surface versus normal stress, noted as c in the equation below.
Initial friction angle (PHIO) (11-20) (F10.0) (degrees)	Initial friction angle Default = 0.0 deg	PHIO = initial angle of the of the shear failure surface versus normal stress, noted as ϕ_0 in the equation below.
Reduction of friction angle (DPHI) (21-30) (F10.0) (degrees)	Reduction of friction angle Default = 0.0 deg	DPHI = the reduction in initial friction angle for a 10-fold increase in confining pressure, noted as $\Delta\phi$ in the equation below.
Magnitude of initial tangent modulus (ZK) (31-40) (F10.0) (dimensionless)	Magnitude of initial tangent modulus Default = 0.0	ZK = the initial tangent modulus parameter related to scalar magnitude, noted as K in the equation below.
Exponent for initial tangent modulus (ZN) (41-50) (F10.0) (dimensionless)	Exponent for initial tangent modulus Default = 0.0	ZN = the exponent for the power law characterizing the initial tangent modulus, noted as n in the equation below.

Parameter (columns) (format) (units)	Input Options	Description
Ratio of actual failure stress to model's ultimate (RF) (51-60) (F10.0) (dimensionless)	Ratio of actual failure stress to model's ultimate stress limit	RF = ratio of observed failure stress to the ultimate asymptotic failure stress that characterizes the model, noted as R_f in the equation below.

Basic Equations for Tangent Young's modulus:

- Tangent modulus: $E_t = E_i(1 - R_f(1 - \sin\phi)(\sigma_1 - \sigma_3)/(2C\cos\phi + 2\sigma_3 \sin\phi))^2$
- Initial modulus: $E_i = KP_a(\sigma_3/P_a)^n$
- Friction angle (rads): $\phi = \phi_0 - \Delta\phi \log_{10}(\sigma_3/P_a)$
- Where σ_1 and σ_3 are principal stresses and P_a is atmospheric pressure (14.7 psi),

Proceed to line D-4

5.6.4.3 D-4 – Duncan/Duncan Selig – Parameters for Tangent Bulk Modulus

D-4.Duncan**Duncan/Duncan Selig parameters for tangent bulk Modulus**

Use if	Comments
A-1.LEVEL = 2 or 3	Use ONLY if the ‘Solution Level’ is 2 or 3.
D-1.ITYP = 3	Use only if the Material Model Type is Duncan/Selig(3).
D-1.MATNAM =USER	Use only if the Material Name (MATNAM) is defined as USER .

Parameter (columns) (format) (units)	Input Options	Description
Magnitude of tangent bulk modulus (BK) (01-10) (F10.0) (dimensionless)	Magnitude of tangent bulk modulus: = K_b , Duncan power law = B_i / P_a , Selig hyper form Default = 0.0	The entry for BK must be consistent with the previous choice for IBULK. For IBULK = 0, set BK to Duncan’s magnitude number, noted as K_b in the equation below. For IBULK = 1, set BK to Selig’s magnitude ratio, noted as B_i / P_a in the equation below.
Bulk modulus parameter , m, Duncan Power Law (BM) (11-20) (F10.0) (dimensionless)	Bulk modulus parameter depending on previous choice of Duncan or Duncan/Selig models: = m, Duncan power law = ϵ_u , Selig hyper form Default = 0.0	The entry for BM must be consistent with the previous choice for IBULK. For IBULK = 0, (Duncan form) set BM to Duncan’s power law exponent, noted as m in the equation below. For IBULK = 1, (Duncan/Selig form) set BM to Selig’s ultimate volumetric strain, noted as ϵ_u in the equation below
Alternate form using constant Poisson’s ratio (VT) (21-30) (F10.0) (dimensionless)	Alternate form using constant Poisson’s ratio Default = 0.0	As an alternative to either of the variable bulk modulus functions above, the user may select a constant Poisson’s ratio to be used with the tangent Young’s modulus. By setting VT to a positive Poisson’s ratio, the bulk modulus functions will not be used. This is the so-called original Duncan model.

Basic Equations for Tangent Bulk modulus:

Power law (Duncan): $B_t = P_a K_b (\sigma_3 / P_a)^m$, where σ_3 is minimum principal stress.

Hyperbolic form (Selig): $B_t = P_a (B_i / P_a) (1 + \sigma_m / (B_i \varepsilon_u))^2$, where σ_m is average stress.

Return to line D-1 for more material definition if needed.

Proceed to Part E if LRFD = 1

Otherwise, this completes the input stream for this problem – insert STOP command.

5.6.5 D-2–Overburden Dependent–User Defined Elastic Prop. vs. Overburden Pressure

D-2.Over

Overburden dependent user defined elastic properties vs. overburden pressure

Note: if a special MATNAM was selected; skip this D-2 input line.

Use if	Comments
A-1.LEVEL = 2 or 3	Use ONLY if the 'Solution Level' is 2 or 3.
D-1.ITYP = 4	Use only if the Material Model Type is Overburden Dependent (4).
D-1.MATNAM =USER	Use only if the Material Name (MATNAM) is defined as USER.

Parameter (columns) (format) (units)	Input Options	Description
Last item indicator (LIMIT) (NOTE: This input is specific to the GUI)	Enter an 'L' to indicate this is the last overburden dependent row to be entered.	Once an 'L' is encountered, all subsequent rows in the table will be ignored.
Overburden pressure (H(N)) (01-10) (F10.0) (lb/in ²)	Overburden pressure for table entry N, where N = 1 to X (No default)	Line D-2 is only required for MATNAM = USER. For other special MATNAMs no additional input is required. See values in Table 5.6-6. Starting with N = 1, set H(N) equal to the overburden pressure associated with the elastic properties entered below. Repeat line D-2 to develop a table of X entries with increasing overburden pressure. The range is: X minimum = 2, X maximum = 10.
Young's modulus (E(N)) (11-20) (F10.0) (lb/in ²)	Young's modulus for table entry N (No default)	Moduli values should correspond to secant values obtained from confined compression tests (uniaxial strain). Secant values are the straight lines connecting the origin to the total stress-strain curve at the overburden pressure H(N). Note the secant's slope is the confined modulus, which must be converted to Young's modulus. The goal is to develop an input table like those shown in Table 5.6-6.

Parameter (columns) (format) (units)	Input Options	Description
Poisson's ratio (PGNV(N)) (21-30) (F10.0) (---)	Poisson's ratio for table entry N (No default)	Usually Poisson's ratio remains relatively constant as overburden pressure increases. Typical values: <ul style="list-style-type: none"> • Granular: 0.30 to 0.35 • Mixed: 0.30 to 0.40 • Cohesive: 0.33 to 0.40
Last Table Entry (XEND) (31-33) (A3) (word)	Last table entry = END, end D-2. = blank, continue to read D-2 lines	Line D-2 will continue to be read by the program until the word "END" is encountered in columns 31 to 33. (NOTE: The GUI automatically inserts the value based if an 'L' input in the first parameter (LIMIT).

Comment: The overburden dependent model is only valid in soil zones that are essentially experiencing one-dimensional compression (uni-axial strain) such as an embankment soil zone that is outside the influence of soil structure interaction. The advantage of the overburden dependent model is that iterations are not required to advance the load step because the overburden stress acting on each element is assumed to be statically determinate based the current height of soil cover above each element. Accordingly, the appropriate incremental elastic properties are interpolated directly from the input table of properties.

Return to line D-1 for more material definition if needed.

Proceed to Part E if LRFD = 1

Otherwise, this completes the input stream for this problem.

Table 5.6-6 – Material names (MATNAM) and values for Overburden Dependent Model

Soil Class→ Compaction→ MATNAM→	Granular		Mixed		Cohesive	
	Good	Fair	Good	Fair	Good	Fair
	GGOOD	GFAIR	MGOOD	MFAIR	CGOOD	CFAIR
Overburden Pressure psi	Young's Modulus psi	Young's Modulus psi	Young's Modulus psi	Young's Modulus psi	Young's Modulus psi	Young's Modulus psi
5	1,100	550	600	400	250	150
10	1,300	750	850	550	325	200
15	1,500	850	1,000	600	375	225
20	1,650	1,000	1,100	700	375	250
25	1,800	1,100	1,200	750	400	250
30	1,900	1,150	1,250	800	400	250
40	2,100	1,300	1,350	900	400	250
50	2,250	1,400	1,450	900	400	250

Comments

- Three soil classes are identified as Granular, Mixed, and Cohesive and each soil class is characterized with two broad levels of compaction Good and Fair. The intent is to provide a set of conservative soil properties for design if there is not specific soil data to develop a user defined table.
- The first letter in the special MATNAM names represents the soil class and the remaining four letters represent the compaction level.
- The entries in Table 5.6-6 are the secant values of Young's modulus for soils in a state of confined compression (uniaxial strain). In CANDE the secant values are converted to chord values for incremental stress-strain relationships.
- In all cases Poisson's ratio is assumed constant with overburden pressure and set equal to 0.33
- For the case MATNAM = USER, then the user completes a set of D-2 cards that provides input information similar to one of the MATNAM columns in the above table.

5.6.6 D-2 – Extended Hardin Soil Model

If MATNAM is defined with a “Special Name” use line D-2 entitled, “Hardin Soil Model Input for Special MATNAM”, listed directly below. Otherwise, if MATNAM is defined as USER proceed to line D-2 entitled, “Hardin Soil Model Input for MATNAM = USER”.

5.6.6.1 D-2 – Hardin Soil Model Input for Special MATNAM

D-2.Hardin
Extended Hardin Poisson’s ratio parameters and physical soil property input

Use if	Comments
A-1.LEVEL = 2 or 3	Use ONLY if the ‘Solution Level’ is 2 or 3.
D-1.ITYP = 5	Use only if the Material Model Type is Extended Hardin (5).
D-1.MATNAM =GRAN, MIXE or COHE	Use only if the Material Name (MATNAM) is defined as ‘granular soil’ (GRAN), ‘mixed soil’ (MIXE) or ‘cohesive soil’ (COHE).

Parameter (columns) (format) (units)	Input Options	Description
Poisson’s ratio for low shear strain. (XNUMIN) (01-10) (F10.0) (dimensionless)	Poisson’s ratio for low shear strain. Default = 0.01 for GRAN, MIXE, and COHE	XNUMIN is a parameter for the hyperbolic Poisson ratio function representing the minimum value of Poisson’s ratio at low shear strain. The default value was calibrated for sand (MATNAM=GRAN), but may be used for mixed and cohesive soils.
Poisson’s ratio for high shear strain (XNUMAX) (11-20) (F10.0) (dimensionless)	Poisson’s ratio for high shear strain. Default = 0.49 for GRAN, MIXE, and COHE	XNUMAX is a parameter for the hyperbolic Poisson ratio function representing the maximum value of Poisson’s ratio at high shear strain. The default value was calibrated for sand (MATNAM=GRAN), but may be used for mixed and cohesive soils.
Shape parameter for Poisson ratio function (XQ) (21-30) (F10.0) (dimensionless)	Shape parameter for Poisson ratio function. Default = 0.26 for GRAN, MIXE, and COHE	XQ is a shape parameter for the hyperbolic Poisson ratio function, which increases the rate of the Poisson value between the low and high limits. The default value was calibrated for sand (MATNAM=GRAN), but may be used for mixed and cohesive soils.
Void ratio of soil (VOIDR) (31-40) (F10.0) (dimensionless)	Void ratio of soil. Default values: = 0.60 GRAN = 0.50 MIXE = 1.00 COHE	Void ratio is the ratio of void space per unit volume divided solid space per unit volume. Values for VOIDR may range is from 0.1 to 3.0. Increased values of VOIDR result in decreased values of the secant shear stiffness.

Parameter (columns) (format) (units)	Input Options	Description
Saturation ratio (SAT) (41-50) (F10.0) (dimensionless)	Saturation ratio. Default values: = 0.00 GRAN = 0.50 MIXE = 0.90 COHE	SAT is ratio of void space filled with water. Values for SAT may range is from 0.0 to 1.0. Increased values of SAT result in decreased values of the secant shear stiffness.
Plasticity index (PI) (51-60) (F10.0) (dimensionless)	Plasticity Index of soil Default values: = 0.00 GRAN = 0.05 MIXE = 0.20 COHE	PI is the standard plasticity index of soil determined in laboratory tests. Values for PI may range is from 0.0 to 1.0. Increased values of PI result in decreased values of the secant shear stiffness.
Nonlinear iteration control (NON) (61-65) (I5) (integer)	Print control parameter Default = 0	Currently not operative. Use default.

Input complete for Extended Hardin model (MATNAM = GRAN, MIXE, or COHE)

Return to line D-1 for more material definition if needed.

Proceed to Part E if LRFD = 1

Otherwise, this completes the input stream for this problem.

5.6.6.2 D-2 – Hardin Soil Model Input for MATNAM = USER

D-2.Hardin.TRIA**Hardin Poisson's Ratio and secant shear modulus parameters**

Use if	Comments
A-1.LEVEL = 2 or 3	Use ONLY if the 'Solution Level' is 2 or 3.
D-1.ITYP = 5	Use only if the Material Model Type is Extended Hardin (5).
D-1.MATNAM = USER	Use only if the Material Name (MATNAM) is defined as USER .

Parameter (columns) (format) (units)	Input Options	Description
Poisson's ratio for low shear strain (XNUMIN) (01-10) (F10.0) (dimensionless)	Poisson's ratio for low shear strain. Default = 0.01	XNUMIN is a parameter for the hyperbolic Poisson ratio function representing the minimum value of Poisson's ratio at low shear strain. The default value was calibrated for sand.
Poisson's ratio for high shear strain (XNUMAX) (11-20) (F10.0) (dimensionless)	Poisson's ratio for high shear strain. Default = 0.49	XNUMAX is a parameter for the hyperbolic Poisson ratio function representing the maximum value of Poisson's ratio at high shear strain. The default value was calibrated for sand.
Shape parameter for Poisson ratio function (XQ) (21-30) (F10.0) (dimensionless)	Shape parameter for Poisson ratio function. Default = 0.26	XQ is a shape parameter for the hyperbolic Poisson ratio function, which increases the rate of the Poisson value between the low and high limits. The default value was calibrated for sand.
Hardin parameter for hyperbolic shear modulus (S1) (31-40) (F10.0) (number)	Hardin parameter for hyperbolic shear modulus. Default = none	S1 is a scalar directly proportional to the magnitude of the secant shear modulus and the reference shear strain.
Hardin parameter for hyperbolic shear modulus (C1) (41-50) (F10.0) (number)	Hardin parameter for hyperbolic shear modulus. Default = none	C1 is a parameter proportional to the magnitude of hyperbolic shear strain, which decreases the secant shear modulus

Parameter (columns) (format) (units)	Input Options	Description
Hardin parameter for hyperbolic shear modulus (A) (51-60) (F10.0) (dimensionless)	Hardin parameter for hyperbolic shear modulus. Default = none	A is parameter associated with the increase of hyperbolic shear strain, which decreases the secant shear modulus
Nonlinear iteration control (NON) (61-65) (I5) (integer)	Print control parameter Default = 0	Currently not operative. Use default.

Comment: This form of the Extended HARDIN soil model is intended be used in conjunction with tri-axial soil test data (MATNAM = USER). See CANDE 1976 Engineering Manual for curve fitting procedures for Hardin parameters.

Return to line D-1 for more material definition if needed.

Proceed to Part E if LRFD = 1

Otherwise, this completes the input stream for this problem.

5.6.7 D-2 – Interface Element – Angle, Friction and Tensile Breaking Force

D-2.Interface

Interface angle, friction, and tensile breaking force, and gap distance

Use if	Comments
A-1.LEVEL = 2 or 3	Use ONLY if the 'Solution Level' is 2 or 3.
D-1.ITYP = 6	Use only if the Material Model Type is Interface (6).

Parameter (columns) (format) (units)	Input Options	Description
Angle from x-axis to normal of interface (ANGLE) (01-10) (F10.0) (degrees)	Angle from x-axis to normal of interface. Default = 0.0 deg	<p>ANGLE is the arc in degrees starting from x-axis to the vector that is normal to the interface when traveling from interface node I to interface node J. ANGLE is treated as a material property so that each interface element with a unique angle must be defined with a separate material number in Part C.</p> <p>The angle and mechanical properties must be input for each interface material number. Thus for the general case, input data for lines D1 and D2 may need to be repeated for each interface element.</p> <p>A short-cut method is available for the typical case when the material numbers are consecutively numbered along any path wherein only the interface angle is changing and mechanical properties remain constant. In this case, only the beginning and ending material properties need to be input. See the discussion on next page.</p>
Coefficient of friction between nodes I and J (FCOEF) (11-20) (F10.0) (dimensionless)	Coefficient of friction between nodes I and J Default = 0.0	<p>FCOEF is the Coulomb friction between bodies I and J. If the interface shear force exceeds the product of the compressive normal force and friction coefficient, then the interface element permits relative slippage between the nodes according to the Coulomb friction hypothesis. A typical range of pipe-soil friction is 0.3 to 0.7. To simulate a bonded condition without slippage, set FCOEF to an arbitrary high value, say 1000.</p>

Parameter (columns) (format) (units)	Input Options	Description
Tensile breaking force of contact nodes (TENSIL) (21-30) (F10.0) (lbs/in)	Tensile breaking force of contact nodes I and J. Default = 1.0 lb/in	TENSIL is the force per unit length required to break the bond between nodes I and J. Should the interface normal force exceed the tensile breaking limit (TENSIL), the contact surfaces will separate from each other and only re-bond if subsequent loading brings them back together. To simulate a bonded condition without tensile rupture, set TENSIL to an arbitrary high value, say 10,000.
<u>Gap distance in normal direction (XNGAP)</u> (31-40) (F10.0) (inches)	<u>Initial normal gap distance between two nodes (positive value)</u> <u>Default = 0.0</u>	<u>XNGAP is the initial gap distance in the direction of the interface angle between two bodies containing nodes I and J.</u> <u>If the gap distance is specified to be zero (default), then the interface behaves the same as the original formulation (i.e., previous CANDE version). However if XNGAP is defined greater than zero, the two nodes I and J respond independently from each other until the normal gap becomes closed. Once the normal gap is closed the interface behavior follows the original formulation.</u>

Discussion of Short-Cut method of input for interface element properties.

The so-called short cut method of input is a reduction in the number of repetitions of lines D1&D2. This short cut is applicable to many common interface situations, and in particular, it is applicable to all interface options associated with Level 2. The short cut method requires that the interface material numbers are consecutively numbered along the interface path and that the mechanical properties (friction coefficient and tension resistance) remain the same along the path but not necessarily the interface angle.

The short-cut method only requires input for the first and last material number in the sequence, that is, input is required for input lines D1and D2 for the first material number and input lines D1 and D2 for the last material number. Each intervening interface element material number is automatically assigned an interface angle determined by constructing a local circle through three points which include its own point's coordinates and the point coordinates of two neighboring interface elements on either side of its own point. The angle assigned to the interface element is the angle that the radius vector makes with the x-axis. The mechanical properties assigned to each these intervening interface materials is the same as prescribed for the first material number.

In the way of an example, consider the case "Level 2-Pipe" with WORD1 = SLIP wherein there are 11 interface the interface materials starting with number 1 at the invert and proceeding counterclockwise to number 11 at the crown. (See Table 5.6-3). The corresponding angles for a circular pipe are: -90, -72, -54, -36, -18, 0, 18, 36, 54, 72, and 90. Thus the long way to input these angles would be to repeat lines D1 and D2 eleven times. The short-cut method would set I = 1 in line D1 and ANGLE = -90 in line D2 followed by one more set with I = 11 in D1 and ANGLE = +90 in D2.

For the case WORD1 = SLPT, the first interface material number starts at the node above the trench floor up to number 7 at the top of the trench. For a vertical trench wall, ANGLE = 0 deg for all seven interface elements. Again this could be established with the short-cut method with I = 1 in line D1 and ANGLE = 0

in line D2 followed by one more set with $I = 7$ in D1 and $ANGLE = 0$ in D2. In this case the straight line is converted into very large local circles to produce an interface angle equal to 0 degrees at intervening points.

For the Level 2 –Arch mesh, interface material numbering starts with number 1 at the crown ($ANGLE = 90$ degrees) and terminates with number 19 slightly above the footing wherein ($ANGLE$ is about 0 degrees but varies depending on arch input options). The short-cut method would set $I = 1$ in line D1 and $ANGLE = +90$ in line D2 followed by one more set with $I = 19$ in D1 and $ANGLE =$ about 0 degrees in D2.

Return to line D-1 for more material definition if needed.

Proceed to Part E if LRFD = 1

Otherwise, this completes the input stream for this problem.

5.7 Part E- Net LRFD Load Factors

This section provides a description of the LRFD Load Factors.
One unique net load factor must be assigned to each load step.

5.7.1 E-1 – LRFD – Net Load Factor per Load step

E-1
LRFD net load factor per load step

Use if	Comments
A-1.LEVEL = 2 or 3	Use ONLY if the 'Solution Level' is 2 or 3.
A-1.LRFD = 1	Use only if the 'Method of Analysis' is set to LRFD = 1.

Parameter (columns) (format) (units)	Input Options	Description
Starting load step (INCRS) (01–05) (15) (integer)	Starting load step number to apply the same load factor Default = 1	INCRS is the load step at which the load factor below will be applied. The first E-1 input must specify INCRS = 1. Subsequent E-1 inputs for INCRS, if needed, must specify INCRS = INCRL(previous) + 1.
Last load step (INCRL) (06–10) (15) (integer)	Last load step number to apply the same load factor Default = INCRS	INCRL is the last load step in this sequence of load steps that share the same load factor specified below. When INCRL = NINC, the input of E-1 data is complete. (NINC = total number of load steps specified in Part C)
Load factor (FACTOR) (11–20) (F10.0) (dimensionless)	LRFD load factor applied to the load steps INCRS through INCRL. Default = 1.00 See Table 5.7-1.	FACTOR is the net load factor applied to the load steps INCRS to INCRL (inclusive). It is the user's responsibility to determine the appropriate value of FACTOR that correlates to each load step. Table 5.7-1 provides information on load factors based on the AASHTO LRFD Specification.
Comment (COMMENT) (21–60) (A40) (words)	User supplied comments to explain load factor value Default = none	The comment, which can be up to 40 characters in length, is printed out with value FACTOR for each load step. The purpose of the comment is to document the rationale for the load factor value including load modifiers, etc.

Comment: If all load steps are assigned the same load factor, then the E-1 data line need only be entered once with INCRS = 1 and INCRL = NINC and the specified FACTOR common to each increment. At the other extreme, if each load step is assigned a different load factor (for whatever reason), then line E-1 would be repeated NINC times. In this case, the first E-1 entry would be INCRS = 1, INCRL = default, and the specified FACTOR for the first load step. The second E-1 entry would be INCRS = 2, INCRL =

default, and the specified FACTOR for the second load step, and so on through the last entry INCRS = NINC, INCRL = default, and the specified FACTOR for the last load step.

The input for this CANDE run is now complete.

Enter a STOP command (see line A-1) if no additional CANDE problems are to be included in this input file.

Table 5.7-1 – Guidance on selecting the net load factor (FACTOR)

Culvert Type	Dead Load Culvert (DC)			Earth fill Loading (EB)			Vehicle Loading (LL)		
	γ_{\max}	γ_{\min}	η_{DC}	γ_{\max}	γ_{\min}	η_{EB}	γ_{\max}	m	η_{LL}
Reinforced Concrete pipe	1.25	0.9	≥ 0.95	1.3	0.9	≥ 0.95	1.75	1.0-1.2	≥ 0.95
Reinforced Concrete box	1.25	0.9	≥ 0.95	1.3	0.9	≥ 0.95	1.75	1.0-1.2	≥ 0.95
Reinforced Concrete arch	1.25	0.9	≥ 0.95	1.3	0.9	≥ 0.95	1.75	1.0-1.2	≥ 0.95
Corrugated metal pipe or arch	1.25	0.9	≥ 0.95	1.95	0.9	≥ 0.95	1.75	1.0-1.2	≥ 0.95
Corrugated metal box	1.25	0.9	≥ 0.95	1.50	0.9	≥ 0.95	1.75	1.0-1.2	≥ 0.95
Plastic pipe (HDPE or PVC)	1.25	0.9	≥ 0.95	1.95	0.9	≥ 0.95	1.75	1.0-1.2	≥ 0.95

Symbols:

γ_{\max} = maximum standard load factor dependent on load case and culvert type.

γ_{\min} = minimum standard load factor dependent on load case and culvert type.

η_{DC} = composite load modifier for DC load case = {(ductility)(redundancy)(importance)}

η_{EB} = composite load modifier for EB load case = {(ductility)(redundancy)(importance)} η_{LL} = composite load modifier for LL load case = {(ductility)(redundancy)(importance)}

m = multiple presence factor for LL load case

IM = impact percentage for LL load case = $33\% \{1.0 - (\text{Cover depth in feet})/8.0\}$

The AASHTO LRFD specifications identify three load cases that generally pertain to buried structures; Dead load of Culvert (DC), Earth loading from Backfill operations (EB), and Live Loading of vehicles on the surface (LL). The user should define the CANDE model such that only one case of loading (DC, EB or LL) is applied to a particular load step. In this way the incremental responses from each load step can be attributed to the appropriate loading case.

DC Load Case. The culvert's dead load is often applied in the first load step if the existing in-situ soil is assumed elastic with zero body weight, or DC may be applied in the second load step if the first load step is used to characterize the deformation of the in-situ soil under its own body weight. In either event the net input value for the DC load case would generally be computed as $\text{FACTOR} = \gamma_{\max} \eta_{DC}$. Here, the maximum value of the load factor is used because it is anticipated the DC load case will add to the overall culvert distress resulting from the net contribution of the remaining load steps. The combined load modifier, η_{DC} , is a product of three factors related to ductility, redundancy and operational importance. Typically the factors associated with ductility and operational importances are assumed to be unity, whereas the LRFD specification says that redundancy factor should be 1.05 for buried structures under dead loads. Thus, a typical net value for a DC load step is $\text{FACTOR} = (1.25) \{ (1.00) (1.05) (1.00) \} = 1.31$.

EB Load Case. Earth backfill loads are usually applied in ten or so incremental load steps after the DC load step. Typically, the first few EB load steps are layers of soil that are compacted along the sides of the culvert, which often creates moments in the culvert that are opposite in sign to those of the DC load step and also opposite in sign to the moments that will be added into the culvert when subsequent EB load steps of soil are placed on top of the culvert. Thus in the spirit of seeking the worst case LRFD loading scenario, it may be reasonable to use γ_{\min} for the standard load factor for those EB load steps placed along the sides of the culvert so that $\text{FACTOR} = \gamma_{\min} \eta_{EB}$. Accordingly for the EB load steps representing soil layers being placed over the top of the culvert, it is reasonable to use γ_{\max} for the standard load factor so that $\text{FACTOR} = \gamma_{\max} \eta_{EB}$. Similar to the DC load case, the combined load modifier, η_{EB} , is a product of three factors related to ductility, redundancy and operational importance. Typically the factors associated with ductility and operational importances are assumed to be unity, whereas the LRFD specification says that redundancy factor should be 1.05 for buried structures under earth loads. Thus, a typical value for η_{EB} is 1.05, which is the product of $\{ (1.00) (1.05) (1.00) \}$.

LL Load Case. Live loads, which are typically represented by surface pressures related to the design truck tires, are usually the last load steps to be applied for shallow burial installations. The first step is to compute the service live load, which is the static wheel pressure multiplied by $m(1.00 + \text{IM}/100)$ where m is the multiple presence factor and IM is the impact percentage. The multiple presence factor, m , ranges from 1.0 to 1.2 for buried culverts and may be interpreted as the likelihood that another design truck is sufficiently close to the design truck being analyzed such that the load on the culvert is further increased. Thus, choosing $m = 1.2$ is a conservative approach. The impact percentage, IM , varies linearly from 33% to 0% as the minimum cover depth varies from 0.0 to 8.0 feet. The resulting service live load is applied as specified forces in Part C of this manual.

The second step is to compute the LRFD factor for the live load as $\text{FACTOR} = \gamma_{\max} \eta_{\text{LL}}$. Here, the LRFD specifications only provide a maximum value of the LL load factor, $\gamma_{\max} = 1.75$. Live loads typically produce moments whose signs are consistent with, and add to, the DC load case and the EB load case for soil layers above the culvert. The combined load modifier, η_{LL} , is a product of three factors related to ductility, redundancy and operational importance. Typically these three factors are assumed to be unity so that $\eta_{\text{LL}} = 1$.

Closing Comment. The above illustrations are not a recipe for all culvert problems because worst loading scenario depends on the pipe type, installation, and the governing limit state. However, the beauty of CANDE is that it is easy to re-run the same problem with another set of FACTORs to find the worst loading condition.

6 List of References

6.1 Background Documents

1. Katona, M.G., Smith, J.M., Odello, R.S., Allgood, J.R., *CANDE: A Modern Approach for the Structural Design and Analysis of Buried Culverts*, Federal Highway Administration Report No. FHWA-RD-77-5, (October 1976).
2. Katona, M.G., Smith, J.M., *CANDE User and System Manuals*, Federal Highway Administration Report No. FHWA-RD-77-6, October 1976.
3. Katona, M.G., Vittes, P.D., Lee, C.H., Ho, H.T., “CANDE-1980: Box Culverts and Soil Models”, *Federal Highway Administration, Report No. FHWA-RD-172*, (May 1981).
4. Musser, S.C., Katona M.G., Selig E.T., *CANDE-89: Culvert Analysis and Design computer program – User Manual*, Federal Highway Administration Report No. FHWA-RD-89-169, (June 1989).
5. Leonards, G.A, Wu, T.H., Juang, C.H., “Predicting Performance of Buried Conduits”, Report No. FHWA/IN/JHRP-81/3, Joint Federal Highway Administration and Indiana State Highway Commission, (June 1982).
6. *AASHTO LRFD Bridge Design Specifications*, Third Edition, American Association of State Highway and Transportation Officials, Washington, D.C., (2004)
7. Burns, J. Q., and R. M. Richard, “Attenuation of Stresses for Buried Cylinders”, Symposium on Soil-Structure Interaction, University of Arizona Engineering Research Laboratory, Tucson, Arizona, Proceedings (1964) pp. 378-392.
8. Mlynarski, M., Puckett, J.A., Clancy, C.M., Thompson, P.D., *NCHRP Report 485 – Bridge Software – Validation Guidelines and Examples*, Transportation Research Board, Washington, DC, (2003)

6.2 Companion Documents

1. *CANDE-2007 Solution Methods and Formulations* contains the mathematical developments that describe the various theoretical formulations and nonlinear models that are contained in CANDE-2007.
2. *CANDE-2007 Tutorials for Applications*: Contains a series of examples for using that demonstrate the use of CANDE-2007.

(This page intentionally left blank)

7 Appendices

7.1 CANDE Output Files

CANDE produces a variety of files as it processes the input and runs the CANDE analysis. The following table provides a synopsis of those file along with a brief description. A detailed description of the plot files is provided in subsequent sections of this Appendix.

File name	Description
<prefix>.cid The <prefix> is provided by the user upon creation of saving of the CANDE input document.	<u>CANDE input document</u> – this file stores the CANDE input instructions as described in Chapter 5 of this User Manual. The <prefix> of this document is used in naming other CANDE documents associated with this input document. This file may be generated manually, but is produced automatically with the CANDE input wizard and every time the user clicks on the ‘Accept Input’ within the CANDE Input Menus
<prefix>.bakNN	<u>CANDE input document Backup files</u> – These files are produced every time a CANDE input document is saved every time the user clicks on the ‘Accept Input’ button within the CANDE Input Menus. If a file is saved accidentally or a change was made that cannot be reversed using the CANDE input menus, the user can return to a previous version of the input document by copying the appropriate backup file to a new CANDE input document.
<prefix>.out	<u>CANDE Output file(readable text format)</u> This is the file that is generated when the CANDE analysis engine executes. It contains all of the pertinent analysis results.
<prefix>_Gen.out	<u>CANDE results generator output (readable text format)</u> CANDE output from results generator – This output file is produced by the CANDE results generator and is customizable. This file is produced after the CANDE analysis is completed as a post-processing event.
<prefix>_MeshGeom.xml	<u>Mesh geometry file (XML format)</u> This file is produced by the CANDE analysis engine and is used to plot the mesh geometry with the CANDE mesh viewer. This file will be produced for level 2 and 3 models.
<prefix>_MeshResults.xml	<u>Mesh results file (XML format)</u> This file is produced by the CANDE analysis engine and is used to plot the mesh results (i.e. deflections, stresses, strains, etc.) with the CANDE mesh viewer. If the ‘data check’ mode is ‘on’, or if the analysis did not successfully complete, this file may not be available. Often in these cases, the user will still be able to view the mesh geometry without the analysis results. This file will be produced for level 2 and 3 models.
<prefix>_BeamResults.xml	<u>Beam results file (XML format)</u> This file is produced by the CANDE analysis engine and is used to plot the beam graphing mesh results (i.e. bending moments, shear, thrust, etc.) in the local beam coordinate system. If the ‘data check’ mode is ‘on’, or if the analysis did not successfully complete, this file may not be available. Often in these cases, the user will still be able to view the mesh geometry without the analysis results. This file will be produced for Level 1, 2, and 3 models.

File name	Description
<prefix>_Process_1250.csv	<p><u>NCHRP Process 12-50 comma delimited file</u></p> <p>This file contains the Process 12-50 data as described in this appendix and in “<i>NCHRP Report 485 – Bridge Software – Validation Guidelines and Examples</i>”</p> <p>This file is only produced if the value for CULVERTID on the A-1 command (see section 5.3.1 A-1 – Master Control Input Data) is greater than zero.</p>
PLOT1.dat	<p><u>CANDE Plot1 file</u></p> <p>This contains finite element mesh data followed by finite element response data records for each load step. This file is automatically created in the same folder that the input file is stored with the extension PLOT1.dat. This is a legacy file that dates to CANDE-89 and has been updated for CANDE-2007.</p>
PLOT2.dat	<p><u>CANDE Plot2 file</u></p> <p>This contains pipe element mesh data followed by detailed pipe-element nodal response data records for each load step. This file is automatically created in the same folder that the input file is stored with the name PLOT2.dat. This is a legacy file that dates to CANDE-89 and has been updated for CANDE-2007.</p>

7.1.1 XML Mesh Geometry Format

The following is the XML mesh geometry format that is used by CANDE for plotting and graphing purposes. This file is automatically generated by CANDE for Levels 2 and 3. It is also used for importing external meshes into CANDE during the creation of new CANDE input documents using the CANDE input wizard. The definition of the XML tags are provided in tables at the end of this section.

```
<?xml version="1.0" encoding="UTF-8"?>
<CANDEMeshGeom>
  <Control>
    <numNodes> 789</numNodes>
    <numElements> 850</numElements>
    <numSoilMaterials> 3</numSoilMaterials>
    <numInterfaceMaterials> 0</numInterfaceMaterials>
    <inputCheck> 0</inputCheck>
    <numBoundCond> 55</numBoundCond>
    <numConstIncr> 15</numConstIncr>
    <meshTitle>MESH </meshTitle>
  </Control>
  <nodeData>
    <nodeCoord>
      <nodeNumber> 1</nodeNumber>
      <nodeXCoord> -0.4019E+02</nodeXCoord>
      <nodeYCoord> -0.3741E+02</nodeYCoord>
    </nodeCoord>
    <nodeCoord>
      <nodeNumber> 2</nodeNumber>
      <nodeXCoord> -0.3328E+02</nodeXCoord>
      <nodeYCoord> -0.3741E+02</nodeYCoord>
    </nodeCoord>
    .
    .
  </nodeData>
  <elementData>
    <elemConn>
      <elemNumber> 1</elemNumber>
      <elemNode1> 423</elemNode1>
      <elemNode2> 454</elemNode2>
      <elemNode3> 453</elemNode3>
      <elemNode4> 453</elemNode4>
      <elemMatNum> 2</elemMatNum>
      <elemConstrIncr> 12</elemConstrIncr>
      <elemType>TRIA</elemType>
    </elemConn>
    <elemConn>
      <elemNumber> 2</elemNumber>
      <elemNode1> 423</elemNode1>
      <elemNode2> 451</elemNode2>
      <elemNode3> 454</elemNode3>
      <elemNode4> 454</elemNode4>
      <elemMatNum> 2</elemMatNum>
      <elemConstrIncr> 12</elemConstrIncr>
      <elemType>TRIA</elemType>
    </elemConn>
    <elemConn>
      <elemNumber> 3</elemNumber>
```

```

    <elemNode1> 682</elemNode1>
    <elemNode2> 699</elemNode2>
    <elemNode3> 684</elemNode3>
    <elemNode4> 683</elemNode4>
    <elemMatNum> 2</elemMatNum>
    <elemConstrIncr> 12</elemConstrIncr>
    <elemType>QUAD</elemType>
  </elemConn>
  .
</elementData>
<boundaryData>
  <boundary>
    <boundNumber> 1</boundNumber>
    <boundNode> 21</boundNode>
    <boundConstrIncr> 1</boundConstrIncr>
    <boundXCode> 1</boundXCode>
    <boundYCode> 0</boundYCode>
    <boundXForce> 0.0000E+00</boundXForce>
    <boundYForce> 0.0000E+00</boundYForce>
    <boundRotAngle> 0.0000E+00</boundRotAngle>
  </boundary>
  <boundary>
    <boundNumber> 2</boundNumber>
    <boundNode> 432</boundNode>
    <boundConstrIncr> 1</boundConstrIncr>
    <boundXCode> 1</boundXCode>
    <boundYCode> 0</boundYCode>
    <boundXForce> 0.0000E+00</boundXForce>
    <boundYForce> 0.0000E+00</boundYForce>
    <boundRotAngle> 0.0000E+00</boundRotAngle>
  </boundary>
  .
</boundaryData>
<soilData>
  <soil>
    <matID> 1</matID>
    <iTYP> 1</iTYP>
    <density> 0.6944444E-01</density>
    <matName>in situ</matName>
  </soil>
  .
</soilData>
<interfaceData>
  <interface>
    <matID> 1</matID>
    <matName> Inter # 1</matName>
    <angle> 0.9000000E+02</angle>
    <coeffFriction> 0.3000000E+00</coeffFriction>
    <tensileForce> 0.1000000E+02</tensileForce>
  </interface>
  .
</interfaceData>
</CANDEMeshGeom>

```

Description of Tags**Master control: <Control>**

Tag	Type	Description
numNodes	Integer	Number of nodes
numElements	Integer	Number of elements
numSoilMaterials	Integer	Number of soil materials
numInterfaceMaterials	Integer	Number of interface materials
inputCheck	Integer	Input check
numBoundCond	Integer	Number of boundary conditions
numConstIncr	Integer	Number of load steps
meshTitle	String	Character string title

Node Information: <nodeData><nodeCoord> (1 to numNodes)

Tag	Type	Description
nodeNumber	Integer	Node identifier number
X	Double Precision	X-coordinate of nodeNumber
Y	Double Precision	Y-coordinate of nodeNumber

Element Information: <elementData><elemConn> (1 to numElements)

Tag	Type	Description
elemNumber	Integer	Element identifier number
elemNode1	Integer	Node 1 connected to element, all elements
elemNode2	Integer	Node 2 connected to element, all elements
elemNode2	Integer	Node 3 connected to element, repeat node 2 for beam
elemNode2	Integer	Node 4 connected to element, repeat node 3 except quad
elemMatNum	Integer	Material Number of the element
elemConstrIncr	Integer	Load step of the element
elemType	String	Either 'QUAD', 'TRIA', or 'BEAM'
elemSelected	String	1 – element selected by the user 0- element not selected by the user (default from CANDE)

Boundary Information: <boundaryData><boundary > (1 to numBoundCond)

Tag	Type	Description
boundNumber	Integer	Boundary identifier number
boundNode	Integer	Node identifier of the boundary condition
boundConstrIncr	Integer	Load step when boundary condition is effective
boundXCode	Integer	Either 0, 1, 2, or 3: 0-, x-force (rotation free) 1 – x-disp. (rotation fix) 2 – x-disp. (rotation free) 3 – x-force (rotation fix)
boundYCode	Integer	Either 0, 1, 2, or 3 0-, y-force (rotation free) 1 – y-disp. (rotation fix)

		2 – y-disp. (rotation free) 3 – y-force (rotation fix)
boundXForce	Double Precision	Value of x-force or x-disp.
boundYForce	Double Precision	Value of y-force or y-disp.
boundRotAngle	Double Precision	Angle of rotated coordinates to define boundary conditions.

Soil Information: <soilData><soil> (1 to numSoilMaterials)

Tag	Type	Description
matID	Integer	Soil material identifier
iTYP	Integer	CANDE soil material type.
density	double precision	Soil density
matName	String	Specifies either a CANDE predefined soil name or user provided description.

Interface Information: <interfaceData><interface> (1 to numInterfaceMaterials)

Tag	Type	Description
matID	Integer	Interface material identifier
matName	String	String to describe the material.
angle	double precision	Angle from x-axis to normal of interface.
coeffFriction	double precision	Coefficient of friction between nodes I and J
tensileForce	double precision	Tensile breaking force of contact nodes I and J.

7.1.2 Mesh results format

The following is the XML mesh results format that is used by CANDE for the plotting of the mesh results using the CANDE mesh viewer. This file is automatically generated by CANDE for Levels 2 and 3. The definition of the XML tags is provided in tables at the end of this section.

```
<CANDEMeshResults>
  <Control>
    <numNodes> 265</numNodes>
    <numElements> 229</numElements>
    <numConstIncr> 13</numConstIncr>
    <LevelNum>3</LevelNum>
    <Heading>217 Corr. Steel Pipe    </Heading>
  </Control>
  <elemOutputDesc>
    <st1BEAM>Thrust force at node I</st1BEAM>
    <st2BEAM>Shear force at node I</st2BEAM>
    <st3BEAM>Moment resultant at node I</st3BEAM>
    <st4BEAM>Thrust force at node J</st4BEAM>
    <st5BEAM>Shear force at node J</st5BEAM>
    <st6BEAM>Moment resultant at node J</st6BEAM>

    <st1TRIA>Vertical strain at element center</st1TRIA>
    <st2TRIA>Horizontal strain at element center</st2TRIA>
    <st3TRIA>Shear strain at element center</st3TRIA>
    <st4TRIA>Vertical stress at element center</st4TRIA>
    <st5TRIA>Horizontal stress at element center</st5TRIA>
    <st6TRIA>Shear stress at element center</st6TRIA>

    <st1QUAD>Vertical strain at element center</st1QUAD>
    <st2QUAD>Horizontal strain at element center</st2QUAD>
    <st3QUAD>Shear strain at element center</st3QUAD>
    <st4QUAD>Vertical stress at element center</st4QUAD>
    <st5QUAD>Horizontal stress at element center</st5QUAD>
    <st6QUAD>Shear stress at element center</st6QUAD>

    <st1INTF>Total normal interface force</st1INTF>
    <st2INTF>Total shear interface force</st2INTF>
    <st3INTF>Last increment of normal interface force</st3INTF>
    <st4INTF>Last increment of shear interface force</st4INTF>
    <st5INTF>Relative x-displacement inc. DU(J)-DU(I)</st5INTF>
    <st6INTF>Relative y-displacement inc. DV(J)-DV(I)</st6INTF>

  </elemOutputDesc>

  <displacementData>
    <dispConstIncr> 1</dispConstIncr>
    <nodeDispData>
      <nodeDisp>
        <nodeDispNumber> 1</nodeDispNumber>
        <nodeXDisp> 0.000000E+00</nodeXDisp>
        <nodeYDisp> 0.000000E+00</nodeYDisp>
      </nodeDisp>
      <nodeDisp>
        <nodeDispNumber> 2</nodeDispNumber>
        <nodeXDisp> 0.000000E+00</nodeXDisp>
      </nodeDisp>
    </nodeDispData>
  </displacementData>
</CANDEMeshResults>
```

```

        <nodeYDisp> 0.000000E+00</nodeYDisp>
    </nodeDisp>
    .
    .
    <elemDispData>
        <elemDisp>
            <elemDispNumber> 1</elemDispNumber>
            <elemDispType>BEAM</elemDispType>
            <st1> -0.562661E+03</st1>
            <st2> 0.144582E+02</st2>
            <st3> 0.195709E+04</st3>
            <st4> -0.562661E+03</st4>
            <st5> 0.144582E+02</st5>
            <st6> 0.208510E+04</st6>
        </elemDisp>
        <elemDisp>
            <elemDispNumber> 2</elemDispNumber>
            <elemDispType>BEAM</elemDispType>
            <st1> -0.580803E+03</st1>
            <st2> 0.389251E+02</st2>
            <st3> 0.162513E+04</st3>
            <st4> -0.580803E+03</st4>
            <st5> 0.389251E+02</st5>
            <st6> 0.195709E+04</st6>
        </elemDisp>
    .
    .
</displacementData>
    .
    .
<displacementData>
</displacementData>

```

Master control: <CANDEMashResults> <Control>

Tag	Type	Description
numNodes	Integer	Number of nodes
numElements	Integer	Number of elements
numConstIncr	Integer	Number of construction increments
LevelNum	Integer	CANDE model level
Heading	string	user input title

Element output descriptions: CANDEMashResults.elemOutputDesc

Defines the definitions of ST1-ST6 (Defined inelemDispData.elemDisp>) based on the element type (<elemDispType>).

Tag	Type	Description
st1BEAM	String	Description of beam ST1
st2BEAM	String	Description of beam ST2
st3BEAM	String	Description of beam ST3
st4BEAM	String	Description of beam ST4
st5BEAM	String	Description of beam ST5
st6BEAM	String	Description of beam ST6
st1TRIA	String	Description of TRIA ST1
st2TRIA	String	Description of TRIA ST2
st3TRIA	String	Description of TRIA ST3
st4TRIA	String	Description of TRIA ST4

Tag	Type	Description
st5TRIA	String	Description of TRIA ST5
st6TRIA	String	Description of TRIA ST6
st1QUAD	String	Description of QUAD ST1
st2QUAD	String	Description of QUAD ST2
st3QUAD	String	Description of QUAD ST3
st4QUAD	String	Description of QUAD ST4
st5QUAD	String	Description of QUAD ST5
st6QUAD	String	Description of QUAD ST6
st1INTF	String	Description of INTF ST1
st2INTF	String	Description of INTF ST2
st3INTF	String	Description of INTF ST3
st4INTF	String	Description of INTF ST4
st5INTF	String	Description of INTF ST5
st6INTF	String	Description of INTF ST6

Element/Node results data: `<CANDEMeshResults><displacementData>`

A set of this data is produced for each construction increment; i.e. There will be `CANDEMeshResults.Control.numConstIncr` sets of this data.

Construction increment: `<dispConstIncr> 1</dispConstIncr>`

Tag	Type	Description
dispConstIncr	Integer	Construction increment #

Node results data: `<CANDEMeshResults><displacementData> <nodeDispData> <nodeDisp>`

One result for each node `CANDEMeshResults.Control.numNodes`

Tag	Type	Description
nodeDispNumber	Integer	Node identifier number
nodeXDisp	Double Precision	X-Displacement of the node coordinate for this construction increment
NodeYDisp	Double Precision	Y-Displacement of the node coordinate for this construction increment

Element results data: `<CANDEMeshResults><displacementData> <elemDispData> <elemDisp>`

One result for each node `CANDEMeshResults.Control.numElements`

Tag	Type	Description
elemDispNumber	Integer	Element identifier number
elemDispType	String	Element type: Type is either BEAM, TRIA, INTF, QUAD and can be used to extract the 'output description for each 'st*' value shown below.
st1	Double Precision	Dependent on element type. Description comes from <code>CANDEMeshResults.elemOutputDesc</code>
st2	Double Precision	Dependent on element type. Description comes from <code>CANDEMeshResults.elemOutputDesc</code>
st3	Double Precision	Dependent on element type. Description comes from <code>CANDEMeshResults.elemOutputDesc</code>

Tag	Type	Description
st4	Double Precision	Dependent on element type. Description comes from CANDEMashResults.elemOutputDesc
st5	Double Precision	Dependent on element type. Description comes from CANDEMashResults.elemOutputDesc
st6	Double Precision	Dependent on element type. Description comes from CANDEMashResults.elemOutputDesc

7.1.3 Beam results format

The following is the XML beam results format that is used by CANDE for the plotting of the beam results using the CANDE Graphs viewer. This file is automatically generated by CANDE for Levels 1, 2 and 3. The definition of the XML tags is provided in tables at the end of this section.

```
<CANDEBeamResults>
  <Control>
    <numConstIncr> 13</numConstIncr>
    <numPipeElements> 19</numPipeElements>
    <numPipeNodes> 20</numPipeNodes>
    <Level>3</Level>
    <Heading>217 Corr. Steel Pipe
  </Heading>
    <meshTitle>Imported from 'C:\Documents and
Settings\bpstrohman\Desktop\Tutoria </meshTitle>
  </Control>
  <beamData>
    <numBeamGroups> 1</numBeamGroups>
    <beamGroup>
      <!--1- Steel, 2-Aluminum,3-Concrete,4-Plastic,5-Basic,6-Special
(Routine added by the user) -->
      <pipeCode> 1</pipeCode>
      <!-- Number of beam elem. in this group -->
      <numBeamElem> 19</numBeamElem>
      <startBeamElem> 1</startBeamElem>
      <endBeamElem> 19</endBeamElem>
      <startNode> 1</startNode>
      <endNode> 20</endNode>
    </beamGroup>
  </beamData>
  <beamResults>
    <constIncrement> 1</constIncrement>
    <resultsData>
      <resultId> 1</resultId>
      <nodeNumber> 1</nodeNumber>
      <!-- elem to right of node: 99999 if end -->
      <elementNumber> 1</elementNumber>
      <beamGroupNumber> 1</beamGroupNumber>
      <pipeType> 1</pipeType>
      <xCoord> 0.000000E+00</xCoord>
      <yCoord> 0.823800E+02</yCoord>
      <xDisp> 0.000000E+00</xDisp>
      <yDisp> -0.794825E+00</yDisp>
      <bendingMoment> 0.899943E+02</bendingMoment>
      <thrustForce> -0.466842E+01</thrustForce>
      <shearForce> 0.102312E-01</shearForce>
      <normalPressure> -0.979715E-06</normalPressure>
      <tangPressure> 0.989320E-09</tangPressure>
      <!-- Results 10-20 dependent on pipe type-->
      <result10> -0.800044E+03</result10>
      <result11> -0.174847E+02</result11>
      <result12> 0.383193E-01</result12>
      <result13> 0.000000E+00</result13>
      <result14> 0.267000E+001</result14>
      <result15> 0.127000E+00</result15>
```

```

    <result16> 0.110435E+01</result16>
    <result17> 0.000000E+00</result17>
    <result18> 0.242438E-01</result18>
    <momentIncrement> 0.240075E-04</momentIncrement>
    <thrustIncrement> -0.251048E-04</thrustIncrement>
  </resultsData>
</resultsData>
.
.
</resultsData>
.
.
</beamResults>
<beamResults>
  <constIncrement> 2</constIncrement>
  .
  .
</beamResults>
.
.
</CANDEBeamResults>

```

Master control: <CANDEBeamResults> <Control>

Tag	Type	Description
numConstIncr	Integer	Number of construction increments
numPipeElements	Integer	Total number of pipe elements
numPipeNodes	Integer	Total number of pipe nodes
LevelNum	Integer	CANDE model level
Heading	string	user input title

Beam Data: <CANDEBeamResults> <beamData> <beamGroup>

Number of Beam Groups: <numBeamGroups> 4</numBeamGroups>

Beam Group: <CANDEBeamResults><beamData><beamGroup>

Set of this data is produced for each beam group

Tag	Type	Description
pipeCode	Integer	code for the pipe type: 1- Steel, 2- Aluminum,3-Concrete,4-Plastic,5-Basic,6-Special (Routine added by the user)
numBeamElem	Integer	Number of beam elements in the group
startBeamElem	Integer	Starting element sequence number in the group
endBeamElem	Integer	Ending element sequence number in the group
startNode	Integer	Starting node sequence number in the group
endNode	Integer	Ending node sequence number in the group

Beam Results: <CANDEBeamResults><beamResults>

Construction increment: <constIncrement> 1</constIncrement>

Results Data: <CANDEBeamResults><beamResults><resultsData>

Set of this data is produced for each element in this beam group; i.e.

CANDEBeamResults.beamData.beamGroup.numBeamElem>

Tag	Type	Description
resultId	Integer	result ID number
nodeNumber	Integer	node ID number
elementNumber	Integer	element to the right of nodeNumber; 9999 if the last node number
beamGroupNumber	Integer	beam group for this result
pipeType	Integer	code for the pipe type: 1- Steel, 2- Aluminum,3-Concrete,4-Plastic,5-Basic,6-Special (Routine added by the user)
xCoord	Double Precision	x coordinate of nodeNumber
yCoord	Double Precision	y coordinate of nodeNumber
xDisp	Double Precision	x displacement of nodeNumber for this construction increment
yDisp	Double Precision	y displacement of nodeNumber for this construction increment
bendingMoment	Double Precision	bending moment
thrustForce	Double Precision	thrust force (compression = negative)
shearForce	Double Precision	shear force
normalPressure	Double Precision	normal pressure on pipe
tangPressure	Double Precision	tangential pressure on pipe
result10	Double Precision	dependent on pipe type
result11	Double Precision	dependent on pipe type
result12	Double Precision	dependent on pipe type
result13	Double Precision	dependent on pipe type
result14	Double Precision	dependent on pipe type
result15	Double Precision	dependent on pipe type
result16	Double Precision	dependent on pipe type
result17	Double Precision	dependent on pipe type
result18	Double Precision	dependent on pipe type
momentIncrement	Double Precision	moment increment
thrustIncrement	Double Precision	thrust increment

7.1.4 NCHRP Process 12-50 Results

For the purposes of regression testing of future versions of CANDE, the NCHRP Process 12-50 results have been included in this version of CANDE. Process 12-50 is described in detail in *NCHRP Report 485 – Bridge Software – Validation Guidelines and Examples*. This file is only produced if the value for CULVERTID on the A-1 command (see section 5.3.1 A-1 – Master Control Input Data) is greater than zero. For CANDE, the 12-50 file format is a comma-delimited ASCII text format and has been modified slightly to account for the two dimensions (i.e. X and Y coordinates). The format is as shown in the following table. This file is suitable for importing into a relational database. A sample of the Process 12-50 output is shown in Figure 7.1-1.

Table 7.1-1 – NCHRP Tag format

Tag	Description
CulvertID	Unique integer to define this input file (user input on A-1 command)
ProcessID	Unique integer to define the process ID (user input on A-1 command).
ReportID	Unique integer to uniquely define each CANDE beam result (see Table 7.1-2 for definitions)
X-location	X-coordinate location of beam node
Y.location	Y-coordinate location of beam node
Value	Value for the specific ReportID
Subdomain	Unique integer to define the subdomain ID (user input on A-1 command). Subdomains can define things such as culvert type.
Location ID	CANDE Beam group ID
AuxID	CANDE local element ID

Figure 7.1-1 – Sample NCHRP Process 12-50 results

```

12, 2, 80003, 0.000000E+00, 0.823800E+02, 0.000000E+00, 1, 1, 1
12, 2, 80004, 0.000000E+00, 0.823800E+02, -0.794825E+00, 1, 1, 1
12, 2, 80005, 0.000000E+00, 0.823800E+02, 0.899943E+02, 1, 1, 1
12, 2, 80006, 0.000000E+00, 0.823800E+02, -0.466842E+01, 1, 1, 1
12, 2, 80007, 0.000000E+00, 0.823800E+02, 0.102312E-01, 1, 1, 1
12, 2, 80008, 0.000000E+00, 0.823800E+02, -0.979715E-06, 1, 1, 1
12, 2, 80009, 0.000000E+00, 0.823800E+02, 0.989320E-09, 1, 1, 1
12, 2, 80010, 0.000000E+00, 0.823800E+02, -0.800044E+03, 1, 1, 1
12, 2, 80011, 0.000000E+00, 0.823800E+02, -0.174847E+02, 1, 1, 1
12, 2, 80012, 0.000000E+00, 0.823800E+02, 0.383193E-01, 1, 1, 1
12, 2, 80013, 0.000000E+00, 0.823800E+02, 0.000000E+00, 1, 1, 1
12, 2, 80014, 0.000000E+00, 0.823800E+02, 0.267000E+00, 1, 1, 1
12, 2, 80015, 0.000000E+00, 0.823800E+02, 0.127000E+00, 1, 1, 1

```

Table 7.1-2 – NCHRP Process 12-50 Report ID table

Report ID	Description
80003	x – displacement (inc)
80004	y – displacement (inch)
80005	Bending moment – positive in fiber tension (in-lb/ inch)
80006	Thrust Force – compression negative (lb/inch)
80007	Shear Force – outward positive (lb/inch)
80008	Normal Pressure on pipe – compression is negative (psi)
80009	Tangential pressure on pipe – positive is clockwise (psi)

Report ID	Aluminum	Basic	Concrete	Plastic	Steel
80010	Maximum fiber stress (psi)	0	Inner cage steel stress (psi)	Max Bending stress (psi)	Maximum fiber stress (psi)
80011	Thrust Stress (psi)	0	Outer cage steel stress (psi)	Thrust Stress (psi)	Thrust Stress (psi)
80012	Shear Stress (psi)	0	Max concrete compression (psi)	Shear Stress (psi)	Shear Stress (psi)
80013	Fraction of wall yielded (ratio)	0	Effective shear stress (psi)	Maximum tensile strain (in/in)	Fraction of wall yielded (ratio)
80014	Modified area (PA*) (in ² /in)	0	Effective Area (PA*) (in ² /in)	Effective Area (PA*) (in ² /in)	Modified area (PA*) (in ² /in)
80015	Modified M-of-I (PI*) (in ⁴ /in)	0	Effective M-of-I (PI*) (in ⁴ /in)	Effective M-of-I (PI*) (in ⁴ /in)	Modified M-of-I (PI*) (in ² /in)
80016	Distance to N-A (y-bar) (in)	0	Distance to N-A (y-bar) (in)	Distance to N-A (y-bar) (in)	Distance to N-A (y-bar) (in)
80017	Bend-stress above yield (psi)	0	Crack Width (inch)	Maximum combined strain (in/in)	Bend-stress above yield (psi)
80018	Strain ratio: max/yield (ratio)	0	Crack Depth (inch)	Percent of remaining area (%)	Strain ratio: max/yield (ratio)

Report ID	Description
80019	Moment increment – current inner strain during iteration (in-lb/inch)
80020	Thrust increment – current outer strain during iteration (lb/inch)

7.1.5 CANDE-2007 Output Files for Plotting

This appendix defines two output files generated by CANDE-2007 that the user may access to plot and/or further process the CANDE input and output. The data files are legacy files that were part of CANDE-89 and have been included to maintain compatibility with any software that continues to use these files. The files are standard ASCII text with a format as described in the following section.

Plot data from CANDE is provided on two files controlled by user input parameter called “IPLOT”. The two files called PLOT1 and PLOT2 are described below.

1. PLOT1 (alias File 10 in CANDE): This contains finite element mesh data followed by finite element response data records for each load step. This file is automatically created in the same folder that the input file is stored with the extension PLOT1.dat.
2. PLOT2 (alias File 30 in CANDE): This contains pipe element mesh data followed by detailed pipe-element nodal response data records for each load step. This file is automatically created in the same folder that the input file is stored with the extension PLOT2.dat.

User control for parameter IPLOT:

IPLOT = 0, data not written to either PLOT1 or PLOT2
 IPLOT = 1, data written to only PLOT1, not PLOT2.
 IPLOT = 2, data written to only PLOT2, not PLOT1.
 IPLOT = 3, data written to both PLOT1 and PLOT2.

7.1.5.1 Contents of PLOT1.DAT

The following records (a) and (b) are sequentially written to PLOT1. Record (a) is written in subroutine SAVED and contains all the constant mesh data. Record (b) is written in subroutine RESOUT and contains the finite element response data for each load step.

(a) FORTRAN statements used to write records written to PLOT1 from subroutine SAVED (mesh data),

- WRITE(LUPLOT,6010) (TITLE(K),K=1,17)
 6010 FORMAT(///,17A4,///)
 title = character strings of user title from the input line (PREP) – (string)
- WRITE(LUPLOT,6015) NPT,NELEM,NUMMAT,NPUTCK,NBPTC,NINC
 6015 FORMAT(I5,5(‘,’,I5))
 npt = Total number of nodal points – (integer)
 numel = Total number of elements – (integer)
 nummat = Number of materials – (integer)
 nputck = Input check code – (integer)
 nbptc = Number of boundary condition nodes – (integer)
 ninc = Number of construction increments – (integer)
- WRITE(LUPLOT,6020) (N, X(N),Y(N)), N=1,NPT)
 6020 FORMAT(I5,2(‘,’,E12.4))
 n = node number – (integer)
 x(n) = X-coordinate of node – (inches)
 y(n) = Y-coordinate of node – (inches)
- WRITE(LUPLOT,6025) (N, (NOD(K,N),K=1,4),KODE(N),NOD(6,N)), N= 1, NELEM
 6025 FORMAT(I5,6(‘,’,I5))
 n = element number – (integer)
 nod(n,1) = node 1 connected to element, all elements – (integer)

nod(n,2) = node 2 connected to element, all elements – (integer)
 nod(n,3) = node 3 connected to element, repeat node 2 for beam – (integer)
 nod(n,4) = node 4 connected to element, repeat node 3 except quad,
 – (integer)
 kode(n) = material number of soil element, for beam and interface =11
 – (integer)
 nod(n,6) = construction increment number of element – (integer)

- WRITE(LUPLOT,6035) N,NDB,IA,IFLAGX,IFLAGY,(BIV(K,N), K=1,3)
 6035 FORMAT(I5,4(' ',I5),3(' ',E12.4))
 n = number of a specified boundary condition – (integer)
 ndb = node with imposed boundary condition – (integer)
 ia = construction increment when boundary condition is effective – (integer)
 Iflagx = X-boundary code (0,1,2, or 3) see CANDE manual – (integer)
 Iflagy = Y-boundary code (0,1,2, or 3) see CANDE manual – (integer)
 biv(1,n) = Specified x-direction force or displacement – (lbs/inch or inch)
 biv(2,n) = Specified y-direction force or displacement – (lbs/inch or inch)
 biv(3,n) = Angle of rotated boundary coordinate system -- (radians)

(b) Records written to PLOT1 from RESOUT. These records sequentially follow the above record (a), wherein record (b) is repeated for each load step from ia = 1 to ninc.

- WRITE(LUPLOT,1000) IA
 1000 FORMAT(I5)
 ia = current construction increment number or load step quad – (integer)
- WRITE(LUPLOT,1010) (U(N),V(N)), N = 1, NPT)
 1010 FORMAT(E12.4, ' ',E12.4)
 n = node number – (integer)
 u(n) = Total current displacement in x direction – (inch)
 v(n) = Total current displacement in y direction – (inch)
- WRITE(LUPLOT,1020) (ST(J,N), J=1,6), N=1,NELEM)
 1020 FORMAT(E12.4, 5(' ',E12.4))
 n = element number – (integer)
 st(array) depends on element type as shown below:

st(array)	Continuum Elements (Quad or Triangle)	Beam elements (2-nodes I and J)	Interface Elements (3-nodes, I, J and K)
ST(1,N)	Horizontal strain at element center (in/in)	Thrust force at node I (lb/inch)	Total normal interface force (lb/inch)
ST(2,N)	Vertical strain at element center (in/in)	Shear force at node I (lb/inch)	Total shear interface force (lb/inch)
ST(3,N)	Shear strain at element center (in/in)	Moment resultant at node I (in-lb/inch)	Last increment of normal interface force (lb/inch)
ST(4,N)	Horizontal stress at element center (psi)	Thrust force at node J (lb/inch)	Last increment of shear interface force (lb/inch)
ST(5,N)	Vertical stress at element center (psi)	Shear force at node J (lb/inch)	Relative x-displacement inc. DU(J)-DU(I) (inch)
ST(6,N)	Shear stress at element center (psi)	Moment resultant at node J (in-lb/inch)	Relative y-displacement inc. DV(J)-DV(I) (inch)

- IF(IA.EQ.NINC) END FILE LUPLOT

7.1.5.2 Contents of PLOT2.dat

The following records (a) and (b) are sequentially written to PLOT2. Record (a) is written in subroutine SAVED and contains only a few key parameters. Record (b) is written in subroutine RESOUT and contains pipe-element group data (written during first load step only) followed by all pipe-element response data for each load step.

(a) Records written to PLOT2 from subroutine SAVED (global beam element data),

- WRITE(30,6010) (TITLE(K),K=1,17)
6010 FORMAT(///, "", 17A4, "")
title = character strings of user title from the PREP input line. (string)
- WRITE(30,6030) NINC,NPMAT,NPPT
6030 FORMAT(I5,2(' ',I5))
ninc = total number of construction increments (integer)
npmat = total number pipe (beam) elements (integer)
nppt = total number of pipe (beam) nodes (integer)

(b) Records written to PLOT1 from subroutine RESOUT. On first load step the pipe-element group data is written once and for all. For the first and subsequent load steps, all beam element responses are recorded from the global RESULT array, which contains all pipe-element groups.

- IF(IA.EQ.1) WRITE(30,1100) NPGRPS,(NTYPEX(N),NPMATX(N),
NPMAT1(N),NPMAT2(N),NPPT1(N),NPPT2(N),N=1,NPGRPS) --- written only on first increment.
1100 FORMAT(I5,(6(' ',I5)))

npgrps = Number of pipe-element groups -- a group is connected. (integer)
ntypex(n) = Pipe-type code number (1,2,3,4,5 or 6) for group n. (integer)

npmatx(n) = Number of beam elements in group -- local count. (integer)
 npmat1(n) = Starting element sequence number in group -- global count. (integer)
 npmat2(n) = Ending element sequence number in group -- global count. (integer)
 nppt1(n) = Starting node sequence number in group -- global count. (integer)
 nppt2(n) = Ending node sequence number in group -- global count. (integer)
 npmat = Total number of beam elements -- global sum of all groups. (integer)
 nppt = Total number of beam nodes -- global sum of all groups. (integer)

- WRITE(30,1000) IA --- written every increment
1000 FORMAT(I5)

ia = construction increment number or load step. (integer)

- WRITE(30,1110) (RESULT(J,N),J=1,20) , N=1, NPPT)
1110 FORMAT(E12.4,19(' ',E12.4))

(Note: RESULT(1,N) to RESULT(9,N) and RESULT(19,N) and RESULT(20,N) are common for all pipe types)

RESULT(1,N) = X-COORDINATE (inch)
 RESULT(2,N) = Y-COORDINATE (inch)
 RESULT(3,N) = X-DISPLACEMENT (inch)
 RESULT(4,N) = Y-DISPLACEMENT (inch)
 RESULT(5,N) = BENDING MOMENT -- positive in fiber tension.
 (in-lb/ inch)
 RESULT(6,N) = THRUST FORCE -- compression negative (lb/inch)
 RESULT(7,N) = SHEAR FORCE – outward positive. (lb/inch)
 RESULT(8,N) = NORMAL PRESSURE ON PIPE – compression is negative.
 (psi)
 RESULT(9,N) = TANGENTIAL PRESSURE ON PIPE -- positive is clockwise.
 (psi)
 RESULT(10,N) through RESULT(18,N) are dependent on pipe-type as shown below:

RESULT Array	Aluminum	Basic	Concrete	Plastic	Steel
(10,N)	Maximum fiber stress (psi)	0	Inner cage steel stress (psi)	Max Bending stress (psi)	Maximum fiber stress (psi)
(11,N)	Thrust Stress (psi)	0	Outer cage steel stress (psi)	Thrust Stress (psi)	Thrust Stress (psi)
(12,N)	Shear Stress (psi)	0	Max concrete compression (psi)	Shear Stress (psi)	Shear Stress (psi)
(13,N)	Fraction of wall yielded (ratio)	0	Effective shear stress (psi)	Maximum tensile strain (in/in)	Fraction of wall yielded (ratio)
(14,N)	Modified area (PA*) (in ² /in)	0	Effective Area (PA*) (in ² /in)	Effective Area (PA*) (in ² /in)	Modified area (PA*) (in ² /in)
(15,N)	Modified M-of-I (PI*) (in ⁴ /in)	0	Effective M-of-I (PI*) (in ⁴ /in)	Effective M-of-I (PI*) (in ⁴ /in)	Modified M-of-I (PI*) (in ² /in)
(16,N)	Distance to N-A (y-bar) (in)	0	Distance to N-A (y-bar) (in)	Distance to N-A (y-bar) (in)	Distance to N-A (y-bar) (in)
(17,N)	Bend-stress above yield (psi)	0	Crack Width (inch)	Maximum combined strain (in/in)	Bend-stress above yield (psi)
(18,N)	Strain ratio: max/yield (ratio)	0	Crack Depth (inch)	Percent of remaining area (%)	Strain ratio: max/yield (ratio)

RESULT(19,N) = MOMENT INCREMENT -- current inner strain during iteration.
(in-lb/inch)

RESULT(20,N) = THRUST INCREMENT -- current outer strain during iteration.
(lb/inch)

7.2 CANDE NASTRAN Import Format

CANDE supports a limited import of NASTRAN files based on the information based in this section. The NASTRAN import is available for Level 3 models when creating a new CANDE input document using the CANDE Input Wizard (see section “4.2.1.2 CANDE Input Wizard – Level 3 items”). The NASTRAN commands supported by the NASTRAN import option are shown in . CANDE’s implementation of these commands is documented in this section.

Table 7.2-1 – NASTRAN commands support by CANDE import

NASTRAN Command	NASTRAN Description	CANDE Use
GRID	Defines the location of a geometric grid point of the structural model and its permanent single point constraints.	Defines level 3 node numbers.
CBAR	Defines a simple beam element (BAR) of the structural model.	Defines a CANDE beam-column element.
CTRIA3	Defines an isoparametric triangular plate element.	Defines a CANDE triangle element.
CQUAD4	Defines an isoparametric quadrilateral plate element	Defines a CANDE quadrilateral element.
PSHELL	Defines the membrane, bending, transverse shear, and coupling properties of thin shell elements.	CANDE interprets this as a soil material. Material properties are not stored, but the PSHELL commands are counted to determine the number of soil materials CANDE defines.
CGAP	Defines a gap or friction element.	CANDE uses the CGAP command to define interface elements.
SPC	Defines the location of a geometric grid point of the structural model and its permanent single point constraints.	CANDE uses the SPC command to define boundary conditions.
FORCE	Defines a static load at a grid point by specifying a vector.	CANDE uses the FORCE command to define boundary conditions as point forces.

7.2.1 NASTRAN Input Data Card- GRID- Point

Description: Defines the location of a geometric grid point of the structural model and its permanent single point constraints.

Format and Example:

1	2	3	4	5	6	7	8	9	10
GRID	ID	CP	X	Y	Z	CD	PS		
GRID	2		1.0	-2.0	0.0		12		

<u>Field</u>	<u>Contents</u>
ID	Grid Point identification number (INTEGER).
CP	Coordinate system ID used to define the node location
X, Y, Z	Location of the grid point (REAL)
CD	Coordinate system ID used to define the displacements
PS	Permanent single-point constraints associated with grid point (any of the digits 1-6 with no embedded blanks) (INTEGER or blank)

CANDE Implementation:

Field	Description	Notes:
2	Retrieves node number	
4	Retrieves x- coordinate	
5	Retrieves y- coordinate	

7.2.2 NASTRAN Input Data Card-CBAR Simple Beam Element

Description: Defines a simple beam element (BAR) of the structural model.


Format and Example:

1	2	3	4	5	6	7	8	9	10
CBAR	EID	PID	GA	GB	X1	X2	X3		
CBAR	3	2	7	3	0.0	1.0	0.0		

Field	Contents
EID	Unique element identification number (INTEGER).
PID	Identification number of a PBAR property card (INTEGER).
GA, GB	Grid point identification numbers of connection points (INTEGER).
X1, X2, X3	Components of orientation vector \vec{v} , from GA, in the displacement coordinate system of GA (REAL).

Remarks:

1. Orientation vector ignored.



CANDE Implementation:

Field	Description	Notes:
2	Retrieves element number	CANDE cannot 'skip' number elements. If the NASTRAN elements are skip-numbered, CANDE will renumber them sequentially.
3	Saves material number as place holder	For Beam materials, CANDE requires that the Beam material numbering be sequential starting with 1. CANDE saves the material number but requires the user to define the material later. If multiple beam material numbers are present, the import will mark them and renumber them starting with 1. For example, if beam material ID's 4 and 7 are present in the NASTRAN file,, CANDE will convert the 4 to a 1 and the 7 to a 2.
4	Start element location (Node I)	
5	End element location (Node J)	

7.2.3 NASTRAN Input Data Card-CTRIA3-Triangular Plate Element

Description: Defines an isoparametric triangular plate element.

Format and Example:

1	2	3	4	5	6	7	8	9	10
CTRIA3	EID	PID	G1	G2	G3				
CTRIA3	3	2	7	3	12				

Field Contents

EID Unique element identification number (INTEGER).
 PID Identification number of a PSHELL property card (INTEGER).
 G1, G2, G3 Grid point identification numbers of connection points (INTEGER).

CANDE Implementation:

Field	Description	Notes:
2	Retrieves element number	CANDE cannot 'skip' number elements. If the NASTRAN elements are skip-numbered, CANDE will renumber them sequentially.
3	Saves material number as place holder	CANDE saves the material number but requires the user to define the material number later
4	Node location (Node I)	
5	Node location (Node J)	
6	Node location (Node K)	

7.2.4 NASTRAN Input Data Card-CQUAD4-Quadrilateral Plate Element

Description: Defines an isoparametric quadrilateral plate element.

Format and Example:

1	2	3	4	5	6	7	8	9	10
CQUAD4	EID	PID	G1	G2	G3	G4			
CQUAD4	4	2	8	6	12	14			

Field

Contents

EID Unique element identification number (INTEGER).

PID Identification number of a PSHELL property card (INTEGER).

G1, G1, G3, G4 Grid point identification numbers of connection points (INTEGER).

CANDE Implementation:

Field	Description	Notes:
2	Retrieves element number	CANDE cannot 'skip' number elements. If the NASTRAN elements are skip-numbered, CANDE will renumber them sequentially.
3	Saves material number as place holder	CANDE saves the material number but requires the user to define the material number later
4	Node location (Node I)	NOTE:: CANDE does not accept elements that are input clockwise. If the NASTRAN element is clockwise, CANDE will produce an error and the user will need to manually change the orientation.
5	Node location (Node J)	
6	Node location (Node K)	
7	Node location (Node L)	

7.2.5 NASTRAN Input Data Card- PSHELL-Shell Element Property

Description: Defines the membrane, bending, transverse shear, and coupling properties of thin shell elements.

Format and Example:

1	2	3	4	5	6	7	8	9	10
PSHELL	PID	MID	T	MID2	12I/T^3	MID3	TS/T	NSM	
PSHELL	11	2	0.125						

Field

Contents

PID Property identification number (INTEGER)
 MID Material identification number for the membrane (INTEGER)
 T Default membrane thickness for the element
 MID2 Material identification number for bending (INTEGER)
 12I/T^2 Bending moment of inertia ratio. (REAL)
 MID3 Material identification number for transverse shear (INTEGER)
 TS/T Transverse shear thickness ratio (default = 0.833333) (REAL)
 NSM Nonstructural mass per unit area. (REAL)

CANDE Implementation:

CANDE simply uses this command to keep count of the number of soil materials. CANDE does not store the actual material properties.

7.2.6 NASTRAN Input Data Card-CGAP-Gap Element Connection

Description: Defines a gap or friction element.

Format and Example:

1	2	3	4	5	6	7	8	9	10
CGAP	EID	PID	GA	GB	X1	X2	X3	CID	
CGAP	11	2	4	5					

Field Contents

EID Element identification number (INTEGER)
 PID Property identification number (INTEGER)
 GA,GB Connected Grid points (INTEGER)
 X1,X2,X3 Components of the orientation vector (REAL)
 CID Element coordinate system (INTEGER)

CANDE Implementation:

For each CGAP command detected, CANDE will place an interface element and will use the following rules to determine the interface angle:

1. The first node in a Gap element should be attached to the beam and the second is attached to the soil. It will be up to the user to make sure the mesh is generated in this way or there will be translation problems. If the user wants this translator to get interface element angles from the mesh, they must slightly move the soil element node away from the beam node by about 0.1 inch.
2. The CANDE importer will obtain the X and Y coordinates of the two nodes defining the Gap element (X1 and Y1 for the first node and X2 and Y2 for the second node).
3. Compute $DX1=X1-X2$, $DY1=Y1-Y2$.
4. IF $ABS(DX1)<1.E-5$.and. $ABS(DY1)<1.E-5$ then the nodes will be considered coincident. The user will need to set the interface angle in CANDE. The user will be notified because the MATNAM in CANDE will be set to "User must set angle"
5. If the two nodes are not coincident, $\Theta = \text{atan2}(DY1,DX1)$.
6. Make the two nodes coincident (i.e. $X2=X1$ and $Y2=Y1$)
7. If a total of N nodes have been read in, generate a new node numberN+1 with the same X and Y coordinates as the first and second nodes. For example, if 10 gaps elements are read in, there will be 10 additional nodes in the mesh.

7.2.7 NASTRAN Input Data Card-SPC-Single Point Constraint

Description: Defines the location of a geometric grid point of the structural model and its permanent single point constraints.

Format and Example:

1	2	3	4	5	6	7	8	9	10
SPC	SID	G1	C1	D1	G2	C2	D2		
SPC	2	1	123456	0.0	2	1	0.0		

<u>Field</u>	<u>Contents</u>
SID	Identification number of the single point constraint set (INTEGER).
G1	Grid point identification number (INTEGER)
C1	Component number. (any of the digits 1-6 with no embedded blanks) (INTEGER)
D1	Value of enforced displacement
G2	Grid point identification number (INTEGER)
C2	Component number. (any of the digits 1-6 with no embedded blanks) (INTEGER)
D2	Value of enforced displacement

CANDE Implementation:

For each SPC command detected, CANDE will place a boundary condition. CANDE converts the NASTRAN boundary codes as described in the following table: If one of boundary codes 1, 2 or 6 is not detected, the SPC command will be ignored.

NASTRAN Boundary Code	CANDE IIFLG(1) X-Code	CANDE IIFLG(2) Y-Code	x- displacement	y- displacement	xy- rotation
1	2	0	Fixed	Free	Free
2	0	2	Free	Fixed	Free
12	2	2	Fixed	Fixed	Free
16	1	0	Fixed	Free	Fixed
26	0	1	Free	Fixed	Fixed
126	1	1	Fixed	Fixed	Fixed

7.2.8 Input Data Card-FORCE-Static Load

Description: Defines a static load at a grid point by specifying a vector.

Format and Example:

1	2	3	4	5	6	7	8	9	10
FORCE	SID	G	CID	F	N1	N2	N3		
FORCE	1	1	1	200.	1.	0.5	0.0		

<u>Field</u>	<u>Contents</u>
SID	Load set identification number (INTEGER)
G	Grid point identification number where load is applied (INTEGER).
CID	Coordinate system identification number (INTEGER)
F	Scale factor (REAL).
N1	X component of the force (REAL)
N2	Y component of the force (REAL)
N3	Z component of the force (REAL)

CANDE Implementation:

For each FORCE command detected, CANDE will place a boundary condition at the specified Grid Point ID (G). The boundary conditions will be placed as follows:

CANDE IIFLG(1) X-Code	CANDE IIFLG(2) Y-Code	x- Value	y- Value	Construction Increment
0	0	$F * N1$	$F*N2$	1

(This page intentionally left blank)